

Homemory®
LOVE AND JOY
HMBBKYKGL-LST2
Led Taper Candles



Homemory HMBBKYKGL-LST2 Led Taper Candles User Manual

[Home](#) » [Homemory](#) » Homemory HMBBKYKGL-LST2 Led Taper Candles User Manual 

Contents

- [1 Homemory HMBBKYKGL-LST2 Led Taper Candles](#)
- [2 Introduction](#)
- [3 Specifications](#)
- [4 Package Includes](#)
- [5 Features](#)
- [6 Usage](#)
- [7 Care and Maintenance](#)
- [8 Troubleshooting](#)
- [9 Pros and Cons](#)
- [10 Contact Information](#)
- [11 Warranty](#)
- [12 FAQs](#)
- [13 Video-Homemory HMBBKYKGL-LST2 Led Taper Candles](#)
- [14 References](#)

Homemory®
LOVE AND JOY

Homemory HMBBKYKGL-LST2 Led Taper Candles



Price: \$67.80 to \$69.16

Introduction

The Homemory HMBBKYKGL-LST2 LED Taper Candles are a beautiful alternative to traditional candles that don't have flames. They have the look of real wax with the safety and ease of LED lights. These taper candles, which are 9.6 inches long, glow like a real flame, making the room feel warm and inviting. Since they run on batteries, you can put them anywhere in your house without having to find a power outlet. The included remote control makes it easy to use by letting you change the brightness, set a timer, and turn the lights on and off. These candles are great for decorating your home, weddings, and holiday events. They are also safe for kids and pets, so you don't have to worry about adding them to any place. The batteries in the Homemory HMBBKYKGL-LST2 candles last up to 200 to 300 hours, making them a long-lasting and low-maintenance way to light your home. The realistic look and warm glow of these lights make any room feel more charming. These flameless candles add a touch of grace to any room, whether they're on a windowsill, a mantel, or a dinner table.

Specifications

- **Model Number:** HMBBKYKGL-LST2
- **Material:** Wax exterior, LED light source
- **Item Dimensions:** 0.78" (Diameter) x 9.6" (Height)
- **Base Diameter:** 0.78 inches
- **Item Shape:** Taper
- **Shade Color:** Yellow (glow)

- **Finish Type:** Polished
- **Power Source:** Battery Powered
- **Light Source Type:** LED
- **Battery Requirements:** 2 AA batteries (not included)
- **Remote Control Included:** Yes
- **Lighting Method:** LED
- **Special Features:** Battery Operated, Remote Control, Flameless Flickering Effect

Package Includes

- **2 x LED Taper Candles (9.6" height, 0.78" diameter)**
- **1 x Remote Control** (for controlling the candles)
- **User Manual** (for setup and operation)

Features



1. Realistic Flickering Flame:

The **Homemory HMBBKYGGL-LST2** candles use advanced **LED technology** to simulate the natural flicker of a real flame. This creates a warm, inviting ambiance in any room, perfect for cozy evenings or romantic settings

2. Battery-Powered Convenience:

These **taper candles** run on **2 AA batteries** (not included), offering flexibility in placement without the need for an electrical outlet. Enjoy up to **200-300 hours** of use with a single set of batteries, making them an energy-efficient and portable lighting option.

3. Remote Control Functionality:

The **included 10-key remote control** allows you to operate the candles from a distance. You can easily turn them on or off, adjust the brightness, or set the **timer function**, all without touching the candles themselves.

4. **Timer Function:**

Set a **timer** for 4, 6, or 8 hours with the **remote control**, and the candles will automatically turn off after the specified time. The timer function cycles every **24 hours**, so you don't have to worry about remembering to turn them off. This feature saves energy and extends battery life.

5. **Safe and Flameless:**

These candles are a **safe alternative** to traditional flame-based candles. With no open flames, hot wax, or smoke, the **Homemory HMBBKYKGL-LST2 candles** are perfect for homes with children or pets. They eliminate any fire hazard while still providing the ambiance of real candles.

6. **Long Battery Life:**

Thanks to the **LED technology**, these candles are highly energy-efficient, offering up to **200-300 hours** of continuous use on a single set of **2 AA batteries**. This long battery life means fewer replacements and longer enjoyment.

7. **Versatile Use:**

The **Homemory HMBBKYKGL-LST2 LED taper candles** are perfect for **various settings**, including dining tables, fireplaces, weddings, holiday décor, and home accent lighting. Their elegant design makes them a beautiful and versatile addition to any room.

8. **Realistic Appearance:**

Covered in **real wax**, these taper candles look like traditional candles. The **warm white glow** and the **flickering flame** effect add to the authenticity, creating a cozy and atmospheric ambiance that enhances any décor.

9. **3D Flame Technology:**

The **3D flame design** creates a flickering effect with **warm yellow light**, making these candles more realistic than ever before. This 3D effect provides the warmth and charm of real flames without any of the risks associated with open flame candles.

10. **Real Wax Construction:**

The **Homemory HMBBKYKGL-LST2** taper candles feature a **real wax** exterior and a **dripping wax effect**, giving them a refined appearance that mimics traditional candles. This wax exterior adds to their beauty while keeping them safe and functional. No mess, no smoke, no hazards.

11. **Size and Dimensions:**

The **9.6-inch height** and **0.78-inch diameter** make these candles the perfect size for windowsills, mantels, or tables. Their elegant proportions also make them ideal for creating romantic or cozy atmospheres at weddings, Christmas gatherings, or other special occasions.

12. **Convenient Remote:**

The **10-key remote** lets you control all of the candle functions: on/off, **timer** (2, 4, 6, or 8 hours), **brightness adjustment**, and the **flickering effect**. With the remote, you can easily adjust the settings from a distance, making it convenient for hard-to-reach spots.

13. **No Fire Hazard:**

With no flame and no wax dripping, the **Homemory HMBBKYKGL-LST2** candles are a much safer alternative to traditional candles. You can safely place them on bookshelves, mantels, or around the house without worrying about fire hazards or mess.

14. **Button Cell Battery Warning:**

The remote control uses a **button cell battery**, which can be dangerous if swallowed. Always keep the remote control and its batteries out of the reach of children. If swallowed, seek immediate medical attention.

Usage

- **Home Décor:** Ideal for enhancing the atmosphere of living rooms, dining rooms, and bedrooms with a cozy, inviting glow.
- **Special Events:** Perfect for creating romantic lighting for weddings, dinners, or holidays like Christmas and Thanksgiving.
- **Safety:** Use in areas where traditional candles might pose a fire hazard, such as near curtains, in children's rooms, or around pets.
- **Outdoor and Indoor Settings:** While designed primarily for indoor use, these candles can also be used in sheltered outdoor spaces like patios, provided they are kept dry.

Care and Maintenance

1. **Battery Replacement:** Replace the **AA batteries** when the light becomes dim or stops working. Batteries are easily replaceable.
2. **Cleaning:** Clean the candles with a soft, dry cloth to remove dust and dirt. Avoid using water or harsh cleaning products.
3. **Remote Control:** Store the remote control safely, and replace the **button cell battery** as needed. Keep it away from children.
4. **Storage:** If not in use for extended p

Troubleshooting

Issue	Solution
Candle does not turn on	Check if the batteries are properly inserted and ensure they are not depleted. Replace with fresh batteries if necessary.
Flickering is uneven or not smooth	If flickering is erratic, replace the batteries as low battery power may affect the flickering effect.
Remote control not working	Ensure the remote has a working button cell battery . Ensure you are within the effective range of 16-20 feet.
Timer function is not working	Verify that the timer is set correctly via the remote. The candles automatically reset every 24 hours, so check if the cycle needs to be restarted.
Candle not responding to remote	Check the remote's battery. Try pressing the on/off button firmly and ensure the remote is pointing directly at the candles.
Low brightness or dim light	Replace the batteries as low power can cause the light to dim. Adjust brightness using the remote.
Candle is not lighting after battery change	Make sure the battery polarity is correct and that the battery contacts are clean. Ensure batteries are properly inserted.
Timer cycle not resetting	Ensure the timer function is properly set for a 2, 4, 6, or 8-hour cycle. Check that the candles are within the 24-hour timer reset window.
Candle stops working after a few hours	If the candle stops working unexpectedly, check the battery connections and ensure there is no corrosion.
Candle's flame doesn't flicker	Ensure that the LED bulb inside the candle is functioning. If the flickering is still off, try replacing the batteries.
Remote working intermittently	Ensure there is a clear line of sight between the remote and the candles, and check the battery in the remote.
Candles not turning off	If the candles are not turning off using the remote, reset the remote control or try removing and re-inserting the batteries.
Candle wax finish getting damaged	Avoid placing the candles in direct sunlight or high-heat areas, which can cause the wax exterior to soften or deform.
The candles aren't as bright as expected	If the brightness seems too low, replace the batteries with fresh ones and check the remote brightness settings .
Timer function repeats too early	Ensure the candles are not in constant operation mode. The timer should automatically reset after the 24-hour cycle completes.

Pros and Cons

Pros	Cons
Realistic wax appearance	Requires batteries
Safe alternative to traditional candles	Limited battery life
Remote control convenience	Not suitable for outdoor use
Adjustable brightness and timer settings	May be more expensive than basic options

Contact Information

For customer support or inquiries regarding your Homemory products, please contact our dedicated team via email at support@homemory.com or call our helpline at 1-800-HOMEMORY.

Warranty

Homemory offers a one-year warranty on all products against manufacturing defects. For warranty claims, please retain your purchase receipt and contact our customer service team for assistance.

FAQs

What is the size of the Homemory HMBBKYKGL-LST2 LED taper candles?

The Homemory HMBBKYKGL-LST2 candles are 9.6 inches tall and 0.78 inches in diameter, making them perfect for window sills, mantels, and dining tables.

How do the Homemory HMBBKYKGL-LST2 LED taper candles work?

The Homemory HMBBKYKGL-LST2 candles are powered by 2 AA batteries, and they use LED technology to create a realistic flickering flame effect.

Can I use the Homemory HMBBKYKGL-LST2 candles outdoors?

The Homemory HMBBKYKGL-LST2 candles are intended for indoor use only and should be kept in dry, cool places, away from high humidity or direct sunlight.

How long do the batteries last in the Homemory HMBBKYKGL-LST2 candles?

The Homemory HMBBKYKGL-LST2 candles can last up to 200-300 hours with a fresh set of 2 AA batteries.

What are the timer settings available on the Homemory HMBBKYKGL-LST2 candles?

The Homemory HMBBKYKGL-LST2 candles feature a timer function with 4, 6, or 8-hour cycles that repeat every 24 hours.

How do you replace the batteries in the Homemory HMBBKYKGL-LST2 candles?

Simply remove the bottom cap of the Homemory HMBBKYKGL-LST2 candles, insert 2 AA batteries (ensuring the correct polarity), and replace the cap.

What type of wax is used for the exterior of the Homemory HMBBKYKGL-LST2 candles?

The Homemory HMBBKYKGL-LST2 candles are made with real wax, which gives them a realistic appearance, even down to the dripped wax effect at the top.

What is the effect of the 3D flame on the Homemory HMBBKYKGL-LST2 candles?

The 3D flame creates a flickering effect that mimics the movement of real flames, adding to the realistic appearance of the candles.


What happens if the timer function on the Homemory HMBBKYKGL-LST2 candles isn't working properly?

If the timer isn't functioning, try resetting the timer via the remote control or ensure the batteries are fresh and inserted correctly.

How do I store the Homemory HMBBKYKGL-LST2 candles when not in use?

Store the Homemory HMBBKYKGL-LST2 candles in a cool, dry place away from direct sunlight and extreme temperatures to maintain their appearance and functionality.

Video-Homemory HMBBKYKGL-LST2 Led Taper Candles



<https://manuals.plus/wp-content/uploads/2024/11/Homemory-HMBBKYKGL-LST2-Led-Taper-Candles.mp4>

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.