



# Homtime S1-AC Clock Radio with Bluetooth Speaker and Power Outlets User Manual

[Home](#) » [Homtime](#) » Homtime S1-AC Clock Radio with Bluetooth Speaker and Power Outlets User Manual 

## Contents

- [1 Homtime S1-AC Clock Radio with Bluetooth Speaker and Power Outlets](#)
- [2 IMPORTANT SAFETY INSTRUCTIONS](#)
- [3 Product Features](#)
- [4 What is included](#)
- [5 Specification Parameters](#)
- [6 Product Features](#)
- [7 Play Music from Mobile via Bluetooth](#)
- [8 FM Radio Operation](#)
- [9 FCC Caution](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)



**Homtime S1-AC Clock Radio with Bluetooth Speaker and Power Outlets**



## IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions.
2. Keep these instructions
3. Heed all warnings.
4. Follow all instructions
5. Do not use this apparatus near water
6. Cleaning-Unplug this product from the wall outlet before cleaning, Do not use liquid cleaners or aerosol cleaners. Use a dry cloth for cleaning
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (Including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized or grounding- type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus. the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

15. Do not overload wall outlet. Use only power source as indicated.
16. Use replacement part as specified by the manufacturer.
17. The product may be mounted to a wall only if recommended by the manufacturer.
18. Upon completion of any service or repairs to this product, ask the service technician to perform safety checks.

## **Product Features**

1. Elegant and fashionable design; simple setting
2. Built-in Bluetooth
3. 3.2 inch LCD display screen
4. FM Digital Radio
5. 4 level dimmable
6. Stereo speaker, providing superior quality sound
7. USB port allows for traditional USB Charging for most devices on the market
8. Alarm clock and Snooze function

## **What is included**


Open S1-AC's box, and you will find

- S1-AC Body Unit 1 PCS
- User Manual 1 PCS


## **Specification Parameters**

- **Bluetooth Version:** 3.0+EDR
- **Bluetooth Profiles:** A2DP, AVRCP, HFP, HSP
- **Receive range:** Up to 10 meters
- **Output Power:** 3W + 3W
- **Driver Unit:** 4Ω 3W 1.6in
- **Frequency range:** 40Hz-20KHz
- **S/N Ratio:** >65dB
- **Distortion Rate:** <1%
- **FM Frequency Range:** 87.5 ~ 108MHz
- **Product Net Weight:** 0.97kg
- **Product Size:** 138\*138\*72mm

## **Diagram of the LCD Display & the Buttons**



1. Bluetooth
2. FM Radio
3. FM Frequency
4. SNOOZE
5. Alarm
6. Alarm Time
7. Sleep
8. Time Setting
9. Adjusting Time
10. FM Antenna
11. Fuse



Button	Function
	Volume up
	Volume down
	Bluetooth
	Micro SD
FM	FM Radio
SLEEP	SN00ZE 10-20-30-40-50-60-70-80-90-OFF Minute
	Pause/Auto Scan FM Station
	Time Setting of Alarm
+	Skip Forwards next Song
-	Skip Backwards last Song
SNOOZE   DIMMER	SNOOZE, Display Brightness Level (4Levels: 1-2-3-4)

## Product Features

### Set Time

Under any mode, press “Time” to set time. Press “+” or “-” to switch the Hour mode between 12-Hour and 24-Hour. Press “Time” to confirm it. Then Hour figure and MINUTE figure begin to flash. Press “+” or “-” to adjust the HOUR and press “Time” to confirm it, then press “+” or “-” to adjust the MINUTE and press “Time” to confirm the setting. It will confirm and exit the setting in 5 seconds if no operation on any key.

### Set Alarm Time

Under any mode, Press and hold for 2s to enter alarm time setting, icon displays on the LCD. Press “+” or “-” to adjust the alarm time, Press to confirm. It will confirm and exit the setting in 5 seconds if no operation on any key.

## Play Music from Mobile via Bluetooth


### Operation

Press to put Bluetooth on, on the LCD display start flashing, turn on Bluetooth on your mobile phone and search Bluetooth devices. Connect “S1-AC”, When it is successfully paired, you will hear a sound of “DU”. Play music from your mobile now.


### Play Music

When playing music, press to pause the music. Press to skip backwards last song, Press to skip forwards next song.

## FM Radio Operation

Press to put FM radio on, press and hold  to auto scan radio station and store the scanned stations accordingly. The frequency starts from 87.5MHz to 108MHz and skips at every 0.1 MHz in scanning process. Once catching a station, it stops a second and store it, then continues the auto-scanning. When it scans from 87.5MHz to 108MHz or stores 20 stations, it will stop scan automatically. Press “+” or “-” to select the station.

### **Play Music from Micro SD**

Insert a micro SD card into the Micro SD card Jack, press , Play music now.

### **SLEEP Function under On Mode**

Press to set timing shutdown time from 90-80-70.....OFF. Choose the time, it will store it automatically in 3 seconds and exit the setting. To see the remaining sleep time, press .

### **Back-up Button Battery**

The 3V button battery is to retain the alarm/clock in case of a power failure. It can not display the alarm/clock time.

### **Smart charging function**

Dual USB ports can charge any devices by USB cable.

### **Infrared remote control(Optional)**

Install the battery: Unscrew the back cover of the remote control, open the screws, install 3 pieces AAA battery, lock the screw and screw the back cover. Sync time with phone: Unscrew the back cover of the remote control, connect the remote control's lightning connector to the iPhone interface. In this way, the time will be synced with iPhone. Sync time with the remote control: Align the remote control with the alarm screen, press the sync button on the remote control, the time of the remote control will be transmitted to the alarm clock and turn off the alarm, reset the alarm.

### **FCC Caution**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **RF warning for Mobile device:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body

- [info@homtime.com](mailto:info@homtime.com)
- [www.homtime.com](http://www.homtime.com)
- [www.facebook.com/homtime.global](https://www.facebook.com/homtime.global)

## Documents / Resources

	<a href="#">Homtime S1-AC Clock Radio with Bluetooth Speaker and Power Outlets</a> [pdf] User Manual S1-AC, S1AC, 2A3X5-S1-AC, 2A3X5S1AC, S1-AC Clock Radio with Bluetooth Speaker and Power Outlets, S1-AC, S1-AC Clock Radio, Clock Radio, Clock Radio with Bluetooth Speaker and Power Outlets, Radio with Speaker, Bluetooth Speaker and Power Outlets
---	--

## References

- [🌐 Alarm clock with USB charger | alarm clock with bluetooth speaker | wireless charger nightstand | clock radio | iPhone docking station | best alarm clock | best alarm clock | bluetooth speaker | alarm clock with wireless charging clock radio-homtime.com](#)