

Honeywell
CT37 Series
HC Mobile
Computer



Honeywell CT37 Series HC Mobile Computer User Guide

[Home](#) » [Honeywell](#) » Honeywell CT37 Series HC Mobile Computer User Guide 

Contents

- [1 Honeywell CT37 Series HC Mobile Computer](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Out of the Box](#)
- [5 Memory Card Specifications](#)
- [6 Computer Features](#)
- [7 Install a Nano SIM Card \(WWAN Models\)](#)
- [8 About the Battery](#)
- [9 Install the Hand Strap \(SKU Dependent\)](#)
- [10 Charge the Mobile Computer](#)
- [11 Turn Power On/Off](#)
- [12 Screen Timeout](#)
- [13 Navigation and Function Buttons](#)
- [14 Sync Data](#)
- [15 Restart the Mobile Computer](#)
- [16 Documents / Resources](#)
 - [16.1 References](#)
- [17 Related Posts](#)

Honeywell

Honeywell CT37 Series HC Mobile Computer



Product Information

Specifications

- **Model:** CT37 Series
- **Operating System:** Android™
- **Memory Card Compatibility:** Single Level Cell (SLC) industrial grade microSD™, microSDHCTM, or microSDXCTM
- **Battery Type:** Li-ion
- **Charging Time:** Minimum of 3 hours with CT37 charging device

Product Usage Instructions

Memory Card Installation

1. Ensure the device is powered off.
2. Insert the compatible memory card into the designated slot.
3. Contact Honeywell for guidance on qualified memory card options.

Battery Installation

1. Locate the battery latch and unlock it.
2. Insert the Li-ion battery provided by Honeywell.

Hand Strap Installation

Depending on the version you have, follow the appropriate steps for installing the hand strap.

Charging the Mobile Computer

Charge the device using a CT37 charging device for a minimum of 3 hours before initial use. Avoid using the device while charging to expedite the charging process.

FAQ

- **Q: What type of memory cards are recommended for use with the CT37 Series?**

A: Honeywell recommends Single Level Cell (SLC) industrial grade microSD™, microSDHC™, or microSDXC™ memory cards for optimal performance and durability.

- **Q: How long should I charge the battery before initial use?**

A: Charge the battery for a minimum of 3 hours using a CT37 charging device that comes with the mobile computer.

Agency Models

CT37 Series: CT37X0N, CT37X1N

Note: Due to variations in model configurations, your computer may appear different than illustrated.

Out of the Box

Make sure that your shipping box contains these items:

- **Standard SKUs:**

- CT37 mobile computer
- Rechargeable Li-ion battery
- Standard hand strap
- Product Documentation

- **Healthcare SKUs:**

- CT37 mobile computer
- Rechargeable Li-ion battery
- USB Type C plug (SKU dependent, pre-installed)
- Product Documentation

If you ordered accessories for your mobile computer, verify that they are also included with the order. Be sure to keep the original packaging in case you need to return the mobile computer for service.


Note: CT37X0N models do not include a WWAN radio.

Memory Card Specifications


Honeywell recommends the use of Single Level Cell (SLC) industrial grade microSD™, microSDHC™ or microSDXC™ memory cards with mobile computers for maximum performance and durability. Contact a Honeywell sales representative for additional information on qualified memory card options.


Computer Features

Note: Due to variations in model configurations, your computer may appear different than illustrated.




Note: Hand strap not shown.





Install a Nano SIM Card (WWAN Models)





Either a nano-SIM card or embedded SIM (eSIM) is used to activate the phone and connect to a mobile network. Refer to the user guide for additional information.



Note: Always power off the computer before attempting to install or remove a nano-SIM card.

Install a microSD Card (Optional)

Note: Format the microSD card before initial use.




Note: Always power off the computer before attempting to install or remove a microSD card.

About the Battery

The mobile computer ships with a Li-ion battery manufactured for Honeywell International Inc.

- Before you attempt to use, charge or replace the battery in the device, carefully read all labels, markings and product documentation provided in the box or online at sps.honeywell.com. To learn more about Battery Maintenance for Portable Devices, go to honeywell.com/PSS-BatteryMaintenance.
- We recommend use of Honeywell Li-ion battery packs. Use of any non-Honeywell battery may result in damage not covered by the warranty.
- Ensure all components are dry prior to placing the battery in the computer. Mating wet components may cause damage not covered by the warranty.




Install Battery






Install the Hand Strap (SKU Dependent)

Standard Version

Note: See page 11 for Healthcare hand strap version (sold separately).



Healthcare Version (Sold Separately)



Note: The optional hand strap for healthcare models is intended for use in environments where cleaning and disinfecting are performed.

Charge the Mobile Computer

The mobile computer ships with a partially charged battery. Charge the battery before initial use with a CT37 charging device for a minimum of 3 hours.

Note: Using the computer while charging the battery increases the time required to reach a full charge. If the mobile computer is drawing more current than supplied by the charging source, charging will not take place. We recommend the use of Honeywell accessories and power adapters. Use of any non-Honeywell accessories or power adapters may cause damage not covered by the warranty.

CT37 series mobile computers are designed for use with CT37 charging accessories. For more information, see the CT37 Accessory Guide available for download at sps.honeywell.com.

Ensure all components are dry prior to mating the computers and batteries with peripheral devices. Mating wet components may cause damage not covered by the warranty.

About the USB Type C Connector

You can use a USB cable to charge the mobile computer from a host device (e.g., laptop or desktop computer).


The connected host device must supply a minimum power output of 5V, 0.5A to the CT37 or the battery will not charge.

Note: On Healthcare SKUs, verify the USB Type C plug has been removed before attempting to attach a cable to the USB connector.

About the USB Type C Plug

Healthcare models include a protective plug for the USB Type C connector that is pre-installed. When you reinstall the plug, make sure the plug is flush with the body of the computer.

Note: Do not use sharp or metallic instruments to install or remove the plug.



Note: Verify the plug is properly installed if intermittent charging and/or communication issues occur when the computer is placed in an accessory.

Turn Power On/Off

Note: Charge the battery before initial use with a CT37 charging device for a minimum of 3 hours.

The first time you power on the computer, a Welcome screen appears. You can either scan a configuration barcode or use the Wizard to manually set up the computer. Once setup is complete, the Welcome screen no longer appears on startup and Provisioning mode is automatically turned off (disabled).

To turn the computer on:

- Press and hold the ePower button for approximately 3 seconds and then release.

To turn the computer off:

1. Press and hold the Power button until the options menu appears.
2. Touch Power Off.

Battery Replacement, Hot Swap

The computer includes an internal battery that provides limited power for on demand replacement of the main battery (i.e., hot swap).

You can replace the battery on demand provided the following conditions are met:

- The internal battery is charged (see note).
- You insert a charged battery within 60 seconds.
- Refer to the user guide for additional guidance on use of the battery hot swap feature.

Note: The internal battery is charged via the main battery but can be depleted if too many consecutive hot swaps occur over a short time. If a low internal battery notification displays, do not perform a hot swap until the notification clears. The internal battery is not user replaceable.

Note: Do not install or remove the microSD card or nano-SIM card while performing a hot swap.

Screen Timeout

The screen timeout (sleep mode) automatically turns the touch panel display off and locks the computer to save battery power when the computer is inactive for a programmed period of time.


- Press and release the Power button to wake the computer.

Adjust the Screen Timeout

To adjust the amount of time before the display sleeps after inactivity:








1. Swipe up on the touch screen.
2. Select Settings > Display > Screen Timeout.
3. Select the amount of time before the display goes to sleep.

About the Home Screen



Navigation and Function Buttons

For button locations, see Computer Features on page 3.


Button	Description	
	Back	Return to the previous screen.
	Home	Return to the Home screen.
	Recent Apps	View and switch between recently used apps.
	Volume	Press the top of the button to raise the speaker volume. Press the bottom of the button to lower the speaker volume.
	Scan	Press left or right Scan button to trigger the scanner.
	Push-to-Talk	Push-to-Talk button for use with apps that support the feature for voice over IP (VoIP) calls over Wi-Fi or cellular data network connections.
	Power	<ul style="list-style-type: none">• Turn Power On/Off• Enter/Exit Screen Timeout (sleep).• Access options menu, including: Power off, Restart, and Screen Timeout.

About Provisioning Mode

After completing the out-of-box set up process, Provisioning mode is automatically turned off. Scanning a barcode to install applications, certificates, configuration files, and licenses on the computer is restricted unless you enable Provisioning mode in the Settings app. To learn more, see the user guide.

Scan a Barcode with the Scan Demo

For optimum performance, avoid reflections by scanning the barcode at a slight angle.



1. Swipe up on the screen.
2. Select Demos > Scan Demo.
3. Point the computer at the barcode.
4. Touch Scan on the screen or press and hold any Scan button. Center the aiming beam over the barcode.

The decode results appear on the screen.

Note: In the Scan Demo app, not all barcode symbologies are enabled by default. If a barcode does not scan, the correct symbology may not be enabled. To learn how to modify the default app settings, see the user guide.

Sync Data

To move files between your CT37 and a computer:

1. Connect the CT37 to your computer using a USB charge/communication accessory.
2. On the CT37, swipe down from the top of the screen to see the notifications panel.
3. Touch the Android System notification twice to open the options menu.
4. Select either File Transfer or PTP.
5. Open the file browser on your computer.
6. Browse to the CT37. You can now copy, delete, and move files or folders between your computer and CT37 as you would with any other storage drive (e.g., cut and paste or drag and drop).

Note: When Provisioning mode is turned off, some folders are hidden from view in the file browser.

Restart the Mobile Computer

You may need to restart the mobile computer to correct conditions where an application stops responding to the system or the computer seems to be locked up.

1. Press and hold the Power button until the options menu appears.
2. Select Restart.

To restart the computer if the touch panel display is unresponsive:

- Press and hold the ePower button for approximately 8 seconds until the computer restarts.

Note: To learn about advanced reset options, see the user guide.

Support

To search our knowledge base for a solution or log into the Technical Support Portal and report a problem, go to honeywell.com/PSTechnicalsupport.

Documentation

Product documentation is available at sps.honeywell.com.

Limited Warranty

For warranty information, go to sps.honeywell.com and click Support > Productivity > Warranties.

Patents

For patent information, see www.hsmpats.com.


Trademarks

Android is a trademark of Google LLC.
Other product names or marks mentioned in this document may be trademarks or registered trademarks of other companies and are property of their respective owners.

Disclaimer

Honeywell International Inc. (“HII”) reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. HII makes no representation or warranties regarding the information provided in this publication.
HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. HII disclaims all responsibility for the selection and use of software and/or hardware to achieve intended results.
This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.
Copyright © 2024 Honeywell Group of Companies.
All rights reserved.

Documents / Resources

	Honeywell CT37 Series HC Mobile Computer [pdf] User Guide CT37 Series HC Mobile Computer, CT37 Series, HC Mobile Computer, Mobile Computer, Computer
---	---

References

- [H Honeywell SPS Community](#)
- [H Industrial Automation | Honeywell](#)
- [H Industrial Automation | Honeywell](#)
- [H Industrial Automation | Honeywell](#)
- [H Productivity products and associated patents | Honeywell](#)
- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.