



Honeywell EDA50-HB-R Single Charging Dock User Manual

[Home](#) » [Honeywell](#) » Honeywell EDA50-HB-R Single Charging Dock User Manual 

Honeywell EDA50-HB-R Single Charging Dock



Contents

1 CHARGERS

1.1 Basic Chargers

1.2 Non-Booted Universal Docks (for 6-pin models only)

1.3 Battery Chargers

2 MOBILE

2.1 Mobile Accessories

3 POWER SUPPLY

3.1 Battery

4 Power Adapter and Plugs

5 Documents / Resources

5.1 References

6 Related Posts

CHARGERS

Basic Chargers



EDA50-HB-R

Single Charging Dock

Charging dock for ScanPal™ EDA50/EDA50HC/ EDA51, EDA52/EDA52HC, EDA56 Wi-Fi 6, EDA57.

For EDA52/EDA52HC, EDA56 Wi-Fi 6, EDA57 charging needs to be worked with EDA52-ADC. Compatible with EDA51/EDA52 scan handle.

Does not include charging cable; cable (CBL500-120-S00) and power adapter and plugs (50130570- 001) must be ordered separately

EDA52-HB-0

EDA52-HB-1

EDA52-HB-2

EDA52-HB-3


EDA52-HB-5



Single Charging Home Base

Single charging home base for ScanPal EDA52/ EDA52 HC/EDA56 Wi-Fi 6/EDA57 terminal and battery. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Compatible with EDA52 scan handle.

Non-Booted Universal Docks (for 6-pin models only)




EDA52-CB-0
EDA52-CB-1
EDA52-CB-2
EDA52-CB-3
EDA52-CB-5

Quad Bay Charging Base

Quad bay charging base for ScanPal EDA52/ EDA52HC/EDA56 Wi-Fi 6/EDA57 terminals and batteries. Kit contains power supply and power cord. (-0 no power cord, -1 for U.S., -2 for Europe, -3 for UK, and -5 for AU). Compatible with EDA52 scan handle.

Non-Booted Universal Docks (for 6-pin models only)



EDA52-NB-UVN-0
EDA52-NB-UVN-2

Non-booted Net Base

EDA52/EDA52 HC/EDA56 Wi-Fi 6/ EDA57 non-booted net base for Ethernet communications and recharging up to four computers. Kit includes net base and power cord (-0 no power cord, -2 for Europe).



EDA52-EB-UN-0
EDA52-EB-UN-2

Non-booted Ethernet Base

EDA52/EDA52 HC/EDA56 Wi-Fi 6/

EDA57 Non-booted Ethernet base for recharging one computer and one battery, Ethernet communications. Kit includes Ethernet home base and power cord (-0 no power cord, -2 for Europe)



EDA52-DB-UVN-0

EDA52-DB-UVN-2

Non-booted Display Dock

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 non-booted display dock for recharging one computer, connection with an external display, extending I/O for HDMI, Ethernet communications. Kit includes display base and power cord (-0 no power cord, -2 for Europe).

Battery Chargers



EDA52-QBC-0

EDA52-QBC-1

EDA52-QBC-2

EDA52-QBC-3

EDA52-QBC-5

Quad Battery Charger

Quad battery charger for ScanPal EDA52/52HC/ EDA56 Wi-Fi 6/EDA57 batteries. Kit contains power supply and power cord. (-0 no power cord,-1 for U.S., -2 for Europe, -3 for UK, and -5 for AU).

MOBILE

Mobile Accessories



EDA52-WS-10PK

Wrist Strap

Wrist strap for ScanPal EDA52/EDA52 HC/ EDA56 Wi-Fi 6/EDA57 (10pcs/kit).



EDA52-HS-10PK

Hand Strap

Hand strap for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6 (10pcs/kit).



3012-0760-001

Hand Strap


Hand strap for ScanPal EDA57 (1pcs/kit).



EDA52-SP-10PK

Screen Film

Screen film for ScanPal EDA52/EDA52 HC/ EDA56 Wi-Fi 6/EDA57 (10pcs/kit).



EDA52-RB-0

Rubber Boot


Rubber boot for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57.



EDA52-SH-R

Scan Handle

Scan handle for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57. Compatible with EDA52/EDA57 hand strap.



EDA52-ADC

Backwards Adapter Cup

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 backwards adapter to work with EDA50-HB-R accessories.



EDA52-SN-USB-0


USB Cup (6-pin models only)

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 snap-on USB cup for standard USB port.

EDA52-UCP-N

Universal Cup (6-pin models only)

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 Universal Cup to be worked with CT40 series universal docks.



IH25-BR-5

RFID Brackets

IH25 bracket for ScanPal EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57. Terminal without rubber boot



MBL-HDST-USBC

Mobility USBC Headset

Mobility headset with PTT, USB-C interface for CT30XP/EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57.

POWER SUPPLY

Battery



50172021-001

Standard Battery Pack

Standard battery pack for ScanPal EDA52/ EDA52 HC/EDA56 Wi-Fi 6/EDA57 (Li-ion, 3.8 V, 4500 mAh) (included with each terminal).



50183310-001

US Battery Pack

Battery pack for ScanPal EDA52 US (Li-ion, 3.8 V, 4500 mAh) (included in EDA52 US kit).

Power Adapter and Plugs



50136024-001

Power Adapter and Plugs

KIT, 5V/2A Power supply, Scanpal EDA50K/

EDA51/EDA52/EDA52 HC/EDA56 Wi-Fi 6/ EDA57/EDA60/EDA61K/EDA70/EDA71.

Mobility Edge CT40 / CT60. Includes 5 PLUGS PACKED US, UK, AU, EU, IN adapters.

SCANPALTM EDA52/ EDA52 HC/ EDA56 WI-FI 6/ EDA57 MOBILE COMPUTER

Accessories Guide (6PIN)

Honeywell

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA57 Mobile Computer (6PIN) Accessories Guide | sps.honeywell.com |

5For more information

sps.honeywell.com

Honeywell Safety and
Productivity Solutions

855 S Mint St

Charlotte, NC 28202

800-582-4263

www.honeywell.com

EDA52/EDA52 HC/EDA56 Wi-Fi 6/EDA (6PIN)

Accessories Guide LTR | Rev D | 12/22

© 2022 Honeywell International Inc.

Honeywell

Documents / Resources



[Honeywell EDA50-HB-R Single Charging Dock](#) [pdf] User Manual
EDA50-HB-R Single Charging Dock, EDA50-HB-R, Single Charging Dock, Charging Dock, Dock

References

- [H Safety and Productivity Solutions | Honeywell](#)
- [H Honeywell - The Future Is What We Make It](#)

[Manuals+](#).