

Honeywell HR91 Radiator Controller Installation Guide


Home » Honeywell » Honeywell HR91 Radiator Controller Installation Guide 🖺

Contents

- 1 Honeywell HR91 Radiator Controller
- **2 Product Usage Instructions**
- **3 Assembly Instruction**
- 4 Documents / Resources
 - **4.1 References**
- **5 Related Posts**



Honeywell HR91 Radiator Controller



Specifications:

· Model: evohome

Model Number: HR9 1

• Power Source: 2 x AA LR6 batteries

• Dimensions: M30 x 1.5mm

Product Usage Instructions

Setting Up a New Zone:

- 1. Press and hold the SETTINGS button for 3 seconds.
- 2. Press the green tick button.
- 3. Press ADD ZONE.
- 4. Type a name for the new zone and press the green tick button.

Configuring Radiator Valve:

- 1. Press RADIATOR VALVE.
- 2. If you want to control the zone temperature with the evohome Controller, press YES; otherwise, press NO.

Binding Process:

- 1. Press the binding button for 5 seconds.
- 2. The LED will flash AMBER for up to 2 minutes while binding.
- 3. Successful binding is confirmed by the LED showing permanent GREEN for 5 seconds.


Final Steps:


You should receive a SUCCESS message on the evohome Controller. Press the green tick to add another radiator to the zone or press the red cross if not needed. Repeat these steps for each radiator controller.


FAQ:


- Q: How do I know if the binding process was successful?
 - A: Successful binding is confirmed by the LED showing a permanent GREEN light for 5 seconds.
- Q: Do I need to repeat the binding process for each zone?
 - A: Yes, you must repeat the binding process for each radiator controller in every zone.


Assembly Instruction

















- 1. Press and hold SETTNGS for 3 seconds.
- 2. Press the green tick
- 3. Press ADD ZONE.
- 4. Type a name for the new zone and press the green tick
- 5. Press RADIATOR VALW
- 6. If you want to control the zone temperature with the evolome Controller (which needs to be located in that zone) press YES, otherwise press NO.



- 7. Press the binding button Of or5 secs.
- 8. The will flash AMBER for up to 2 mins whilet binding.
- 9. Successful binding is confirmed by led showing permanent GREEN for 5 secs.



- 10. You should receive a SUCCESS message on the evohome Controller(ifnot go back and re-bind).
- 11. Either press the green tick to add another radiator to the zone or press the red cross if you don 't need to add another irradiators the zone. You must repeat these steps for each radiator controller.



Manufactured for and on behalf of the Environmental & Energy Solutions Division of Ervionrtental & Enggy Sdut&s van

Resideo Technologies Sàrl, E&ES, Z.A., La Pièce 16, 1180 Rolle, Switzerland by its Authorised Representative Honeywell Home Inc. Conforms to protection requirements of the following directives: EMC: 2014/30/EU, LVD: 2014/35/EU, R.E.D.: 2014/53/EU Hereby, Honeywell Home declares that this HR91 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The full text of the EU Declaration of Conformity is available at the following Internet address: getconnected.honeywell.com

Receiver Category 2

WEEE Directive 2012/19/EU

At the end of the product life dispose of the packaging and product in a corresponding recycling centre. Do not dispose of the unit with the usual domestic refuse. Do not burn the product.



Ademco 1 GmbH Hardhofweg 40 74821 Mosbach

Phone: +49 1801 466 388 info.de@resideo.com homecomfort.resideo.com

@2020 Resideo Technologies, Inc.

All rights reserved The Honeywell Home trademark is used under license from Honeywell International Inc. This product is manufactured by Resideo Technologies, Inc and its affiliates.



Documents / Resources



<u>Honeywell HR91 Radiator Controller</u> [pdf] Installation Guide HR91, HR91 Radiator Controller, HR91, Radiator Controller, Controller

References

- Comfort Europe from Resideo
- Smart Home Products and Systems | Resideo
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.