



Home » Honeywell » Honeywell HWL-F2 Torchiere Standing Ambient Floor Lamp User Manual



Honeywell

Honeywell

TORCHIERE STANDING AMBIENT FLOOR LAMP

User Manual

Read and save these instructions before use

HWL-F2



Contents [hide]

- 1 THANK YOU
- **2 PRODUCT INTRODUCTION**
- 3 SAFETY WARNING
- **4 CLEANING AND MAINTENANCE**
- **5 TECHNICAL SPECIFICATIONS**
- **6 PACKAGE CONTENT**
- 7 PARTS DESCRIPTION
- 8 INSTALLATION STEPS
- 9 USE AND OPERATION
- 10 TROUBLESHOOTING
- 11 WARRANTY CARD
- 12 Documents / Resources
 - 12.1 References

THANK YOU

Thank you for choosing our lamp. Before using it, please take a moment to read this user manual carefully to understand its features and safety precautions.

PRODUCT INTRODUCTION

Torchiere Standing Ambient Floor Lamp

The Honeywell HWL-F2 Floor Lamp adopts 180 pieces of Sunturalux™ 2835 full spectrum LED lamp beads, providing a large-area diffuse reflection lighting effect that is closest to natural light. With a CRI292, they have no glare and flicker. In addition, this lamp is set up with multiple RGB colors and modes.

- Health-conscious and Eye-friendly Light Source: The lamp has undergone flicker, blue light hazard, and glare tests to meet or exceed standards, ensuring a strain-free visual experience.
- Multiple Color Temperature and Brightness Adjustments: Tailor your lighting with HWL-F2's expansive color temperature spectrum (2,700K-5,700K) and dimming options, creating the perfect atmosphere for work or relaxation.

- Multiple RGB scene light effects: the product is set with 6 different RGB light effect combinations, which can be adapted to a variety of ambient scenes.
- Adjustable shaft: The product is set with two shafts, adjusting the position of the lamp panel at multiple angles to meet various lighting needs.
- Built to Last: Crafted with premium metals like iron, the HWL-F2 promises enduring performance, boasting a lifespan exceeding 30,000 hours.
- Effortless Control:Seamlessly switch between touch and remote control for unparalleled convenience.

SAFETY WARNING

When using the lamp, please always follow these basic safety precautions:

- Ensure that the power voltage matches the rated voltage and frequency of the lamp.

 Mismatched voltage may cause damage to the components and result in malfunction.
- Ensure that the lamp is securely installed with fasteners on a flat, sturdy surface to prevent tipping, falling, product damage, personal injury, or property loss, and that installation is not performed while the power is on.
- Ensure that the power source has proper grounding protection. Incorrect power connections may lead to electric shock and pose serious risks.
- Please consult a qualified electrician for the inspection and repair of the lamp, as unauthorized repairs may pose serious safety risks.
- If any parts of the lamp are exposed, there is a risk of electric shock, which can be lifethreatening. Ensure that the lamp is fully assembled before connecting it to power.

WARNING: To prevent the occurrence of accidents that threaten personal safety such as lamp damage, falling, electrical shock, fire, and so on, please strictly follow the instructions for installation and use, do not modify the lamp's structure, and exchange parts or accessories,

CLEANING AND MAINTENANCE

We kindly ask you to clean and inspect the lamp regularly. Before performing any care
or maintenance, please ensure that the lamp is turned off and the power is
disconnected to prevent electric shock.

- When cleaning the lamp, please use a soft, lint-free cloth lightly dampened with a
 diluted neutral cleaner to wipe the lamp's body. We recommend avoiding alcohol or
 any chemical solvents, such as kerosene or stain removal oil, as these may damage
 the lamp's housing.
- Please refrain from using water or any other liquids to wash any parts of the lamp directly.

WARNING: For your safety, please always disconnect the power before cleaning and maintaining the lamp to prevent electric shock.

TECHNICAL SPECIFICATIONS

PARAMETERS	DETAILS	SPECIFICATIONS
General	Model Number	HWL-F2
	Material	ABS, Iron, PC
	Adapter Input	NA: 100-240 V-50/60 Hz
		EU: 220-240 V-50/60 Hz
		UK: 220-240 V-50/60 Hz
	Adapter Output	DC 24 V; 2 A
	Power	40 W
Light Source	LED	Sunturalue 2835 Full Spectrum
	LED Beads Quantity	180 pcs
	Luminous Flux(Max)	3,000 LM
	CCT	2,700 K – 5,700 K
	CRI (Ra)	92
	Lifespan	>30,000 hrs

	Net Weight	3.95 kg
Others	Voltage Standard	NA: 120 V-60 Hz
Others		EU: 220-230 V-50 Hz
		UK: 240 V-50 Hz


PACKAGE CONTENT

(The optional accessories in the package will have different configurations depending on the style chosen at the time of purchase.)




PARTS DESCRIPTION

(The product appearance diagram is for reference only, please refer to the actual product for detailed specifications.)



INSTALLATION STEPS

Installation of the Lamp




USE AND OPERATION

Angle Adjustment


This product supports multi-angle adjustment. When adjusting the angle, please do not insert your fingers into various connection points of the lamp to avoid injury to your fingers.

The adjustable angles are as shown in the diagram.




Recommended adjustable angle range (deviation±5%)

Lamp Pole Touch Control Panel



Remote control panel



(The effective control distance of the remote control is 10 meters.)

TROUBLESHOOTING

If the lamp is not functioning, please follow these troubleshooting steps:

- 1. Kindly check if the lamp is properly plugged in and ensure that the power cord is securely connected.
- 2. If the power is on, please inspect the control panel for any visible damage.
- 3. If you have completed these checks and the lamp still does not turn on, it is possible that the internal wiring may be damaged. In this case, we kindly ask you to contact our customer support team for assistance in resolving the issue.

Email: support@honeywellsmartlighting.com

WARRANTY CARD

Return and Exchange Policies

Huo Ming Technology Guangdong Co., Ltd. warrants that this product is free from defects in materials and workmanship for a period of 2 years. This warranty is valid only in the United States, Canada, Germany, France, Italy, Spain, and the United Kingdom.

This warranty applies only to products that are properly installed, maintained, and operated in accordance with the provided instructions. It does not cover failures or

operational difficulties caused by normal wear and tear, accidents, abuse, misuse, alterations, misapplications, improper installation, or inadequate maintenance.

Kind Reminder: If you encounter any issues with your order and contact us for assistance, please ensure you include your product order information and any relevant photos or videos (if necessary) to facilitate a quick resolution.

IMPORTANT: If you experience any product-related issues, please contact our customer support center first. We can help resolve your concerns before you decide to return the product. Do not attempt to disassemble the product or modify any original parts or accessories, as doing so may void your warranty and result in damage to the product or personal injury.

The Warranty Does Not Cover:

- 1. Damage resulting from abusive or unreasonable use, or additional damage.
- 2. Defects arising from normal wear and tear, which will not be considered manufacturing defects under this warranty.
- 3. Damage resulting from unauthorized repair attempts or use that does not comply with the instruction manual.
- 4. Damage incurred by failing to follow the instructions outlined in the "Safety Warning" and "Cleaning and Maintenance sections.

Return or Exchange Information

Please fill out the order, product, and user information below and include it in th
package for collection.

Product Name:——-	
Model Number:	
Date of Purchase:	
Purchased From:———	
Customer Name:———	
Phone Number:———	
Fmail:	

If you have any questions, please feel free to contact us.

Huo Ming Technology Guangdong Co., Ltd.

Address: Room 3501, Haijunda Plaza, Guizhou Avenue, Foshan, China

Contact Information:

Phone Numbers:

NA: +18005608962-Mon - Fri: 9:00 AM - 5:00 PM (EST)

EU: +864008787805-Mon - Fri: 9:00 AM - 5:00 PM (GMT+2)

UK: +864008787805-Mon – Fri: 9:00 AM – 5:00 PM (GMT)

Email: support@honeywellsmartlighting.com

Website: www.honeywellsmartlighting.com

Huo Ming Technology Guangdong Co., Ltd.

Room 3501, Haijunda Plaza, Guizhou

Avenue, Foshan, China

NA: +18005608962

EU: +864008787805

UK: +864008787805

support@honeywellsmartlighting.com

www.honeywellsmartlighting.com

The Honeywell Trademark is used under license from Honeywell International Inc.

Honeywell International Inc. makes no representations or warranties with respect to this product.

This product is manufactured by Huo Ming Technology Guangdong Co., Ltd.

MADE IN CHINA

Documents / Resources



<u>Honeywell HWL-F2 Torchiere Standing Ambient Floor Lamp</u> [pdf] User Manual

HWL-F2 Torchiere Standing Ambient Floor Lamp, HWL-F2, Torchiere Standing Ambient Floor Lamp, Standing Ambient Floor Lamp, Ambient Floor Lamp, Floor Lamp

References

User Manual

Ambient Floor Lamp, Floor Lamp, Honeywell, HWL-F2, HWL-F2 Torchiere Standing Ambient Floor Lamp, Standing Ambient Floor Lamp, Torchiere Standing Ambient Floor Lamp

—Previous Post

Honeywell ES800 7L Compact Air Cooler User Manual

Next Post—

Honeywell DLS4IM DALI Series Interface Module Instruction Manual

Leave a comment

Your email address will not be published. Required fields are marked*
Comment *
Name
Name
Email
Website
☐ Save my name, email, and website in this browser for the next time I comment.
Post Comment
Search:
e a whirlnool wrf535swhz

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of

these marks on this website does not imply any affiliation with or endorsement.					