Manuals+ — User Manuals Simplified.

Honeywell T6/T6R Smart Thermostat User Guide

Honeywell T6/T6R Smart Thermostat User Guide

Contents

Quick Guide

Online Guides

http://hwllhome.co/eut-T6

For help, contact:
WEB: **getconnected.honeywellhome.com**
PHONE: **0300 130 1299**
First step is to download the Honeywell Home-app from the App store or Google Play store:
Honeywell Home-app

With the Honeywell Home-app your thermostat will be connected with your own 2,4 GHz Wi-Fi network and registered to your account, after this you can control the thermostat remotely.

TIP: Make sure you have a 2.14GHz Wi-Fi network. The thermostat does not work on 5 GHz networks. When in doubt. check with your Internet provider or modem settings.

1. **Create account**

Create account with your email and activate from the email you receive back.

2. **Log on**

Log on and select the thermostat you have.

3. **Status thermostat**

Press "Yes' in the following screens.

4. Select

Select the thermostat (Name same as displayed on thermostat-screen)

5. Wi-Fi network

Select your Wi-Fi network and the 'Next'.

6. Wi-Fi connect

Thermostat Connects with your Wi-Fi network.

When successful press 'Done' thermostat shows 'Conected.

7. Conect

Press "Next"

8. Secure


Enter the Code displayed on Thermostat.

9. Configure

Select Language and clock setting…

10. Configured

… and the 'Next'

11. Complete config

Press 'Next'

12. Location

Choose a name for your location.

13. Name

← Thermostat Name

Name your thermostat

Select a name for your thermostat.

Honeywell Home

Honeywell Home Thermostat

My Honeywell Home

My Thermostat

Thermostat

Or enter a custom name

Custom

… Then a name for the thermostat.

14. Register


Finalising registration

Registering device

The Thermostat is now being registered to your account. This can take some minutes.

15. Registered

Thermostat is connected and registers, press 'Next'

16. Geofence

Geo fencing can be set or skipped.

17. Siri set up

Siri can be set up or skipped.

18. Completed

Registration is complete and choose 'Done'

ANDROID

1. **Create account**

Create account with your email and activate from the email you receive back

2. Log on

Log on and select the thermostat you have.

3. Thermostat

Press 'Yes' in the following screen.

4. Start Network

Press 'Next after pressing 5 sec on the thermostat.

5. Wi-Fi network

The Android-app goes to the Wi-Fi Setting, Choose 'Next'.

6. Select


Select the Thermostat (Name displayed on the thermostat-screen).

Press Dismiss and the back of Phone.

7. Connect

Press'Next'

8. Secure

Enter the code displayed on thermostat.

9. Configure

Select Language and clock setting…

10. Configured

  — and the 'Next'.

11. Compl. config.

  Press 'Next'.

12. Wi-Fi

Press 'OK' after reading the warning.

13. Select Wi-Fi

Select your Wi-Fi network and then 'Next'.

Enter your Wi-Fi password and then 'Next'.

14. Connecting

Thermostat makes connection with your Wi-Fi network and shows 'SUCCESS'

15. Location

Choose a name for your location.

16. Name

… Then a name for the Thermostat.

17. Select Wi-Fi

Select your Wi-Fi network and then 'Next'.

18. Register

The Thermostat is now being registed to your account this can take some minutes.

19. Geofence

Geofencing can be set or skipped.

20. Completed

Registration is Complete and choose 'Done'.

Wi-Fi is a registered trademark of Wi-Fi Alliance.

T6-T6R-REG-ENOH 8620 NL01 1019

2019 Resideo Technologies, Inc

www.resideo.com
This product is manufactured by Resideo and its affiliates. The Honeywell Home Trademark is used under license from Honeywell international Inc. All rights reserved.

Documents / Resources

Honeywell T6/T6R Smart Thermostat [pdf] User Guide

T6, T6R, Smart Thermostat, Thermostat