



Honeywell WDR 2 MP/5 MP IR Bullet Camera Installation Guide

[Home](#) » [Honeywell](#) » Honeywell WDR 2 MP/5 MP IR Bullet Camera Installation Guide 

Honeywell WDR 2 MP/5 MP IR Bullet Camera Installation Guide



Honeywell

Contents

- [1 What is in the Box](#)
- [2 Tools Needed](#)
- [3 Insert Micro SD](#)
- [4 Installation Instructions](#)
- [5 Logging On to the Camera](#)
- [6 Support Brackets](#)
- [7 Cautions and Warnings](#)
- [8 Important Safeguards](#)
- [9 Regulatory Statements](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)


What is in the Box



Tools Needed




Insert Micro SD




Installation Instructions


1



2




3




4


(Optional)




5



OR



6



Logging On to the Camera

If logging on the camera remotely from a PC, install the Honeywell Config Tool from the software and documentation CD, find the camera on the network, and then open the web browser with the Honeywell Config Tool. The default user name is **admin** (case-sensitive) and the default password is **1234**.

Note:

- Internet Explorer 11 (or later) with ActiveX plug-in is supported.
- Chrome 71 (or later) is supported for H.264 video. Chrome is not supported for H.265 video.
- IP address of the device is assigned automatically by DHCP server. If the DHCP server is not available, the device will acquire 192.168.1.108 as the default IP address.

Support Brackets

| | |
|----------------------|--------------|
| HBS2-BB | Junction Box |
| HQA-PM2 with HBS2-BB | Pole Mount |



Cautions and Warnings



Caution:

- Risk of Electric Shock
- Do not open



THIS SYMBOL INDICATES THAT DANGEROUS VOLTAGE CONSTITUTING A RISK OF ELECTRIC SHOCK IS PRESENT WITHIN THE UNIT.

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



THIS SYMBOL INDICATES THAT IMPORTANT OPERATING AND MAINTENANCE INSTRUCTIONS ACCOMPANY THIS UNIT.

Warning: To ensure compliance with electrical safety standards, CSA Certified/UL Listed LPS or Class 2 power adapters are required. Power over Ethernet (PoE) shall be provided by listed Information Technology Equipment meeting the IEEE 802.3af PoE standard. The PoE is not intended to be connected to exposed (outside plant) networks.

Important Safeguards

- Read and keep these instructions.
- Please ensure that your installation area can safely support the weight of the camera.
- Do not aim the camera toward a bright light source for extended periods to prevent damage to the imager.
Avoid operating the unit under or close to unstable light sources (may cause flickering), or close to fluorescent lamps or objects reflecting light.
- Do not touch the camera lens.
- Do not drop the camera or subject it to physical shock.
- Do not use a strong or abrasive detergent when cleaning the camera.
- Avoid operating or storing the unit in extremely humid, dusty, hot/cold environments, where the operating temperature is outside the recommended range of -22°F to 140°F (-30°C to 60°C).
- Avoid operating the unit close to sources of powerful electromagnetic radiation, such as radio or TV transmitters.
- If powered by a power adapter, the adapter should be properly grounded. Consult Honeywell for the recommended adapter or check it in Honeywell DOC.

Regulatory Statements

FCC Statement of Compliance

Information to the User: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

<http://www.honeywell.com/security>

+1 800 323 4576 (North America only)


Document 800-25041 – Rev B – 05/2019

© 2019 Honeywell International Inc. All rights reserved. No part of this publication may be reproduced by any means without written permission from Honeywell. The information in this publication is believed to be accurate in all respects. However, Honeywell cannot assume responsibility for any consequences resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this

publication may be issued to incorporate such changes. For patent information, see www.honeywell.com/patent.



Documents / Resources

| | |
|---|---|
|  | <p>Honeywell WDR 2 MP/5 MP IR Bullet Camera [pdf] Installation Guide Honeywell, HC30WB2R1, HC30WB5R1, WDR 2 MP IR Bullet Camera, 5 MP IR Bullet Camera, Bullet Camera</p> |
|---|---|

References

- [H Commercial Buildings and Modern Cities | Honeywell](#)