

HOVER-1 MAVERICK Hoverbaord User Guide

Home » HOVER-1 » HOVER-1 MAVERICK Hoverbaord User Guide

Contents

- 1 HOVER-1 MAVERICK Hoverboard
- 2 BEFORE FIRST USE, PLEASE FULLY CHARGE YOUR HOVER-1 **MAVERICK**
- **3 CALIBRATING YOUR HOVER-1 MAVERICK**
- 4 Documents / Resources
 - 4.1 References
- **5 Related Posts**



HOVER-1 MAVERICK Hoverboard




IMPORTANT

Retain this card, a copy of your receipt, and your 13-digit serial number for your records


BEFORE FIRST USE, PLEASE FULLY CHARGE YOUR HOVER-1 MAVERICK

• The Maverick is fully charged when the light on the charger itself, turns from red to green as shown below.




LOCATING YOUR HOVER-1 MAVERICK SERIAL NUMBER

• There are two (2) stickers with a corresponding serial number for your Maverick affixed on the bottom of the unit as shown below. Carefully remove one (1) serial number sticker and affix it onto the designated place on page 21 in the manual of your Maverick.



CALIBRATING YOUR HOVER-1 MAVERICK

If your Maverick is vibrating, spinning, uneven, leaning or unbalanced, a quick calibration is necessary.



- First, place the Maverick on a flat, horizontal surface, such as the floor or a table, making sure it is powered off and not plugged into the charger.
- Press and hold the power button for 10-15 seconds as shown to the right.
- When your Maverick starts beeping, you may release the power button.
- To complete calibration, power off your Maverick and then back on. The beeping will stop and the board is now calibrated. It's a good idea to recalibrate your Maverick after every few rides, to keep it running smoothly.

Documents / Resources

References

• © Hover-1™ Rideables™ – Hover-1 Rideables

Manuals+,