hp jump 2 Group Mouse

hp jump 2 Group Mouse User Manual

Contents

hp jump 2 Group Mouse

Specifications

- **Color Side** 1: BLACK
- **Color Side 2**: BLACK
- **Flat size:** 7 x 16.25 in. (177.8 x 412.75 mm)
- **Finished size:** 3.5 x 3.25 in (88.9 x 82.55 mm)
- **Fold 1**: In-half
- **Fold 2:** 5-panel accordion

Product Usage Instructions

Programming Keyboard Keys:
To program the keyboard keys, follow these steps:

1. Use the software provided.
2. If the software doesn't download automatically, open Microsoft Store.
3. Search for HP Accessory Center and download the app.

Components Description

- **Programmable keys:** To change default functions, use HP Accessory Center.
- **Power light:** Solid white (5 s): Keyboard is on. Slowly blinking amber: Batteries are low.
- **Receiver light:** Two white blinks and pauses (180 s): Receiver channel selected but not connected to a computer.
- **Bluetooth buttons and lights:** Press button for 2 s to enter pairing mode. Solid white (5 s): Connected to paired computer.

NOTE: To extend battery life, turn off the keyboard and numpad when not in use.

BATTERY

|	
:¦:	1000 DPI
:¦::¦:	1200 DPI
:¦::¦::¦:	1600 DPI

3S

**POWER**

2

USB

CONNECTION

3

OR

3S

- **Color Side 1:** BLACK
- **Color Side 2:** BLACK
- **Flat size:** 8.27 x 11.652 in. (210.058 x 295.96 mm)
- **Finished size:** 4.134 x 2.913 in. (A7) (105 x 73.9902 mm)

Fold 1:
4-panel
accordion

Fold 2:
In Half

SCANNER

For regulatory, certification, and environmental information, including Restriction of Hazardous Substances (RoHS), scan the QR code, or go to **www.hp.com/go/regulatory**.
© Copyright 2022 HP Development Company, L.P.

- The Bluetooth trademark is owned by its proprietor and used by HP Inc. under license.
- The information contained herein is subject to change without notice. The only warranties for
- HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty.
- HP shall not be liable for technical or editorial errors or omissions contained herein.

  First Edition: December 2022

Printed in China

FAQ

- **Q: How to pair the keyboard via Bluetooth?**
  - A: Press the Bluetooth button for 2 seconds to enter pairing mode, then enter the 6-digit PIN displayed on the computer to pair.
- **Q: What does a slowly blinking amber power light indicate?**
  - A: A slowly blinking amber light indicates low battery level; replace the batteries.

Documents / Resources

hp jump 2 Group Mouse [pdf] User Manual
TPAD004K, O62-TPAD004K, O62TPAD004K, jump 2 Group Mouse, jump 2 Group, jump 2 Mouse, jump 2, Mouse

References

- **User Manual**