




HUANUO Monitor Table Stand Instruction Manual

[Home](#) » [HUANUO](#) » HUANUO Monitor Table Stand Instruction Manual

HUANUO

Monitor Table Stand
Instruction Manual



Model: HNHM5



<https://www.huanuoav.com/>

Thank you for choosing this HUANUO product! At HUANUO we strive to provide you with the best quality products and services in the industry. Please share your experience of our product with others at www.huanuoav.com/reviews if you are satisfied. Should you have any issues, please don't hesitate to contact us.

Technical Support: 1-800-556-0533 Mon-Fri 10am – 5pm (PST) (USA) (CAN)

Other Info: support@huanuoav.com (US/CA)

Contents [[hide](#)

[1 UNPACKING INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION](#)

[2 Supplied Parts and Hardware](#)

[3 Features](#)

[4 Documents / Resources](#)

[4.1 References](#)

[5 Related Posts](#)

UNPACKING INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION

- Carefully open the carton, remove contents and layout on cardboard or another protective surface to avoid damage.
- Check package contents against the Supplied Parts and Hardware Lists to assure that all components were received undamaged. Do not use damaged or defective parts.
- Not all parts and hardware included will be used. If you require replacement parts, contact customer service at support@huanuoav.com
- Carefully read all instructions before attempting installation.
- If you do not understand the instructions or have any concerns or questions, please contact customer service at support@huanuoav.com
- This product may contain moving parts. Use with caution.
- Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaim any liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


Supplied Parts and Hardware



01 X1




02 X1



03 X1



04 X1



05 X2



06 X2



07 X2



08 X1



09 X1



M8x10mm

A x2



M5x16mm

B x3



C x2



1/8 in.(3mm)

D x1




15/64 in.(6mm)

E x1



M4x12mm
M- A X8



M4X30mm
M- B X8




D4
M-C X8




M- D X8

Step 1 Connect Upper Pole to Lower Pole


STEP 1-1 Loosen the screw [S] on pole [02] using Allen key [E]



STEP 1-2 Connect pole [01] to pole [02]




STEP 1-3 Tighten the screw [S] using Allen key [E] to fix the two poles



Step 2A For C Clamp Mounting


STEP 2A-1 Install part [03] to pole[02]



STEP 2A-2 Adjust the mount according to the thickness of desktop


STEP 2A-3 Install part [04] to part [03]

STEP 2A-4 Secure the mount to the desktop




Step 2B For Grommet Mounting

STEP 2B-1 Install part [08] to pole [02]




STEP 2B-2 Remove part [a] from part [04]

STEP 2B-3 Secure the mount to the desktop




Step 3 Install Cable Clip & Monitor Connector to the Pole Assembly


STEP 3-1 Slide the cable clip [07] and monitor connector [05] in sequence to the pole assembly as shown below



STEP 3-2 Secure the monitor connectors [05] to the pole assembly





Step 4 Check Monitor Hole Pattern and Select TV Monitor Bolts



75 mm \approx 4 in.
100 mm \approx 7 7/8 in.

Only one bolt size fits your monitor.




Bolt length: Verify adequate thread engagement with bolts or bolts/spacers combination. We recommend thread engagement by at least 5 turns.


- Too short will not hold the monitor.
- Too long will damage the monitor.




Step 5 Attach the Monitor Brackets to the Monitors




Step 6 Hang Monitors to the Stand and Secure with Nuts [C]




Step 7 Fix Tilt Angle of the Monitors




Step 8 Manage Cables




Step 9 Store Allen Keys into the Cable Clip





Warning: To avoid tipping, please be careful not to extend the monitor too far backward. When you adjust the angle of the monitor, please make sure the monitor is balanced to avoid instability of the center of gravity of the base.

Features



Documents / Resources

	<p>HUANUO Monitor Table Stand [pdf] Instruction Manual Monitor Table Stand, HNHM5</p>
--	---

References

- [A Huanuo shop](#)