



Huawei WS331c User Manual, Login Instructions Default Password

[Home](#) » [Huawei](#) » Huawei WS331c User Manual, Login Instructions Default Password 

Step 1: Plug the WS331c into a power socket near the wireless router



Step 2: Wirelessly connecting WS331c to the wireless router

Method 1: Automatic Connection through WPS Button



Method 2: Manual Connection through the WS331c Web Page

1. Check the WS331c's Wi-Fi network name (unencrypted by default), and then wirelessly connect your phone to the Wi-Fi network.
2. On your phone, open a browser and enter 192.168.3.1 or mediarouter.home to access the WS331a configuration screen. Then enter the **login password (default value: admin)**.
3. Touch Internet Connection Wizard. Complete the configuration by following the Internet Connection Wizard.



