

**Huizhizhen
JMK-D01
Multi
Functional
Speaker**



Huizhizhen JMK-D01 Multi Functional Speaker Instruction Manual

[Home](#) » [Huizhizhen](#) » Huizhizhen JMK-D01 Multi Functional Speaker Instruction Manual 

Contents

- [1 Huizhizhen JMK-D01 Multi Functional Speaker](#)
- [2 Product Features](#)
- [3 Specifications](#)
- [4 Accessories List](#)
- [5 Product Description](#)
- [6 Operating Instructions](#)
- [7 FCC STATEMENT](#)
- [8 Warranty card](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)

Huizhizhen

Huizhizhen JMK-D01 Multi Functional Speaker



Thank you for buying and using this product!

In order to bring you a better user experience, please read this user manual carefully before using the product. Please keep it safe for future reference. Thank you.

Product Features

- This product is a retro multifunctional audio system that integrates aroma-therapy, wireless charging, a clock, a perpetual calendar, ambient lighting, a phone holder, and other functions, simplifying complexity and making the product more practical;
- Retro and modern are like two rivers of time, intertwined and converging in our product design, forming a unique melody:
- Retro is an ancient poem softly recited by time, flowing with the depth and weight of history. It is like a yellowed scroll, gently unfolded, revealing the charm of the past, enchanting people.
- Modernization is a new chapter in the era's singing, playing with the passion and vitality of innovation. It is like a dazzling neon light, dazzling and leading the direction of the trend, making people yearn for it.
- Every detail design contains both classical charm and modern inspiration. It seems that ancient and modern people are intersecting at this moment, telling the story of time together. Welcome to my world, let's explore this wonderful time together!

Specifications

- **Product Name:** Fragrance diffuserStereo Audio speaker
- **Product Material:** ABS+ PC
- **Product packaging:** 150mm*60mm*175mm
- **Style/Color:** Wood grain +Black
- **Wireless charging rated voltage:** 9V
- **Speaker power:** 5W
- **Rated power of night light:** 4.6W
- **Lamp lumen value:** 55-60LM
- **TX to RX sensing distance:** 6mm
- **Product model:** D01






- **Product size:** 216mm*176mm*49mm
- **Individual weight/net weight:** 650g
- **Power interface:** DC12V 2A
- **Wireless charging output power:** 15W
- **Atmosphere lamp charging voltage:** 3.3V
- **Lamp color temperature:** 3000-3200K
- **Color rendering index:** 70
- **Aromatherapy type:** Solid Aromatherapy Tablets

Accessories List

- Host 1
- Instruction manual 1
- Aromatherapy sheet 1
- Adapter 1
- Cover clip 1



Product Description



1. Audio switch (off state)
2. Pause button, music pause, clock adjustment
3. Light button, ambient light adjustment
4. Alarm button, alarm adjustment
5. Audio switch (open state)
6. "+" key: Volume+/Previous track/Tme+
7. "-" key. volume -/next track/time-
8. Aromatherapy cover
9. Wireless charging area
10. Digital screen display
11. Aromatherapy sheet
12. Groove can be used as a phone holder
13. Logo area
14. USB output port
15. DC interface

16. Bottom ambient light

Operating Instructions

Key definition:

1. **Toggle switch:** audio switch
2. **Pause button:** Music pause, clock adjustment
3. **Light button:** Atmosphere light adjustment
4. **Alarm key:** Alarm adjustment
5. **“+” key:** Volume +/Previous track/Time+
6. **“-” key:** volume -/next track/time-



Power indicator light:

Digital screen icon display

Important Instructions

Connect DC power supply

Clock, alarm clock, date, temperature, ambient light, wireless charging, USB output port start, disconnect power, turn off all functions;

1. Flip the switch: Turn left 30 degrees to turn on the Bluetooth speaker, Bluetooth waits for pairing, and after a successful Bluetooth connection, the time and period will automatically update. Turn right 30 degrees to turn off the speaker;
2. Pause button: Click on the music play/pause button, press and hold to switch to manual adjustment mode for time and date;
3. Light button: The default brightness of the light is 20%. Click once to switch the light brightness to 50%. Click again to switch the light brightness to 100%. Click again to turn off the light;
4. Alarm button: Click to enter Alarm 1 adjustment mode, long press to enter Alarm 2 adjustment mode;
5. ***+* key:** Click/Long press on previous track/Volume +Manual clock adjustment mode/Time+ Time +Alarm mode/Time + Alarm adjustment Alarm switch adjustment;
6. **“-* key:** click/long press next track/volume down in manual clock adjustment mode/time up, date up in alarm mode/time down in alarm adjustment alarm switch adjustment;
7. Screen display: week, time, date, temperature, Bluetooth connection status icon, aromatherapy machine status icon, ambient light status icon, and wireless charging status icon;

8. Groove: can hold a phone as a stand for use;
9. USB output port: The output current is 5v2a, which can supply power to external devices;

FCC STATEMENT

Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with a minimum distance between 20cm of the radiator and your body: Use only the supplied antenna.

Warranty card

Please keep this card properly. The company will take this card as the warranty certificate Thank you for purchasing this product. The warranty period of this product is 12 months from the date of purchase. Please keep it properly and fill in detailed relevant information for warranty use.

Product model:

Date of purchase:

Dealer name:

User name:

Contact number:

Address:

Explain the reason: ☐ Return goods ☐ Exchange goods ☐ Guarantee

Warranty conditions

- When warranty service is required, please show this card and fill in the relevant contents in detail.
- The company provides users with a 1 2-month warranty period from the date of purchase.

Warranty scope


The quality problem that appears under the normal use condition, is not the damage caused by external force damage, the product warranty period, because can not use the inconvenience or damage caused by the product, the company assumes any responsibility, principle. The product belongs to the warranty period users do not have to pay the cost, but in the case of human damage is necessary to charge testing or spare parts costs, for products beyond the warranty period of a-law charges.

Warranty is not available under the following circumstances

Manpower damage: for example, due to improper use, improper damage, abnormal wear and tear of appearance, falling damage, circuit destruction, extrusion deformation, entry of foreign matters, moisture, alteration or tearing of sealing labels on products, and any other visible man-made damage, and other conditions, such as the user's reasons (unauthorized disassembly and modification, unafraid use, improper operation, water ingress, etc.) Damage caused by force majeure, such as earthquake, flood, fire, typhoon, or war.

MADE IN P.R.C.

Documents / Resources

	Huizhizhen JMK-D01 Multi Functional Speaker [pdf] Instruction Manual JMK-D01, JMK-D01 Multi Functional Speaker, Multi Functional Speaker, Functional Speaker, Speaker
---	--

References

- [User Manual](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.