



[Home](#) » [Humane](#) » **Humane B1 Bark Collar with Smartphone App Instruction Manual** 

Contents [[hide](#)]

- [1 Humane B1 Bark Collar with Smartphone App](#)
- [2 Product Usage Instructions](#)
- [3 USING INSTRUCTION](#)
- [4 Important Safety and Product Information](#)
- [5 FAQ](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Humane B1 Bark Collar with Smartphone App



Product Specifications:

- **Product:** Battery Booster
- **Material:** Hyacinth (Books & Albums) White, 80G
- **Printing:** 2-sided, 5 Colors Offset
- **Finish:** Do not apply aqueous coating
- **Dimensions:** 50.8 mm x 50.8 mm

Product Usage Instructions

Charging Ai Pin with Battery Booster:

The Battery Booster wirelessly charges the onboard Ai Pin battery to increase usage time. It also acts as a magnetic clasp to attach Ai Pin to clothing.

- For thicker clothing, use the Clip.
- For lighter clothing, use the Latch.

You can charge both the Battery Booster and Ai Pin simultaneously by attaching the Battery Booster to Ai Pin. To charge the Battery Booster, place it on the Charge Pad connected to the provided Adapter and Cable.

Removing Battery Booster from Ai Pin:

To remove the Battery Booster, slide it using a top-to-bottom motion on Ai Pin.

Safety Information:

Read all safety instructions before using the Battery Booster to prevent fire, electric shock hazards, or damage. Keep away from liquid sources and extreme temperatures. Properly dispose of the product when necessary.

Additional Resources:


For more information on using and caring for the Battery Booster, refer to the online documentation at hu.ma.ne/support.

USING INSTRUCTION

1. The Battery Booster wirelessly charges the onboard Ai Pin battery to increase the amount of time you can use Ai Pin. The Battery Booster also acts as a magnetic clasp to attach Ai Pin to your clothing. For thicker clothing, you can use the Clip. For lighter clothing, you can use the Latch.



2. You can also charge the Battery Booster and Ai Pin at the same time by first attaching the Battery Booster to Ai Pin.



3. When it's time to charge the Battery Booster, place it on the Charge Pad. Make sure the Charge Pad is connected to the Humane-provided Adapter and Cable.



4. To remove the Battery Booster from Ai Pin, slide it using a top-to-bottom motion.

Green: Charge > 80% (Ready to use.)



Amber: Charge < 80%



Important Safety and Product Information

HEALTH and SAFETY WARNINGS:

Failure to follow these safety instructions may create fire, electric shock hazards, and result in serious injury or damage to the Battery Booster or other property.

To reduce the risk of personal injury, discomfort, or property damage, please read all the safety information below before using the Battery Booster.

WARNING: Liquid Exposure

Keep the Battery Booster away from all sources of liquid such as sinks, bathtubs, shower stalls, drinks, oils, and lotions. Protect the Battery Booster from humidity, dampness, and wet weather such as rain, snow, and fog.

WARNING: Electrical Safety

Failure to take the following precautions can result in serious injury or death from electric shock, fire, or damage to the Battery Booster. Handle with care.

Do not store the Battery Booster in very hot or very cold locations.

Do not use the Battery Booster if it is hot to the touch or appears damaged in any way.

Immediately stop using the Battery Booster if you notice a battery fluid leak. Battery fluid is corrosive, and may be toxic if it is swallowed or makes contact with the skin or eyes. If battery fluid contacts the skin, flush skin with water immediately.

Do not attempt to replace the battery, open the enclosure, disassemble, or otherwise try to service the Battery Booster other than performing basic maintenance described in the Humane user manual.

Doing so will void the warranty, may damage the Battery Booster, and can result in fire, burn, and electric shock hazards.

Charge the Battery Booster in accordance with the instructions provided during setup. Only use an authorized Humane power adapter (Adapter) and cable.

Do not charge the Battery Booster if it is wet.

Using damaged cables or chargers, or charging when moisture is present, can cause fire, burn, electric shock, injury, or damage to the Battery Booster or other property.

Substances in the Battery Booster may harm the environment or cause injury if handled and disposed of improperly. For proper disposal instructions, visit hu.ma.ne/support/recycling.

Use and Care

For more information on the use and care of the Battery Booster, visit hu.ma.ne/support.

Regulatory Compliance Information**FCC and ISED Canada Compliance**

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

For more information regarding FCC Compliance and ISED Canada Compliance, visit hu.ma.ne/legal.

■ Custom Black	■ PMS Cool Grey 5 U	■ Change Notes from PVT (Do not Print)
■ Custom Green	■ PMS 1575 U	■ PMS 649 U

FAQ


Q: Can I charge the Battery Booster and Ai Pin simultaneously?

A: Yes, you can charge both devices at the same time by attaching the Battery Booster to Ai Pin.

Q: How do I remove the Battery Booster from Ai Pin?

A: Slide the Battery Booster in a top-to-bottom motion to detach it from Ai Pin.

Documents / Resources

	Humane B1 Bark Collar with Smartphone App [pdf] Instruction Manual HU223, 2BAFM-HU223, 2BAFMHU223, B1 Bark Collar with Smartphone App, B1, Bark Collar with Smartphone App, Smartphone App
---	---

References

- [User Manual](#)

■ Humane

■ 2BAFM-HU223, 2BAFMHU223, B1, B1 Bark Collar with Smartphone App, Bark Collar with Smartphone App, HU223, Humane, Smartphone APP

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.