



HVMLAK AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver Instructions

[Home](#) » [HVMLAK](#) » HVMLAK AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver Instructions 

Contents


- [1 HVMLAK AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver](#)
- [2 WIRELESS ADAPTER](#)
- [3 Parameter Table](#)
- [4 Basic Control](#)
- [5 Music handling in RX Mode](#)
- [6 LED Indicators](#)
- [7 Use as a Transmitter](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



HVMLAK AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver



WIRELESS ADAPTER



1. Rotatable 3.5mm Jack
2. Led Indicator
3. MFB Button
4. Vol-/Pro Tracie (RX mode)
5. Vol+/Nex Track {RX mode}
6. USB-C Charging Port

Parameter Table

Item Name	Bluetooth Transceiver
Bluetooth Chip	CSR8670
Bluetooth Version	BT5.2
Audio Codecs(RX Mode)	aptX LL, aptX, AAC, SBC (RX Mode)
Audio Codecs(TX Mode)	aptX LL, aptX, SBC (TX Mode)
Effective Range	Up to 20m (open Area)
Battery Capacity	180mAh
Battery Life	TX Mode-13 hours /RX Mode- 11 hours
Charging Time	2.5 Hours
Charging Voltage	DC 5V/1A
Dimension	67*21*11mm
Unit Weight	15.3g

Basic Control

Function	Operation
Power on	Press and hold the MFB ③ for 3 seconds
Power off	Press and hold the MFB ③ for 5 seconds
Enter Pairing	Automatically or Press MFB ③ for 3 seconds
Mode Switching	Press ④ and ⑤ for 3 seconds to change mode (TX/RX)
Restore Factory Defaults	Press ③ and ④ for 3 seconds to reset
Mute Sound	Short press the MFB ③ in TX mode

Music handling in RX Mode

Function	Operation
Play/pause	Short press ③ to play/pause music
Previous Track	Press ④ for 2s
Next Track	Press ⑤ for 2s
Volume -	Short press ④
Volume +	Short press ⑤

LED Indicators

LED	Status
Solid Red	Charging
Solid White	Fully Charged
Fast Flash White	Pairing in TX Mode
Fast Flash Blue	Pairing in RX Mode
Flash every 5s	Playing
Flash White and Blue	Connect with 2 Bluetooth headphones.
Flash Red	Low battery indication

Definition:

TX Mode: Transmitter which can be paired with Bluetooth headphones.

RX Mode: Receiver which can be paired with Smartphones.

Use as a Transmitter

(TX Mode):


Step 1.



- Turn on AIR99
- Make sure that it is in TX mode it will automatically enter pairing mode (fast flash white LED)
- Press the MFB Button for 3s to enter pairing mode again to pair with your 2nd Bluetooth headphone or AirPods if you


want to.

Step 2



- Make your airpod in pairing mode to connect with AIR99.
- Sometimes you need to make airpod into pairing mode first and then make AIR99 in pairing mode.

Step 3.



- Plug AIR99 into the Aux audio output port to stream music to your AirPods or other Bluetooth headphones.
- This usage scenario can be Airplane / TV / PC / Switch / iPod etc

Use as a Receiver (RX Mode)

Step 1.



- Turn on AIR99.
- Make sure that it is in RX mode.
- It will automatically enter pairing mode(fast flash Blue LED).
- press the MFB Button for 3s to enter pairing mode again to pair with your 2nd smartphone if you want to.

Step 2.



- Enable the Bluetooth on your cell phone and search.

- Tap “HVMLAK AIR99” to connect with AIR99.

step 3.




- Plug AIR99 into the Aux audio input port to stream music from your phone to the car stereo or other home stereo.
- This usage scenario can be Car / Speaker / Boat / Motorcycle etc.



We apologize for any inconvenience caused by minor inconsistencies in these Instructions, which may occur as a result of product improvement and development.

Documents / Resources

	<p>HVMLAK AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver [pdf] Instructions AIR99 2 in 1 Bluetooth Audio Transmitter and Receiver, AIR99, 2 in 1 Bluetooth Audio Transmitter and Receiver, Audio Transmitter and Receiver, Transmitter and Receiver, Receiver</p>
---	--

References

- [User Manual](#)