



# HWWR-T10-T Portable Bluetooth Speaker User Manual

[Home](#) » [HWWR](#) » HWWR-T10-T Portable Bluetooth Speaker User Manual 

## Contents


- [1 HWWR-T10-T Portable Bluetooth Speaker](#)
- [2 Product keys, jack function introduction](#)
- [3 Remote Control](#)
- [4 Charging Instructions](#)
- [5 Simple Troubleshooting](#)
- [6 Product Specifications](#)
- [7 Packing list](#)
- [8 Documents / Resources](#)



**HWWR-T10-T Portable Bluetooth Speaker**








## Product keys, jack function introduction




1. [MIC ]: Microphone.
2. [REC]: In the USB/TF card state to insert the microphone or open the wireless microphone, short press to record. The screen shows REC, press again to play the recording, long presses to delete the recording during playback, The screen will show dEL.
3. [EQ ]: Short press two sound effects, EQ0 (Default outdoor sound effect for power on); EQ1 (indoor sound effect).
4. [ M]: Short press to switch between Bluetooth, USB, TF card, and FM radio, long press to hold to automatically

search the station in the FM mode.(Long press the M key to enter the TWS connection function in Bluetooth mode)

5. [  ]: Short press to switch the lighting effect. In the FM radio state, just only one light effect.
6. [VOLUME]: Rotate left to reduce the volume, and rotate right to increase the volume.
7. [ON/OFF]: Power ON/OFF
8. [  ]: Loop: Press to switch between single cycle and all cycle
9. [  ]: Short press last song/select last radio station, long press fastback
10. [  ]: Short press next song/select next radio station, long press fast forward
11. [  ]: Short press to play/pause, long press to search stations automatically when in FM mode. In Bluetooth mode state, Press play to directly disconnect the Bluetooth connection.
12. [USB]: Insert the USB to play music. (The max capacity of USB is 64GB, if more than 64GB can not be read)
13. [TF]: insert TF card to play music. (The max capacity of a TF card is 64GB, if more than 64GB cannot be read)
14. [AUX]: AUX IN Jack
15. [DC 5V]: 5V Charging Port
16. [CHARGING INDICATOR]: The red light is on when charging, green light is on after full.

## Remote Control



## Bluetooth Connection instructions

Boot into Bluetooth mode, open your phone Bluetooth to search for speaker name or digital codes for pairing, If need a pairing password, please enter "0000" and click OK to connect.

## TWS Connection instructions

1. Turn on two identical Bluetooth speakers, and both two are in Bluetooth mode, For any one of the speakers to set, long press the M key to pair and connect with the other speaker to use TWS function. Long press the M key will disconnect the TWS function.

2. The best connection distance for two Bluetooth speakers is about 5 meters.

## **Charging Instructions**

Connect the charging cable to the 5V 2A charger and plug it into the charging port after the machine is turned off; the red light is on when charging, and the green light is on when it is full.

### **NOTE:**

1. The lithium battery of this product is replaceable and can only be replaced with the same battery or equivalent.  
There is a risk of explosion if the battery is not replaced properly
2. The battery should not be exposed to such as sunlight, fire, or a similar overheating environment to avoid causing an explosion.

## **Simple Troubleshooting**

1. Q: Automatically shut down when you turn on the speaker  
A: The battery is low, please use it after a full charge.
2. Q: Automatic shutdown or restart during playback  
A: Battery power is insufficient, please use after full charge.
3. Q: The charging light does not light up, not charging  
A: Check whether the charging cable is well plugged in or damaged, and if the charger is well, please use a 5V 2A charger to charge the speaker.
4. Q: Bluetooth status no sound  
A: Check whether the Bluetooth is correctly paired, and whether the volume cannot be the minimum volume when playing.
5. Q: TF card/USB playback no sound  
A: Check whether the TF card is in place, the USB is inserted in place or has good contact, and whether the TF card or USB music format is correct (Note: TF card /USB music supports MP3 compressed audio files and WMA lossless audio file playback); and the volume cannot be the minimum volume when playing.
6. Q: REC does not work  
A: Is there space on the TF card or USB, delete part of the file to reserve storage space. Recording should be done in TF card /USB mode and with a wired microphone inserted or wireless microphone turned on.
7. Q: Recording can not be deleted  
A: Please press and hold the record key or connect to a computer to delete while playing the recording file.
8. Q: Recording sound is small or there is noise  
A: Please insert the wired microphone or turn on the wireless microphone when recording.

## **The remote control diagram and operating instructions**

1. In normal circumstances, the remote control should be used within a reception range of about 6 meters and 30 degrees in front of the reception window of the machine.
2. When operating the remote control, please point the remote control at the receiving window of the machine.  
There should be no obstacle between the remote control and the machine.
3. If the receiving window of the machine is placed under direct light, the operation panel of the remote control

used in this case may not work, in this case, please move the machine away to avoid direct light.

4. When the battery of the remote control is dead, you can replace the AAA battery. Avoid mixing old and new batteries, please check regularly if the remote control battery needs to be replaced.


Product Specifications

- Output power 2x30W
- Frequency effect 80Hz-12KHz
- Input power 5V 2A
- Bluetooth version 5.0
- Signal-to-noise ratio? B0dB

Packing list

- |                         |      |
|-------------------------|------|
| 1. Speaker .....        | 1 pc |
| 2. Instructions.....    | 1 pc |
| 3. Charging cable ..... | 1 pc |
| 4. Remote control. .... | 1 pc |
| 5. Micphones .....      | 2pcs |
| 6. AUX cable .....      | 1 pc |

Documents / Resources

	<p><a href="#">HWWR HWWR-T10-T Portable Bluetooth Speaker</a> [pdf] User Manual HWWR-T10-T Portable Bluetooth Speaker, HWWR-T10-T, Portable Bluetooth Speaker, Bluetooth Speaker, Speaker</p>
---	---