



hygger HG032 4 in 1 Submersible U-V Filter User Manual

September 1,
2025



E-mail: distributor@hyggeraquarium.com

Website: www.hyggeraquarium.com



Contents [[hide](#)]

1 HG032 USER MANUAL

1.1 hygger 4-in-1 Submersible U-V Filter

1.1.1 1. PRODUCT FEATURE

1.1.2 2. PRODUCT SPECIFICATIONS

1.1.3 3. INSTRUCTIONS

1.1.4 4. ATTENTIONS

1.1.5 5. WARNING

1.1.6 6. HYGGER LIMITED MANUFACTURER'S WARRANTY

1.1.6.1 WARRANTY LIABILITY DISCLAIMER

1.1.7 7. DISPOSAL

1.1.8 8. PACKING LIST

1.1.9 9. CONTACT INFORMATION


2 Documents / Resources

2.1 References

HG032 USER MANUAL

hygger 4-in-1 Submersible U-V Filter

This product has the functions of filtration, circulation, oxygenation, rain oxygenation and water purification.



Important cautions

Filters with UV function cannot be looked directly during operation

1. PRODUCT FEATURE

- Efficient oxygenation
- Activated carbon sponge better purifies water
- The humanized timer has a wider application range
- Only for freshwater use


2. PRODUCT SPECIFICATIONS

Model	HG032
Volt/Freq	US standard: AC 110-120V/60Hz EU/UK/AU standard: AC 220-240V/50Hz
Product size	Dia2.8"x11"(7x28CM)
Water pump power	6W
H max	2.6Ft(0.8M)
Q max	211GPH(800L)
Light	8W

3. INSTRUCTIONS

1. Open the package and remove the filter. Check for damaged filters or damaged power cords. Do not use it if damaged.

2. Use suction cups to fix the filter to the proper position and angle of the aquarium or fish tank wall. The water level must reach the MINIMUM WATER LEVEL line for it to work properly damaged filters or damaged power cords. Do not use it if damaged.



a. MINIMUM WATER LEVEL

Reminder: Make sure the filter is positioned above the minimum water level.

3. Connect the power supply of the filter to the socket to make it work with electricity! Select functions such as rain oxygenation and oxygenation according to your needs. When the Oxygenation nozzle is configured, the oxygen-enhancing effect is better when the minimum water level line is less than 10 CM (3.94 inch) from the water surface.


4. For users who use the version with the UV timed sterilization function, please select the lighting duration as required. You can choose from 4H, 8H, 12H, or 24H per day; just press the SET button to select the desired duration. Take 4 hours as an example. Press the SET button, and the yellow light for 4H will light up, and UV will run for 4 hours. After 4 hours, the indicator lamp will flash, and UV will start running again the next day according to the time initially pressed. Long press 3seconds to turn ON or OFF the UV light.

5. After the filter works for a period of time, due to the influence of impurities in the fish tank, the filter water pump will be blocked and the filter sponge will be blocked. Please replace the filter sponge and clean the filter water pump in time!

Attention please! The filter sponge is suggested to be replaced every 2 weeks to 1 month depending on the number of fish, filthiness, or the extent of degradation.

6. Filters with UV function cannot be looked directly during operation.

Installation Diagram



a. Fitter sponge

b. UV lamp

4. ATTENTIONS

1. This product has the functions of filtration, circulation, oxygenation, rain oxygenation and water purification.

2. If this product is used in conjunction with UV lamps, it also has the functions of sterilizing, removing green algae and restoring water clarity.

3. The power plug and UV time controller are not waterproof please keep it away from water and water vapor. It is strictly forbidden to touch with power plug with wet hands, and please turn off the power before cleaning.

4. The working voltage must be compatible with the voltage specified for the filter.

5. The filter must be fully submersible for use. When using a filter with UV sterilization function, when cleaning and replacing the UV lamp, please pay attention to protect your eyes and not directly look at it. And cleaning and replacement should be carried out in the case of power failure or wearing protective glasses.

6. When this product does not work properly, it should be repaired by a professional.

The filter sponge inside the filter is recommended to be replaced every three months.

This product is not a toy. It is recommended to replace the UV lamp tube every 6 months, and please replace the appropriate UV lamp tube and filter sponge according to the packaging instructions. In this way, it can play a better effect. Keep this product away from children.

7. Please mind that the operating temperature range for the filter is between 40°F ~95°F (4°C~35).

5. WARNING

To avoid possible electric shock, do not immerse the switch in the water. If the switch falls into the water or becomes wet, do not touch it until you have unplugged it. Basic safety precautions that should be observed are as follows:

1. Read and follow this user manual strictly.
2. DANGER- To avoid possible electric shock, special care should be taken since water is employed in the use of aquarium equipment. For each of the following situations, do not attempt to repair yourself. Instead, return the filter to an authorized service facility for maintenance or discard it.
 - A. If the appliance falls into the water, DO NOT touch it. First unplug it, then retrieve it. If electrical components of the appliance get wet, unplug it immediately.
 - B. Carefully examine the filter after installation. It should not be plugged in if there is water on parts that are not intended to be wet.
 - C. Do not operate the filter if it has a damaged cord or plug, is malfunctioning, dropped, or damaged in any manner. The power cord of this filter cannot be replaced. If the cord is damaged, the filter should be discarded.
 - D. To avoid the possibility of the filter plug getting wet, position the aquarium and its stand to one side of a wall mounted outlet to prevent water from dripping onto the outlet or plug. A “drip loop”, shown in the figure below, should be arranged by the user for each cord, which connects the filter to the outlet. If an extension cord is used, the “drip loop” is the part of the cord below the level of the outlet or the connector that prevents water

from traveling along the cord and coming in contact with the outlet. If the plug or outlet does get wet, DO NOT unplug the cord. Disconnect the fuse to the circuit breaker that supplies power to the filter. Then, unplug and examine for the presence of water in the outlet. If you are not sure, consult a certified electrician.

POWER CORD



DRIP LOOP

3. Close supervision is necessary when the filter is used near children.
4. This filter is not allowed to use by persons (including children) with reduced physical sensory or mental capabilities or lack of experience and knowledge unless they have been given supervision or instruction concerning the use of the filter by a person responsible for their safety.
5. To avoid injury, do not contact moving or hot parts.
6. Always unplug the filter from the outlet when not in use, before putting on or taking off parts, maintenance, or placing hands in the water. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull to disconnect.
7. Do not use the filter for other than intended use. The use of attachments not recommended or sold by the appliance manufacturer may cause an unsafe condition and will void the warranty.
8. Do not install or store the filter where it will be exposed to extreme weather or temperatures below freezing.
9. Make sure the filter is securely installed before operating it.
10. Read and observe all the important notices on the filter.

11. If an extension cord is necessary, a cord with a proper rating should be used, such as rated amperes or watts. A cord rated for fewer amperes or watts than the filter rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.

12. The filter is intended FOR HOUSEHOLD USE ONLY.

13. SAVE THIS USER MANUAL.

6. HYGGER LIMITED MANUFACTURER'S WARRANTY

We offer the end user of this product a manufacturer warranty of 3 (2) years from the date of sale if this product was purchased from a hygger®-authorised specialist dealer.

Retain receipt for any future warranty claim. Conditions apply. Products are guaranteed by hygger® Aquatic Supplies to the original purchaser against defective material and workmanship under normal use for a period up to 3 (2) years from the date of the original purchase through an Authorized Dealer. Refer to the User Manual included with your product for specific warranty details.

Products have no warranty if:

- 1.) The product has been serviced, modified or tampered with by anyone other than hygger® Aquatic Supplies.
- 2.) The product has been abused or damaged (including broken or cracked bulbs), and/or.
- 3.) The product has been transported without proper packaging.
- 4.) The product was purchased from an Unauthorized Reseller.

WARRANTY LIABILITY DISCLAIMER

In no event will hygger® be liable for any consequential or incidental damages, including but not limited to, lost aquatic life, personal injury, property damage, equipment damage, lost profits, lost wages, lost savings, lost income, etc., arising out of the use of any hygger® products.

1.0. Terms and Conditions of Warranty.

- 1.1. hygger® warrants to the purchaser, for 3 (2) years from date of original purchase through an Authorized hygger® Reseller, free to repair or replace parts where fault is found due to defective materials or faulty workmanship and where goods do not operate in accordance with the instructions.
- 1.2. All claims for repair or replacement must be made at place of purchase.
- 1.3. Only the direct purchaser is entitled to warranty claims against us and these are not transferable without our consent.
- 1.4. The original and dated Proof of Purchase (receipt) must be supplied with all goods claims. Please also provide this Guarantee where possible.
- 1.5. Wear parts (e.g.: seals, suction devices, axes, pump wheels, light sources, pH electrodes, filter media, such as filter cartridges, as well as UVC burners), glass damage and the opening of the product, as well as structural changes or the use of non-hygger® original parts are excluded from the guarantee.
- 1.6. All goods subject to claim under Guarantee should be prepared for transportation in the original packaging or other comparable packaging which offers the same degree of protection and hygger® must incur no costs from the shipment.
- 1.7. Where claims on inspection reveal goods are in normal working order, hygger® will request reimbursement of all reasonable costs incurred.
- 1.8. Warranty claims do not exist in the case of only insignificant deviations from the agreed or customary condition or usability, e.g. insignificant deviations in colour, dimensions and/or quality or performance characteristics of the products.
- 1.9. Our warranty obligation extends only to the delivery of newly manufactured products. Unless otherwise agreed, used products are sold as seen, excluding any warranty.

For more warranty information, please see the hygger website.

7. DISPOSAL

Do not dispose of this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary. This product has to be disposed of at an authorized place for the recycling of electrical and electronic appliances rather than being disposed of together with the domestic waste. Collecting and recycling waste is a way of saving natural resources. So, please consult with your local seller to make sure the product is disposed of in an environmentally friendly way.



8. PACKING LIST

1x Filter with timer
1x Bag accessories
1x User manual

9. CONTACT INFORMATION

Distributed by: Hygger Aquarium, Inc.
13941 Magnolia Ave, Chino, CA 91710

E-mail: distributor@hyggeraquarium.com

Website: www.hyggeraquarium.com

Trademarks of Shenzhen Mago Trading Co., Ltd
Bantian Group Business Center, Longgang,
Shenzhen City, China
All Rights Reserved

Made in China



Company: E-CrossStu GmbH
Address: Mainzer Landstr.69,60329
Frankfurt am Main

E-mail: e-crossstu@outlook.com

Tel: +49 69332967674



CET Product Service Ltd.
Beacon House Stokenchurch Business

Park, Ibstone Rd, Stokenchurch

High Wycombe HP14 3FE UK


info.cetservice@gmail.com

+447419325266



MADE IN CHINA

Documents / Resources

 <small>Email: sales@hygger.com Website: www.hygger.com</small>	hygger HG032 4 in 1 Submersible U-V Filter [pdf] User Manual HG032 4 in 1 Submersible U-V Filter, HG032, 4 in 1 Submersible U-V Filter, Submersible U-V Filter, U-V Filter
---	---

References

- [User Manual](#)

hygger

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.