

Contents [[hide](#)]

- [1 Meet Hyperboot](#)
- [2 MEET YOUR NEW HYPERBOOTS](#)
- [3 CONTROL UNIT](#)
- [4 BEFORE YOU START](#)
- [5 START YOUR SESSION](#)
- [6 CHARGE YOUR NEW HYPERBOOTS](#)
- [7 WE'RE HERE FOR YOU](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

Meet


Meet Hyperboot



MEET YOUR NEW HYPERBOOTS


RIGHT

LEFT



CONTROL UNIT

1. USB-C CHARGING PORT
2. BATTERY CHARGE/POWER INDICATOR LED
3. POWER BUTTON (ON/OFF)
4. COMPRESSION LEVEL (MASSAGE MODE) INDICATOR LED
5. COMPRESSION LEVEL (MASSAGE MODE) BUTTON
6. HEAT LEVEL INDICATOR LED
7. HEAT LEVEL BUTTON
8. START/STOP INDICATOR LED
9. START/STOP BUTTON



BEFORE YOU START

READ THE ENTIRE INSTRUCTION MANUAL BEFORE USING THE HYPERBOOT BY NIKE X HYPERICE

DOWNLOAD AND CONNECT TO THE HYPERICEAPP

GET THE MOST OUT OF YOUR HYPERBOOTS WITH THE HYPERICE APP.

FIRST, MAKE SURE YOUR HYPERBOOT IS TURNED ON. MAKE SURE-THAT BLUETOOTH@ IS ENABLED ON YOUR MOBILE DEVICE, AND THAT YOUR HYPERBOOT IS WITHIN RANGE. OPEN THE HYPERICE APP ON YOUR MOBILE DEVICE-AND CLICK ON THE IMAGE OF YOUR HYPERBOOTTO CONNECT. ONCE CONNECTED, THE POWER INDICATOR LED WILL TURN BLUE TO SHOW SUCCESSFUL BLUETOOTH@ CONNECTION. BATTERY LEVEL WILL NOW BE DISPLAYED IN THE APP.



DOWNLOAD THE
HYPERICE APP


START YOUR SESSION

PUTTING ON YOUR HYPERBOOT

PUT YOUR DEVICE ON AND SECURE STRAPS TO A COMFORTABLE POSITION.

POWER

PRESS AND HOLD [POWER] BUTTON FOR 1 SECOND AND THEN RELEASE LED WILL LIGHT UP TO SHOW BATTERY LEVEL DEVICE WILL AUTOMATICALLY INFLATE TO FIT.



- COMPRESSION




PRESS [COMPRESSION] BUTTON TO DESIRED LEVEL. WHITE LEDS INDICATE LEVEL (0-3).

- HEAT

PRESS [HEAT] BUTTON TO DESIRED LEVEL. WHITE LEDS INDICATE LEVEL (0-3).


- START/STOP

PRESS [START/STOP] TO BEGIN OR END ASESSION.



CHARGE YOUR NEW HYPERBOOTS

TO CHARGE, CONNECT THE USB CABLE INTO THE CHARGER, PLUG THE CHARGER INTO THE WALL OUTLET, AND THE USB-C CABLE INTO THE HYPERBOOT. FULLY CHARGE THE BATTERY FOR UP TO SIX HOURS BEFORE USE.



CARING FOR YOUR HYPERBOOTS

MAKE SURE THE POWER IS OFF AND THE CHARGER IS NOT ATTACHED. USE A TOWEL OR SOFT CLOTH TO WIPE AWAY ANY MOISTURE FROM THE UNIT. STORE IN A CLEAN, COOL, DRY PLACE OUT OF DIRECT SUNLIGHT. WHEN NOT IN USE, DO NOT CREASE THE UNIT BY PLACING ITEMS ON TOP OF IT DURING STORAGE

WE'RE HERE FOR YOU


HYPERCARE

GET AWARD-WINNING SUPPORT FROM OUR HYPERCARE TEAM -A GROUP OF SPECIALISTS DEDICATED TO YOUR OVERALL WELL-BEING AND PERTIGRATION ON HYPE-RICE PRODUCTS

- 1855734.7224
- [HYPE-RICE.COM](https://hype-rice.com)
- CUSTOMERSUPPORT@HYPERICE.COM

IF OUTSIDE OF THE UNITED STATES, PLEASE VISIT [HYPERICE.COM/CONTACT](https://hyperice.com/contact) 460-00120 REV 1

Documents / Resources

	Hype Meet Hyperboot [pdf] User Manual 460-00120, 460-00120Rev1, Meet Hyperboot, Meet, Hyperboot
---	--

References

- [User Manual](#)

■ HYPE ♦ 460-00120, 460-00120Rev1, HYPE, Hyperboot, MEET, Meet Hyperboot

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.