



# Hyperice Hypervolt BT Bluetooth Percussion Massage Device Instruction Manual

[Home](#) » [Hyperice](#) » Hyperice Hypervolt BT Bluetooth Percussion Massage Device Instruction Manual 



## Hypervolt BT Operating Instructions

### PLEASE READ PRIOR TO USE

The Hypervolt Plus is a handheld percussion massage device that helps relieve muscle soreness and stiffness, accelerates warmup and recovery before and after physical activity, and promotes circulation.

#### Contents

- [1 OPERATING](#)
- [2 CLEANING AND STORAGE](#)
- [3 SPECIFICATIONS](#)
- [4 IMPORTANT SAFETY INSTRUCTIONS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

## OPERATING

Switch your Hypervolt Plus to the ON position at the base of the handle. Once your device is powered ON a blue light will illuminate, plus (up to) four green lights for battery level. Next, activate the pressure sensor by pressing the speed setting button once. Wait five seconds as the white lights sequence and turn off. Your Hypervolt Plus is now ready for use.

Change speeds (1-3) by pressing the speed setting button once per speed. The blue lights above the speed setting button will indicate the current speed. To change head attachments insert the desired head directly into the shaft/opening while pushing firmly. For the Fork, attachment align the “groove” on the fork with the recess on the shaft/opening and push firmly.

## CLEANING AND STORAGE

Make sure the power is OFF and the battery charger is not attached. Use a damp, clean, cloth and gently wipe your Hypervolt Plus. Store in a clean, cool place when not in use.


## SPECIFICATIONS

1. Removable battery release
2. Handle/rechargeable lithium-ion battery
3. Speed indicators (3)
4. Speed setting button
5. Pressure sensor indicators
6. Battery level indicators (4 / LED band)
7. ON / OFF power switch
8. Interchangeable head attachments (5)
9. Bluetooth® connection indicator

AC charger: 110-240V 50/60Hz – .5A – 24VDC- 1A

Frequency (Hz): level 1 – 1800/30, level 2 – 2400/40, level 3 – 3200/53

Weight: 3 lbs/1.3 kg



**DANGER:** TO REDUCE RISKS OF ELECTRIC SHOCK, FIRE, PERSONAL INJURY, OR PROPERTY DAMAGE, THIS PRODUCT MUST BE USED IN ACCORDANCE WITH THE FOLLOWING WARNINGS, CAUTIONS, AND SAFETY INSTRUCTIONS:

## IMPORTANT SAFETY INSTRUCTIONS

The Hypervolt (the term “Hypervolt” shall refer to both the Hypervolt and Hypervolt Plus models) is for adult use only and should always be used in accordance with the following warnings and instructions.

When using the Hypervolt use only on dry, clean surfaces of the body by lightly pressing and moving across the

body for approximately sixty(60) seconds per region. The Hypervolt should only be used on soft tissue areas of the body and should not be used on any hard or bony areas of the body, including the head. Please immediately stop the use of the Hypervolt upon experiencing any pain or discomfort, apart from light muscle soreness. Bruising can occur from the use of the Hypervolt, regardless of the pressure setting, and if bruising does occur you should not use the Hypervolt on the bruised area until the bruise is fully healed. Use of the Hypervolt should also be avoided on all bruises, contusions, rashes, or irritated or injured areas of the skin until they are fully healed. When using the Hypervolt be sure to keep fingers, toes, hair, and other body parts away from the back of the applicator to avoid pinching or hair entanglement.

The Hypervolt should be kept dry, should never be immersed in water, and should be kept away from liquids and heat sources at all times. The ventilation holes on the Hypervolt should be kept free of dust, debris, and/or any other substance that could penetrate the holes, including but not limited to liquids, dirt, sand, or food. You should never operate the Hypervolt for more than one (1) continuous hour at a time and after each use please allow the Hypervolt to rest for a minimum of thirty (30) minutes before using it again.

THE HYPER VOLT SHOULD ONLY BE CHARGED WITH THE TWO-PRONGED, DOUBLE INSULATED, 26VDC HYPERICE CHARGER (MODEL NUMBER

SK03T1-2600100W2 OR MX24D2-2801000) THAT WAS SUPPLIED WITH THE UNIT. DO NOT CHARGE THE HYPERVOLT OVERNIGHT OR LEAVE THE HYPER VOLT UNATTENDED WHEN CHARGING OR IN USE.

After charging the Hypervolt, the charger should be unplugged from the Hypervolt's battery handle prior to use. Prior to disposing of a Hypervolt unit the battery must be removed. The battery must be complied with safely at an appropriate e-waste disposal or recycling facility.

The Hypervolt should never be used for any purpose other than its intended use, should not be dropped, and should never be tampered with or altered in any way.

PLEASE DO NOT USE THE HYPER VOLT, OR ANY PERCUSSION OR VIBRATION DEVICE WITHOUT FIRST OBTAINING APPROVAL FROM YOUR PHYSICIAN IF ANY OF THE FOLLOWING APPLY:

Pregnancy, diabetes with complications such as neuropathy or retinal damage, wear of pacemakers, recent surgery or injury, epilepsy or migraines, herniated disks, spondylolisthesis, spondylolysis, or spondylosis, recent joint replacements or IUD's, metal pins or plates or any concerns about your physical health. Frail individuals and children should be accompanied by an adult when using any percussion or vibration device. These contraindications do not mean that you are not able to use a percussion or vibration device but we advise that before doing so you consult your physician. Ongoing research is being done on the effects of percussion massage for specific medical disorders that may result in the shortening of the list of contraindications as shown above.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The device has been evaluated to meet general RF exposure requirements the device can be used in portable

exposure conditions with restriction



Documents / Resources

<div><div>Hypervolt BT</div><div><div></div><div></div></div></div>	<p><a href="#">Hyperice Hypervolt BT Bluetooth Percussion Massage Device</a> [pdf] Instruction Manual 54020, 2AWQY-54020, 2AWQY54020, Hypervolt BT, Bluetooth Percussion Massage Device, Hypervolt, BT Bluetooth Percussion Massage Device, Hypervolt BT Bluetooth Percussion Massage Device, Percussion Massage Device, Massage Device</p>
---	---

[Manuals+](#).