



[Home](#) » [hyperoptic](#) » **hyperoptic EX3301 Hyperhub Router Instruction Manual** 

## Contents [ [hide](#) ]

- [1 hyperoptic EX3301 Hyperhub Router](#)
- [2 Product Usage Instructions](#)
- [3 What's in the box](#)
- [4 Get connected now](#)
- [5 Setting up your Hyperhub router](#)
- [6 Connecting your devices](#)
- [7 What the lights on your router mean](#)
- [8 Safety instructions](#)
- [9 FAQ](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)



## hyperoptic EX3301 Hyperhub Router



## Product Usage Instructions

- Connect one end of the ethernet cable to the WAN port on the router and the other end to the Hyperoptic socket on the wall.
- Plug the router into the mains power using the power supply and press the on/off button on the router.
- Wait until the WAN and internet lights turn green, indicating readiness to connect your devices.
- For optimal connection, it is recommended to connect your devices directly to the router via LAN ports using an Ethernet cable.
- Follow the router's Wi-Fi setup instructions.
- If compatible, plug your phone into the router's phone port using an RJ11 phone cable.
- Ensure proper ventilation by wall-mounting the router. Avoid placing it on soft fabric or in areas that restrict air circulation.

## Hello from Hyperoptic

- Let's get you up and running with your new full fiber broadband.
- In this guide, you'll find everything you need to get your
- Hyperhub router and other devices set up, plus loads more.

## What's in the box



## Get connected now


- Watch our video guide to setting up your Hyperhub router.
- Simply use your mobile phone camera to scan the QR code or visit [hyperoptic.com/zyxel3301](https://hyperoptic.com/zyxel3301)



## Setting up your Hyperhub router


### Plug in

- Plug one end of the Ethernet cable into the WAN port on the router and the other end into the Hyperoptic socket on the wall.




### Power up

- Connect the router to the mains power using the power supply and press the on/off button on the router.



## Green means go

- Once the WAN and internet lights are green (this might take a few minutes), you're ready to connect your devices.



## Connecting your devices

- For the best possible connection, we recommend connecting your devices directly to the router (via the LAN ports) using an Ethernet cable.



### To connect to the Wi-Fi

- Scan the QR code on the card on the back of your Hyperhub router using the camera on your mobile phone or tablet.
- Alternatively, use the Wi-Fi username and password info on the back of your Hyperhub router.



### To connect your phone

- If you have a compatible phone and have ordered our phone service, simply plug it into the router's phone port using an RJ11 phone cable (supplied with most phones).
- Please note, while most handsets are compatible, some BT-branded handsets may not work with our service.

## What the lights on your router mean



### INTERNET

- Green On – Internet is ready Blinking – Transmitting/receiving internet data
- Red On – Hyperhub is receiving a broadband signal but isn't connected to the

internet. Off – The Internet is not ready

If everything is plugged in and all lights are off, or the red light is on 20 minutes after set-up, please get in touch.



- Green On – Power is on Blinking – Starting up
- Red On – Malfunctioning Blinking – We're upgrading your Hyperhub firmware. Please keep the power on

If everything is plugged in and the red light is on or blinking 1 hour after set-up, please get in touch.

## **Safety instructions**

In order to keep your connection running smoothly and avoid any potential safety risks, you must treat your Hyperoptic equipment properly and make sure it's placed in the right location.

Please take a look at our tips below and make sure you're following proper guidance when it comes to your Hyperoptic router.

- Hyperhubs should be kept indoors, far away from sources of heat and/or direct sunlight (e.g., radiators, oven hobs, etc.).
- Hyperhubs should be kept on a flat surface, clear of clutter (e.g. a desk or cabinet) or wall-mounted, ensuring that there is adequate air circulation around the device. Please do not place the device on soft fabric, furniture or items that limit the air circulation (e.g. carpet or rugs, inside cupboards, on/behind sofas etc.).
- Hyperhubs should be kept far away from any electrical appliances with strong magnetic or electric outputs (e.g, microwaves, fridges, Bluetooth devices, etc.).
- Hyperhubs should be kept away from liquids and damp areas. It's very important to keep your devices dry, without the possibility of liquid spilling onto or into them.
- Please do not use flammable substances on or around your devices and keep them away from any potentially flammable atmospheres, such as a garage or a workshop.
- Please ensure that all cables are not twisted, pulled, or wrapped tightly.

- Clean Hyperhubs with a soft, dry cloth only. Never use liquids or solvents.
- Please only use the power supply included with your Hyperhub.

## Need help?


- Visit our online help pages to find answers to frequently asked questions:  
[hyperoptic.com/help](https://hyperoptic.com/help)
- If your service is not working, scan the QR code to find our step-by-step guide to restoring service quickly
- Prefer to get in touch with our Customer Support team?
- You can find all the ways to contact us at [hyperoptic.com/contact-us](https://hyperoptic.com/contact-us)



## FAQ

- **What should I do if my internet is not working after setup?**
  - If your service is not working, refer to our online help pages for troubleshooting steps or contact Customer Support for assistance.
- **How do I know if my router is malfunctioning?**
  - If the power light is red or blinking an hour after setup, please contact us for support.
- **Can I use my own phone with the router?**
  - Most compatible phones can be used with our service. For specific compatibility concerns, please reach out to us for guidance.

## Documents / Resources

	<a href="#">hyperoptic EX3301 Hyperhub Router [pdf]</a> Instruction Manual EX3301, EX3301 Hyperhub Router, Hyperhub Router, Router
---	---

## References

- [User Manual](#)

🔑 EX3301, EX3301 Hyperhub Router, Hyperhub Router, hyperoptic,

📁 hyperoptic router

---

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.