



HYPERX B08NTYB4M7 Cloud II-wireless Gaming Headset User Guide

[Home](#) » [HYPERX](#) » **HYPERX B08NTYB4M7 Cloud II-wireless Gaming Headset User Guide**


HYPERX B08NTYB4M7 Cloud II-wireless Gaming Headset



Contents [[hide](#)]

- 1 Overview
- 2 Usage
- 3 Setting up with PC
 - 3.1 Playback Device
 - 3.2 Recording Device
- 4 Setting up with PlayStation 4
- 5 Status LED
- 6 Mic mute / mic monitoring button
- 7 Power button / 7.1 Surround Sound
- 8 Volume wheel
- 9 Charging
 - 9.1 Wired Charging
- 10 HyperX NGENUITY Software
- 11 Questions or Setup Issues?
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

Overview



- A. Mic mute/mic monitoring button
- B. USB charge port
- C. Microphone port
- D. Status LED
- E. Power button / 7.1 Surround Sound button
- F. Volume wheel

- G. Detachable microphone
- H. Microphone mute LED
- I. USB adapter
- J. Wireless pairing pin hole
- K. Wireless status LED
- L. USB charge cable


Usage




1. Connect the wireless USB adapter to your device
2. Power on the headset

Setting up with PC

Right click speaker icon > Select Open Sound settings > Select Sound control panel






Playback Device


1. Set Default Device to **“HyperX Cloud II Wireless”**
2. Right click on **“HyperX Cloud II Wireless”** and click on Configure.

Select 7.1 Surround to configure your setup and click next.



Recording Device

Set Default Device to **“HyperX Cloud II Wireless”**



Setting up with PlayStation 4

1. Connect the wireless USB adapter to your device
2. Power on the headset



Settings > Devices > Audio Devices

Input Device: **USB Headset “HyperX Cloud II Wireless”**

Output Device: **USB Headset “HyperX Cloud II Wireless”**

Output to headphones: **All Audio**

Status LED

STATUS	LED
Pairing	Flash Green and Red every 0.2s
Searching	Slow breathing Green
Connected*	90% — 100%: Solid Green
	15% — 90%: Blinking Green
	< 15%: Blinking Red

*Battery level indication

Mic mute / mic monitoring button

- LED On – Mic muted
- LED Off – Mic active
- Hold for 3 seconds to toggle mic monitoring on/off


Power button / 7.1 Surround Sound

- Power on/off – Hold power button for 3 seconds
- Press to toggle 7.1 Surround Sound on/of

Volume wheel

Scroll up and down to adjust volume level.

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.




Charging

It is recommended to fully charge your headset before first use.

STATUS LED	CHARGE STATUS
Solid Green	Fully Charged
Breathing Green	15% — 99%
Breathing Red	< 15%

Wired Charging



HyperX NGENUITY Software



NGENUITY

hyperxgaming.com/ngenuity

Questions or Setup Issues?

Contact the HyperX support team or see the user manual at : hyperxgaming.com/support/headsets



ANATEL ID: 14135-20-07196

ANATEL ID: 14212-20-07196

 RAMATEL C-25675

 RAMATEL C-25674



NTC

Type Accepted


No.: ESD-RCE-2023687



NTC

Type Accepted

No.: ESD-RCE-2023688



HyperX is a division of Kingston.

THIS DOCUMENT SUBJECT TO CHANGE WITHOUT NOTICE

©2021 Kingston Technology Corporation, 17600 Newhope Street, Fountain Valley, CA 92708 USA.


All rights reserved. All registered trademarks and trademarks are the property of their respective owners.

Kingston Technology Europe Co LLP, Kingston Court, Brooklands Close, Sunbury-on-Thames, Middlesex, TW16 7EP, UK.

Kingston Technology International Ltd, Stratus House, College & Business Technology Park, Blanchardstown Road North, Dublin, D15 PEC4, Ireland



Documents / Resources



- ~~HX~~ HyperX | High Quality Gaming Gear
- ~~HX~~ HyperX | High Quality Gaming Gear