



HYPERX CL004 Cloud Core Wireless Headset User Guide

[Home](#) » [HYPERX](#) » HYPERX CL004 Cloud Core Wireless Headset User Guide 

Contents

- [1 HYPERX CL004 Cloud Core Wireless Headset](#)
- [2 Overview](#)
- [3 Usage](#)
- [4 FCC Statement](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



HYPERX CL004 Cloud Core Wireless Headset




Overview

Use the following line drawings:

1. $\frac{3}{4}$ view of headset without microphone
2. Bottom view of headset (labels A-F)
3. Detachable boom microphone with mic foam (label G-H)
4. Top-down view of USB wireless adapter (labels I-K)
5. USB charge cable (label L)

Reference images:




- Status LED
- Mic mute / mic monitoring button
- USB-C charge port
- Microphone port
- Volume wheel
- Detachable microphone
- Microphone mute LED
- USB adapter
- Wireless pairing pinhole
- Wireless status LED

Usage

Use the following line drawings:

- $\frac{3}{4}$ view of headset with microphone attached
- Wireless adapter
 - Arrow pointing from the USB adapter to PC USB port and PS4 USB port

Reference images:





1. Connect the wireless adapter to your device
2. Power on the headset

Setting up with PC

Right-click speaker icon > Select Open Sound settings > Select Sound control panel [Use Windows 10 1903 Setup speaker icon menu graphic and sound settings menu graphic]


Reference images:



Playback Device

1. Set Default Device to "HyperX Cloud Core Wireless"
[Use Windows OS playback sound control panel menu graphic for selecting HyperX Cloud II Wireless as Default Device]


Reference image:



2. Right click on “HyperX Cloud Core Wireless” and click on Configure.
3. Select 7.1 Surround to configure your setup and click next.

[Use Windows OS playback sound control panel menu graphic for selecting speaker setup]


Reference image:



Recording Device

Set Default Device to “HyperX Cloud Core Wireless” [Use Windows OS recording sound control panel menu graphic for selecting HyperX Cloud II Wireless as Default Device]

Reference image:




Setting up with PlayStation 4

Settings > Devices > Audio Devices Input Device: USB Headset “HyperX Cloud Core Wireless” Output Device: USB Headset “HyperX Cloud Core Wireless” Output to headphones: All Audio

Use the following line drawing:

- Bottom view of headset with left earcup only
 - Small label “Status LED” with an arrow pointing to the status LED on the left earcup
 - Small label “Mic mute / mic monitoring button” with an arrow pointing to the mic mute button on the left earcup

Reference image:



Status LED

Battery level indication


Mic mute / mic monitoring button

- Mic mute toggle – Press button to turn the mic mute on/off
 - Microphone mute LED On – Mic muted
 - Microphone mute LED Off – Mic active
- Mic monitoring toggle – Hold button for 3 seconds to toggle mic monitoring on/off

Use the following line drawing:

- Zoomed-in crop of the right earcup with focus on volume wheel
 - Small label “Volume wheel” with an arrow pointing to the volume wheel on the right earcup

Reference image:



Volume wheel

Scroll up and down to adjust volume level.

Charging

It is recommended to fully charge your headset before first use.

Use the following line drawing:

- Connect the USB-C charge cable USB-A end to PC and USB-C end to headset USB charge port

Reference images:



HyperX NGENUITY Software

Download software and latest firmware updates at hyperxgaming.com/ngenuity [NGENUITY logo]

Questions or Setup Issues?

Contact the HyperX support team or see the user manual at hyperxgaming.com/support/headsets **WARNING:** Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —
Consult the dealer or an experienced radio/TV technician for help.


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ISED Statement:



This device contains license-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

1. this device may not cause interference,
2. this device must accept any interference, including interference that may cause undesired operation of the device.

Documents / Resources

	<p>HYPERX CL004 Cloud Core Wireless Headset [pdf] User Guide CL004, JIC-CL004, JICCL004, CL004WA, JIC-CL004WA, JICCL004WA, CL004 Cloud Core Wireless Headset, Cloud Core Wireless Headset, CL004WA HyperX Cloud Core Wireless adapter</p>
---	---

References

-  [HyperX | High Quality Gaming Gear](#)
-  [HyperX | High Quality Gaming Gear](#)