

# **HYPERX Cloud Buds User Manual**

**Home** » **HYPERX** » **HYPERX** Cloud Buds User Manual



# User Manual HyperX Cloud Buds

Find the language and latest documentation for your HyperX Cloud Buds here.

# **HyperX Cloud Buds Installation Guide**

## Contents [ hide

- 1 HyperX Cloud Buds
- 2 Overview
- 3 Specifications
- 4 Fitting the HyperX Cloud Buds to your

#### Ears


- **5 Changing Ear Tips**
- **6 Controls** 
  - **6.1 Power Button**
- 7 Headset Charging
- **8 Status LED Indicators**
- 9 Factory Reset
- 10 Questions or Setup Issues?
- 11 Documents / Resources
  - 11.1 References
- **12 Related Posts**

# **HyperX Cloud Buds**



Part Numbers HEBBXX-MC-RD/G

# Overview



A. HyperX Cloud Buds	C. USB-C charge cable
B. Interchangeable ear tips	D. Carrying case

# **Specifications**

## Headphone

Speaker driver: Dynamic with Neodymium magnets

Type: Neckband

Frequency response: 20Hz – 20kHz

Impedance:  $65.2 \Omega$ 

Sound pressure level: 104±3 dB 1mW at 1kHz

T.H.D: ≦2% at 200-3kHz

Weight: 27.5g

Charge cable length: USB-C to USB-A: 0.2m

### **Inline Microphone**

Element: Electret condenser microphone

Polar pattern: Omni-directional

Frequency response: 100Hz – 7.2kHz

Open circuit sensitivity: -16.5dBV (1V/Pa at1kHz)

# **Battery Life\***

Bluetooth: 10 hours

### **Bluetooth**

Bluetooth version: 5.1

Wireless range\*\*: Up to 10 meters / 33 feet Supported codecs: aptX<sup>™</sup>, aptX<sup>™</sup> HD, SBC Supported profiles: A2DP, AVRCP, HFP, HSP

# Fitting the HyperX Cloud Buds to your Ears

1. Insert ear tip into ear.



2. Tuck stabilizer flap into ear fold.

<sup>\*</sup>Tested at 50% headphone volume

<sup>\*\*</sup>Wireless range may vary due to environmental conditions



# **Changing Ear Tips**

1. Remove original ear tip by gripping the stabilizer flap and stretching ear tip over the hook on the nozzle.



2. Place new ear tip on the nozzle of the ear bud.



3. Pull the stabilizer flap to stretch the nozzle over the hook




# **Controls**

**Power Button** 

Hold for 2 seconds to turn on or off.

## Bluetooth® Pairing

- 1. With the headset off, hold the power button for 5 seconds to enter pairing mode. The LED indicator will flash red and blue and a voice prompt will play.
- 2. On your Bluetooth® enabled device, search and connect to "HyperX Cloud Buds." Once connected, the indicator LED will flash blue every 5 seconds and a voice prompt will play.



Status	1 Press	2 Presses	3 Presses	Long Press
Playing Media	Play/Pause	Skip Track	Previous Track	Activate Mobile Assistant
Receiving Call	Answer Call	X	X	Reject Call
In Call	End Call	Swap Calls	X	Х

Note: Button functionality may differ depending on the connected device.

## **Headset Charging**

When the headset is connected to a charger with the USB charge cable, the status LED will indicate the charge status. The headset will take approximately 3 hours to fully charge.

Status LED	Charging Status
Breathing red	Charging
Off	Fully charged

## **Status LED Indicators**

The status LED on the headset indicates the current state of the headset.

Status LED	Headset Status
Flash blue every 5 seconds	Connected to a device
Flash blue every 2 seconds	Not connected to a device
Pairing mode	Flashing red and blue
Factory reset	Flash blue 5 times and light up red for 1 second


# **Factory Reset**

To perform a factory reset on the headset, hold the power and volume up buttons together for 7 seconds. The status LED will flash red and blue 2 times, followed by solid red for 1 second. At the same time, the headset will play two low beeps. After this, the headset will automatically turn off.

# **Questions or Setup Issues?**

Contact the HyperX support team at: hyperxgaming.com/support/headsets

### **Documents / Resources**



## References

- <a>HyperX | High Quality Gaming Gear</a>
- <u>→ HyperX | High Quality Gaming Gear</u>

Manuals+, home privacy