

HyperX HX-KB7RDX-US Alloy Origins Core Mechanical **Gaming Keyboard User Manual**

Home » HYPERX » HyperX HX-KB7RDX-US Alloy Origins Core Mechanical Gaming Keyboard User Manual



Contents

- 1 HyperX HX-KB7RDX-US Alloy Origins Core Mechanical Gaming **Keyboard**
- 2 Overview
- 3 What's Included
- **4 Specifications**
 - 4.1 Installation
- 4.2 Function Keys
- 5 Documents / Resources
 - **5.1 References**
- **6 Related Posts**



HyperX HX-KB7RDX-US Alloy Origins Core Mechanical Gaming Keyboard




Overview





What's Included


HyperX Alloy Origins Core Mechanical Gaming Keyboard



• A. FN + F1, F2, F3 = Onboard memory profile selection




• B. FN + F6, F7, F8 = Media control keys




• C. FN + F9, F10, F11 = Volume control keys



• D. FN + F12 Game Mode key



- E. Game Mode / Num Lock / Caps Lock indicators
- F. FN + Up & Down = LED brightness control keys



- G. Keyboard feet with three adjustable angles (3°, 7°, 11°)
- . H. Keyboard USB-C port

Specifications

Keyboard

• Switch: HyperX Switch

• Type: Mechanical

• Backlight: RGB (16,777,216 colors)

• Light effects: Per key RGB lighting** and 5 brightness levels Onboard memory: 3 profiles

• Connection type: USB Type-C to USB Type-A

• Adjustable keyboard feet: 3°, 7°, 11°

• Anti-ghosting: 100% anti-ghosting

• Key rollover: N-key mode

· LED indicator: Yes

· Media control: Yes

· Game Mode: Yes

• OS compatibility: Windows® 10, 8.1, 8, 7

• Console compatibility: PS4, Xbox One

Key Switches

· Switch: HyperX Red Switch

· Operation style: Linear

• Operating force: 45 g

· Actuation point: 1.8 mm

• Total travel distance: 3.8 mm

• Life span (keystrokes): 80 million

Cable

• Type: Detachable, Braided


• Length 1.8 m

Dimensions

Width: 360.0 mmDepth: 132.5 mmHeight: 34.5 mm

• Weight (keyboard and cable): 900 g

Installation



- 1. Connect the USB-C connector to the keyboard.
- 2. Connect the USB connector to the computer.

Function Keys

Function Keys	Secondary Feature
FN + F1 F2 F3	Switch between the profiles on the onboard me mory.
FN F6 F7 F8 H	Play/pause, skip backward, or skip forward thro ugh your media.
FN F9 F10 F11 ++	
	Mute, decrease, or increase your volume level.
FN F12 申	Toggle Game Mode on/off. Game Mode will disable the Windows key. When Game Mode is
	enabled, the indicator on the top right of the key board will illuminate.
FN	Increase or decrease the LED backlight brightness.
	There are 5 levels of brightness: Off, 25%, 50%, 75%, 100%.

HyperX NGENUITY Software


To customize Lighting, Game Mode and Macro Settings, download the HyperX NGENUITY Software here: hyperxgaming.com/ngenuity.

Using with Console

Connect to PS4 or Xbox One using the included USB cable.

Factory Reset

If you are experiencing any issue with the keyboard, you can perform a factory reset. Onboard memory will be cleared, and all settings will revert back to default.



Questions or Setup Issues?

Contact the HyperX support team at: hyperxgaming.com/support/

Documents / Resources



HyperX HX-KB7RDX-US Alloy Origins Core Mechanical Gaming Keyboard [pdf] User Manu al

HX-KB7RDX-US, HX-KB7RDX-NO, HX-KB7RDX-RU, HX-KB7RDX-BR, HX-KB7RDX-JP, HX-KB7RDX-KO, Alloy Origins Core RGB Mechanical Gaming Keyboard, HX-KB7RDX-US Alloy Origins Core Mechanical Gaming Keyboard, Alloy Origins Core Mechanical Gaming Keyboard, Alloy Origins Core Mechanical Gaming Keyboard

References

- <u>March 1988</u>
 <u>Marc</u>
- <u>MyperX | High Quality Gaming Gear</u>

Manuals+,