



HyperX HX-MC006B Pulsefire Dart Wireless Gaming Mouse User Manual

[Home](#) » [HYPERX](#) » HyperX HX-MC006B Pulsefire Dart Wireless Gaming Mouse User Manual 

Contents


- [1 HyperX HX-MC006B Pulsefire Dart Wireless Gaming Mouse](#)
- [2 Overview](#)
- [3 Specifications](#)
- [4 Installation](#)
- [5 Charging](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



HyperX HX-MC006B Pulsefire Dart Wireless Gaming Mouse



Overview



- Left click button
- .Right click button
- .Mouse wheel
- DPI button
- Forward click button

- Backward click button
- USB-C port
- Mouse skates
- Power switch
- Optical gaming sensor
- Built-in wireless charging receiver module
- USB receiver
- USB cable adapter
- USB-C to USB-A extension cable

Specifications

Ergonomic: Ergonomic

Sensor: Pixart PMW3389

Resolution: Up to 16000 DPI

Speed: 450ips

Acceleration: 50G

Buttons: 6

Left / Right buttons switches: Omron

Left / Right buttons durability: 50 million clicks

Light effects: Per-LED RGB lighting¹

Onboard memory: 1 profile

Connection type: 2.4GHz wireless / wired

Battery life: 90 hours – LED off / 50 hours – Default LED lighting

Charging type: Wireless Qi charging³ / wired

Polling rate: 1000Hz

Cable type: Detachable charging/data cable

Weight (without cable): 112g

Weight (with cable): 130g


Dimensions (L x W x H): 124.8mm x 73.9mm x 43.6mm

Cable length: 1.8m

Installation


Wireless Mode

Connect your USB receiver to USB cable adapter, and USB-C to USB-A extension cable to a PC USB port. For optimal placement, please keep the USB receiver within 20 cm of the mouse.





Wired Mode

Connect your USB-C to USB-A extension cable to your mouse and to a PC USB port.




Charging

Wireless Charging



Wired charging



Function Keys

| Function Keys | Secondary Feature |
|---------------|--|
| DPI button | Change between DPI presets. Default values are: <ul style="list-style-type: none"> – 800 DPI (blue). – 1600 DPI (yellow). – 3200 DPI (green). |

HyperX NGENUITY Software

To customize lighting, DPI, and macro settings, download the HyperX NGENUITY Software here: hyperxgaming.com/ngenuity.

Using with Console

Connect to PS4 or Xbox One using the included USB cable or dongle attachment.

Factory Reset



If you are experiencing any issue with the mouse, you can perform a factory reset. Onboard memory will be cleared, and all settings will revert back to default.

| Function Keys | Secondary Feature |
|---|---------------------------------------|
| Hold DPI button + mouse wheel button down for 5 seconds | Perform a factory reset on the mouse. |



Questions or Setup Issues?





Contact the HyperX support team at: hyperxgaming.com/support/

Documents / Resources

| | |
|---|---|
|  | HyperX HX-MC006B Pulsefire Dart Wireless Gaming Mouse [pdf] User Manual HX-MC006B, Pulsefire Dart, Wireless Gaming Mouse, Pulsefire Dart Wireless Gaming Mouse, HX-MC006B Pulsefire Dart Wireless Gaming Mouse |
|  | HYPERX HX-MC006B Pulsefire Dart Wireless Gaming Mouse [pdf] User Manual HX-MC006B Pulsefire Dart Wireless Gaming Mouse, HX-MC006B, Pulsefire Dart Wireless Gaming Mouse, Wireless Gaming Mouse, Gaming Mouse |

References

-  [HyperX | High Quality Gaming Gear](#)
-  [HyperX | High Quality Gaming Gear](#)

-  [HyperX | High Quality Gaming Gear](#)
-  [HyperX | High Quality Gaming Gear](#)
-  [HyperX | High Quality Gaming Gear](#)
-  [HyperX - Pro Gaming Gear – HyperX ROW](#)

Manuals+.