



HYPERX Wireless Gaming Controller User Guide

[Home](#) » [HYPERX](#) » HYPERX Wireless Gaming Controller User Guide 

Contents


- [1 HYPERX Wireless Gaming Controller](#)
- [2 Overview](#)
- [3 Setup](#)
- [4 Pairing and Connecting](#)
- [5 Usage](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



HYPERX Wireless Gaming Controller




Overview



- Action buttons
- Analog sticks (L3/R3)
- D-Pad
- Home button
- Mode selection switch
- Bumpers (L1/R1)
- Triggers (L2/R2)
- USB-C port
- Convertible mobile clip
- 2.4GHz wireless adapter
- USB-C to USB-A cable

Setup


Charging



LED STATUS	BATTERY LEVEL
	≤ 25%
	26% - 50%
	51% - 75%
	76% - 100%

It is recommended to fully charge the controller before first use.

Mode Selection



Pairing and Connecting

2.4G

1. Set the mode selection switch to 2.4G.
2. Connect the 2.4GHz wireless adapter to the PC.
3. Tap the Home button. The controller will power on and attempt to connect to the 2.4GHz wireless adapter.


Bluetooth

1. Set the mode selection switch to Bluetooth.
2. Press and hold the Home button for 6 seconds until the LEDs rapidly scroll to indicate pairing mode.
3. On your Bluetooth-enabled device, search and connect to "HyperX Clutch."

Usage

Power – 2.4G or Bluetooth Mode

















Press the Home button to power the controller. The controller will attempt to connect to your device. The controller will automatically shut off after 5 minutes of inactivity.



Questions or Setup Issues?

Contact the HyperX Support Team at: <http://www.hyperxgaming.com/support>

Setup Charging

LED STATUS	BATTERY LEVEL
   	≤ 25%
   	26% - 50%
   	51% - 75%
   	76% - 100%

It is recommended to fully charge the controller before first use. Mode Selection Pairing and Connecting

2,4G

1. Set the mode selection switch to 2.4G.
2. Connect the 2.4GHz wireless adapter to the PC.
3. Tap the Home button. The controller will power on and attempt to connect to the 2.4GHz wireless adapter.

Bluetooth

1. Set the mode selection switch to Bluetooth.
2. Press and hold the Home button for 6 seconds until the LEDs rapidly scroll to indicate pairing mode.
3. In your Bluetooth-enabled device, search and connect to “HyperX Clutch.”

Usage

- Power – 2.4G or Bluetooth Mode
- Press the Home button to power the controller. The controller will attempt to connect to your device.
- The controller will automatically shut off after 5 minutes of inactivity.

Handheld Mode

Attach the mobile clip and insert a phone.


Tabletop Mode

Fold the clip to use as a phone or tablet stand.

Questions or Setup Issues?

Contact the HyperX Support Team at: <http://www.hyperxgaming.com/support>

Documents / Resources

	<p>HYPERX Wireless Gaming Controller [pdf] User Guide Wireless Gaming Controller, Gaming Controller, Controller</p>
---	---

References

-  [HyperX | High Quality Gaming Gear](#)

