



i-tec intel Graphics Driver Installer User Guide


[Home](#) » [i-tec](#) » i-tec intel Graphics Driver Installer User Guide 

Contents

- [1 i-tec intel Graphics Driver Installer](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)



i-tec intel Graphics Driver Installer



This step-by-step manual describes how to install a corresponding Intel® Graphics Driver.

1. Download the Intel® Graphics Driver 30.0.101.1631 from https://i-tec.cz/wp-content/uploads/man_dri/igfx_win_101.1631.exe
2. Run the downloaded file and click on the “Begin installation” button.




3. Read the Intel software agreement and click on the “I agree” button.





4. In the next window click on the “Yes” button next and then on the “Start” button.



5. Installation of the Intel® Graphics Driver 30.0.101.1631 should be finished in a few minutes. Then click on the “Finish” button and restart your device to finalize the installation process.



Documents / Resources

 <small>Step-by-step manual How to install a corresponding Intel® Graphics Driver</small> 	i-tec intel Graphics Driver Installer [pdf] User Guide intel Graphics Driver Installer, Graphics Driver Installer, Driver Installer, Installer
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------