



iball BTR009 Bluetooth Receiver for Speaker Instructions

[Home](#) » [iball](#) » **iball BTR009 Bluetooth Receiver for Speaker Instructions** 

Contents

- [1 iball BTR009 Bluetooth Receiver for Speaker](#)
- [2 Bluetooth Version](#)
- [3 Bluetooth Profile](#)
- [4 Working Time](#)
- [5 Weight](#)
- [6 Features](#)
- [7 Frequency Range](#)
- [8 Power Source](#)
- [9 Charging Time](#)
- [10 Dimensions](#)
- [11 Accessories](#)
- [12 Documents / Resources](#)
- [13 Related Posts](#)



iball BTR009 Bluetooth Receiver for Speaker



Bluetooth Version

Bluetooth V2.1

Bluetooth Profile

A2DP

Working Time

Up to 8 hours

Weight

14g

Features

- Enable your Speaker to receive audio
 - signal wirelessly.
 - Compact size.
 - Built-in rechargeable Lithium-ion battery. Compatible with Bluetooth A2DP Mobiles, Bluetooth enable PC and more
- Can be use with Speakers and any other audio device

Frequency Range

2.4GHz-2.4835GHz

Power Source

Rechargeable Lithium-ion battery

Charging Time

About 2.5 hours


Dimensions

45(W) x 32(D) x 8(H) mm

Accessories

- Bluetooth Audio Receiver,
- USB Charging Cable,
- RCA male to Stereo female converter,
- User Manual,
- Service Center List.

Documents / Resources



iball BTR009 Bluetooth Receiver for Speaker [pdf] Instructions
BTR009, Bluetooth Receiver for Speaker, BTR009 Bluetooth Receiver for Speaker