



IC REALTIME Orbit 360° WiFi Security Camera User Guide

[Home](#) » [IC REALTIME](#) » IC REALTIME Orbit 360° WiFi Security Camera User Guide 

Contents

- [1 IC REALTIME Orbit 360° WiFi Security Camera](#)
- [2 About the Guide](#)
- [3 Using IC Home](#)
- [4 Camera Installation](#)
- [5 What's in the Box](#)
- [6 Know your Orb](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



IC REALTIME Orbit 360° WiFi Security Camera



About the Guide

- This quick start guide is for reference only. Minor difference might be found in user interface.
- All the design and software here are subject to change without prior written notice.
- All trademarks & registered trademarks mentioned are the properties of their respective owners.
- Please visit our website or contact your local service engineer for more information.
- If there is any uncertainty or controversy, please refer to our final explanation.

Using IC Home

• Step 1

Scan the QR code or search “IC Realtime” in the Google Play or App Store to download and install IC Home.



• Step 2

Run the App, and then register a new account if you do not already have one.

• Step 3

Connect the camera to a power source.

- **Step 4**

The camera LED indicator will flash green when it is fully booted up.

- **Step 5**

With your mobile device connected to a 2.4 GHz WiFi band, add a camera by following the steps on the app.




Note:

- Repeat step S for adding multiple cameras.
- If camera fails to add or the WiFi connection is changed. Reset the camera and repeat step S.

Camera Installation

Note: Make sure the mounting surface can hold at least lib.



- **Step 1** Use the guide to mark & drill holes for the drywall anchors.
- **Step 2** Attach the mounting plate by drilling the provided screws into the anchors from step 1.
- **Step 3** Attach the camera to the mounting plate.


What's in the Box



Camera ×1




Power Adapter ×1




Power Cable ×1



Hole Guide ×1



Mounting Plate ×1




Hardware Package ×1



QSG ×1

Know your Orb





Note: Press & hold the reset button for 30s until you hear the audible prompt. The pattern of the LED indicator is included in the following table

Led Indicator Status : Device status	
Off Red light on	Powered off/LED turned off Rebooting after reset Booting Device malfunction
Green light flashing	Waiting for network/Hotspot Enabled
Green light on	Operating properly
Red light flashing	Network connection failed
Green and Red light	
flashing alternately	Firmware updating

Documents / Resources

	<p>IC REALTIME Orbit 360° WiFi Security Camera [pdf] User Guide Orbit 360 WiFi Security Camera, 360 WiFi Security Camera, WiFi Security Camera, Security Camera, Camera</p>
--	---