



ICODE WiFi Range Extender Instructions

[Home](#) » [ICODE](#) » ICODE WiFi Range Extender Instructions 

ICODE WiFi Range Extender Instructions



Contents

- [1 Introduction](#)
- [2 Trouble shooting](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Introduction

Dear customer

Thank you for purchasing on ICODE EX 300 wifi extender

This PDF is EX 300 wifi extender troubleshooting. Due to Amazon policy, some relevant videos, images and links will be band. If you can't click the link, please copy and paste link address on your browser IP address bar.

Trouble shooting

1. Can't login 192.168.188.1

icodestore.com/pages/enter-management_page-failed.

2. WPS setup failed

icodestore.com/pages/wps-connect-failed.

3. Extender expand failed

icodestore.com/pages/wireless-range-extenderexpand-fail.

4. No wi-fi signal

icodestore.com/pages/there-is-no-range-extender-wifisignal-after-i-plug-it.

5. No internet access, after setup successful

icodestore.com/pages/nointernet-access-after-successful-setup.

6. Internet slow down, after expand

icodestore.com/pages/network-slowsdown-after-connection.

7. Network weak or stuck

icodestore.com/pages/weak-networkconnection-or-stuck-after-linked

If you find that the content in the PDF is blocked, please contact us, thank you for your help. If you have other questions, please feel free to contact us, we will try our best to help you.

From: ICODE team

Documents / Resources

	ICODE WiFi Range Extender [pdf] Instructions ICODE, EX 300, WiFi Range Extender
---	--