



IDEAL HALO Changing Wi-fi Password or Router Instructions

[Home](#) » [IDEAL](#) » IDEAL HALO Changing Wi-fi Password or Router Instructions 



Contents

1 CHANGING WI-FI PASSWORD OR ROUTER

2 Documents / Resources

3 Related Posts

CHANGING WI-FI PASSWORD OR ROUTER


If you have changed your Wi-Fi password or changed broadband providers you will need to reconnect your Halo Smart Interface to re-establish the internet connection to the cloud and Halo app.

Follow these simple steps to reconnect your Halo device.

1. In the Halo App, navigate to the summary page




2. Select 'System Status & History'




3. Select 'Smart Interface'



4. Select 'Delete Device'



5. Select 'Delete'



6. Select 'Add Smart Interface' and follow the step-by-step instructions in the app



EXPERTS IN HEATING

Customer Service:

01482 498660

Technical Help:

01482 498663

Ideal Heating, PO Box 103, National Avenue,
Kingston upon Hull, East Yorkshire, HU5 4JN

E: enquiries@idealheating.com

ideal
HEATING

idealheating.com



Documents / Resources



[IDEAL HALO Changing Wi-fi Password or Router](#) [pdf] Instructions

IDEAL, HALO, Changing, Wi-fi, Password, or, Router