



ifi SupaNova User Guide

[Home](#) » [ifi](#) » ifi SupaNova User Guide 


ifi SupaNova User Guide



Contents

- [1 Overview](#)
- [2 Specifications](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

Overview



1. EC (male)

Plug into a wall outlet that supplies power to audio equipment, or plug into a power extension block that supplies power to audio equipment.

2. Polarity/Earth detection

The following table depicts the different readings and the respective LED colour combinations. Where needed, make the necessary system adjustments.

	Polarity (LED)	Earth (LED)	Status
1	Green	Green	Normal
2	Red	Green	Polarity error. Live and N eutral connections are re versed.
3	Red	Red	Ground error. Earth is mi ssing or faulty (e.g. resist ance too high).
4	Off	Off	Cut-out mode. Over volta ge or an electrical short.

Tips: Regardless of the LED colour, the SupaNova will always be actively cancelling noise.

3. Power outlet IEC

Connect to your device.

Specifications

- **Noise reduction:** > 40dB (> 100x)
- **Surge Protection:** max. 10,000A @ 775V / 8/20uS
- **Under operating voltage:** Maximum operating rating 10A at 250Vac and 15A at 125Vac
- **Dimensions:** 1.8 m (70.8")
- **Net weight:**
 - **USA:** 675 g (1.43 lbs)


- **EUR:** 695 g (1.47 lbs)
- **Warranty period:** 12 months

Specifications are subject to change without notice.

ifi-audio.com



Documents / Resources

	ifi SupaNova [pdf] User Guide SupaNova
---	---

References

- [ifi iFi audio | the Award-Winning Audio Technology Company](#)