

Contents [[hide](#)]

- [1 IFixit Nokia 3100b Removing Keypad](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 INTRODUCTION](#)
- [5 Frequently Asked Questions](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



IFIXIT Nokia 3100b Removing Keypad



Product Information

Specifications:

- **Product Model:** Nokia 3100b
- **Manufacturer:** Nokia
- **Part:** Keypad Replacement

Product Usage Instructions

Step 1: Battery Removal

Make sure your phone is turned off.

Step 2: Back Panel Removal

Press the button on the back of the phone and slide the back panel off. Remove the battery by pulling it from the phone.

Step 3: Removing Nokia 3100b Keypad

Push the black tabs down and pull the colored half of the phone from the white half.

Step 4: Front Part Removal

The front part of the phone is now removed. Ensure nothing was damaged while removing the front cover.

Step 5: Keypad Membrane Removal

- Remove the keypad membrane by pulling it from the front cover.
- To reassemble your device, follow these instructions in reverse order.

INTRODUCTION

The keypad inside the Nokia 3100b may eventually need replacement. This guide shows you how to access the keypad.

Step 1 — Battery

- Make sure your phone is turned off.



Step 2

- Press the button on the back of the phone and slide the back panel off.
- Remove the battery by pulling it from the phone.



Step 3 — Removing Nokia 3100b Keypad

- Push the black tabs down and pull the colored half of the phone from the white half.



Step 4

- The front part of the phone is now removed. Make sure nothing was damaged while removing the front cover.



Step 5

- Remove the keypad membrane by pulling it from the front cover.




To reassemble your device, follow these instructions in reverse order.

Frequently Asked Questions

How often should I replace the keypad?

The keypad may need replacement when keys become unresponsive or physically damaged. It is recommended to replace it as needed.

Documents / Resources

	IFIXIT Nokia 3100b Removing Keypad [pdf] Instruction Manual Nokia 3100b Removing Keypad, Removing Keypad, Keypad
---	---

References

- [User Manual](#)

IFIXIT, Keypad, Nokia 3100b Removing Keypad, Removing

IFIXIT Keypad

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.