



# iJOY JEBDCO1 Dynamic Earbuds with Charging Case User Manual

[Home](#) » [iJOY](#) » iJOY JEBDCO1 Dynamic Earbuds with Charging Case User Manual 

# iJOY

**EARBUDS WITH CHARGING CASE  
DYNAMIC**



**Model: IJEBDC01 IJEBDC02**  
**FCC ID: 2AJQ7DYNAMIC for use with**  
**USER MANUAL**



## **Contents**

- [\*\*1 FCC STATEMENT\*\*](#)
- [\*\*2 YOUR IJOY PRODUCT\*\*](#)
- [\*\*3 SPECS\*\*](#)
- [\*\*4 BATTERY CAUTION\*\*](#)
- [\*\*5 BATTERY DISPOSAL\*\*](#)
- [\*\*6 DEVICE FUNCTIONS\*\*](#)
- [\*\*7 OTHER IMPORTANT SAFETY INFORMATION\*\*](#)
- [\*\*8 INSTRUCTIONS\*\*](#)
- [\*\*9 LIMITED LIFETIME WARRANTY\*\*](#)
- [\*\*10 Documents / Resources\*\*](#)
- [\*\*11 Related Posts\*\*](#)

## **FCC STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed

and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

## **YOUR IJOY PRODUCT**

Thank you for purchasing and using the "IJOY DYNAMIC" wireless Blue-tooth® earbuds with case. This product can provide a high-quality listening experience for your mobile phone, computer, and other media devices. Before using this product, carefully read this manual to correctly operate this device. Please ask your local dealer if you have any questions.

DYNAMIC Bluetooth® Earbuds X 2

Charging Case X 1

Charging Cable X 1

User Manual X 1

## **SPECS**

Operating distance: 32 ft

Playtime: Up to 16 hours

## **BATTERY CAUTION**

The battery used in this device may present a risk of fire, explosion or chemical burn if used incorrectly. Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never disassemble the unit or attempt to remove the battery as that could cause leakage of alkaline solution or other electrolytic substances. Never expose the battery to any liquid. Never expose the battery to excessive heat such as direct light or fire. Always keep the battery out of the reach of infants and small children.

## **BATTERY DISPOSAL**

Please do not attempt to change the battery yourself. If the battery has died, you should follow the disposal instructions listed here. Never dispose of used batteries/electronics with ordinary solid wastes. Always dispose of used batteries/electronics in accordance with the prevailing community regulations that apply to the disposal of batteries/electronics. If there are no local regulations concerning battery/electronics disposal, please dispose of the device in a waste bin for electronic devices. Many electronics retailers now recycle batteries and other electronic components at no charge.

## **DEVICE FUNCTIONS**

### **CALL FUNCTION**

- Answering a call: Press either earbud once
- Ending a call: Press either earbud once
- Reject a call: Press either earbud 2 times
- Wake up intelligent voice assistant: Press either earbud 3 times

### **ADJUSTING VOLUME AND CONTROLLING MUSIC PLAYBACK**

- Play/Pause Music: Press either earbud once

- Decrease volume: Press left earbud twice
- Increase volume: Press right earbud twice
- Play previous song: Press and hold left earbud
- Play next song: Press and hold the right earbud

## OTHER IMPORTANT SAFETY INFORMATION

To avoid the danger of choking, please keep cables away from babies and children. This product is not a toy. Do not treat this product as household waste. Dispose of this device properly by handing it over to local collection services for recycling of electronic equipment. By ensuring that this product is properly disposed of, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling. For more detailed information about this product, please contact your local household waste disposal service or the shop where you purchased this item.



## INSTRUCTIONS

### POWERING ON/OFF

- The earbuds should automatically turn on when you remove them from the charging case. If they do not, press and hold either earbud for 5 seconds. The lights on the earbuds should turn on.
  - To turn the earbuds OFF, press either earbud for 5 seconds until the lights turn off or just put them inside the charging case.
- ### PAIRING YOUR PRODUCT
- Take the two earbuds out of the case. They should automatically power on and the left and right earbuds will enter pairing mode. If they do not, press and hold either earbud for 5 seconds. Place the earbuds within 32 ft of a Bluetooth® enabled device. Enable Blue-tooth® on the device you want to connect the earbuds to and search for “IJOY DYNAMIC”. Select “IJOY DYNAMIC” to connect. The earbuds will automatically connect to this same device next time both items are turned on.
- ### CHARGING
- The charging case offers additional power for the earbuds. There will be a voice indicator when the battery is low. When you put the earbuds inside the case to charge, the earbuds and case will light up. The light will turn off once charging the earbuds is complete. Use the charging cable provided to charge the charging case. Connect the cable to the port of the case. The light on the case will flash while charging and be consistent when the case finishes charging.

## LIMITED LIFETIME WARRANTY


Our product is warranted for a limited lifetime warranty from the date of purchase. The warranty is provided on all material defects and workmanship. A guarantee of 24 months does not apply to decreases in the effective capacity caused by its use or age. WE RESERVE THE RIGHT TO CHANGE TECHNICAL SPECIFICATIONS. For more information please visit, [www.goijoy.com](http://www.goijoy.com).

Distributed by Quest USA CORP 495 Flatbush Ave. Brooklyn, NY 11225

©GOIJOY & IJOY are registered trademarks of Quest USA Corp. All other trademarks and trade names are property of their respective owners. Designed by GOIJOY & IJOY in New York. All rights reserved Quest USA Corp. One (1) year limited warranty. To activate your product warranty go to our website [www.goijoy.com](http://www.goijoy.com) & register this product.

Made in China. **PLEASE FOLD ON THE GREEN LINES AND PRINT DOUBLE-SIDED. DO NOT PRINT GREEN LINES**

## Documents / Resources

	<a href="#">iJOY JEBDCO1 Dynamic Earbuds with Charging Case</a> [pdf] User Manual DYNAMIC, 2AJQ7DYNAMIC, JEBDCO1, JEBDCO2, JEBDCO1 Dynamic Earbuds with Charging Case, JEBDCO1, Dynamic Earbuds with Charging Case
---	---

[Manuals+](#)