

IKEA 302.387.03 UTRUSTA Electric Push Buttons Instructions

Home » Ikea » IKEA 302.387.03 UTRUSTA Electric Push Buttons Instructions



Contents

- 1 IKEA 302.387.03 UTRUSTA Electric Push
- **Buttons**
- **2 TOOLS REQUIRED**
- **3 INSTALLATION**
- **4 HOW TO OPERATE**
- **5 HOW TO FIXED**
- 6 Documents / Resources



IKEA 302.387.03 UTRUSTA Electric Push Buttons



Product Information


- Product Name: UTRUSTA
- Languages: English, Nederlands, Italiano, Polski, Latviesu,
- Lietuvi, Hrvatski, Srpski, Slovenscina, Bahasa Indonesia, Bahasa Malaysia
- Model Number: AA-596358-8

Product Usage Instructions


- 1. Before proceeding with installation, read the safety information in the User Manual.
- 2. Make sure to carefully follow the instructions provided in the User Manual for a safe and successful installation.
- 3. Refer to the specific language section in the User Manual that corresponds to your preferred language.
- 4. If you are unsure about any step or have questions regarding the installation process, consult the User Manual for guidance.
- 5. Ensure all necessary tools and materials are available before starting the installation.
- 6. If there are any warnings or important information mentioned in the User Manual, pay close attention and follow them accordingly.
- 7. Take necessary safety precautions while handling the product during installation.
- 8. If you encounter any difficulties or issues during the installation, contact customer support for assistance.


Warning! Before proceeding with installation, read the safety information in the User Manual.


TOOLS REQUIRED



INSTALLATION







Inter IKEA Systems B.V. 2012 2022-04-06 AA-596358-8

Documents / Resources



IKEA 302.387.03 UTRUSTA Electric Push Buttons [pdf] Instructions

302.387.03 UTRUSTA Electric Push Buttons, 302.387.03, UTRUSTA Electric Push Buttons, Electric Push Buttons, Push Buttons, Buttons

Manuals+,