



IKEA BRUNBAGE Work Lamp User Manual

[Home](#) » [Ikea](#) » IKEA BRUNBAGE Work Lamp User Manual 

IKEA BRUNBAGE Work Lamp User Manual





The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.


The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.






Contents


- [1 Instructions](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)


Instructions











Documents / Resources

BRUNBÅGE 	IKEA BRUNBAGE Work Lamp [pdf] User Manual AA-2331128-1, BRUNBAGE Work Lamp, BRUNBAGE, BRUNBAGE Lamp, Work Lamp, Lamp
--	---