




IKEA E1922 SYMFONISK WiFi Bookshelf Speaker Black/gen 2 User Guide

[Home](#) » [Ikea](#) » IKEA E1922 SYMFONISK WiFi Bookshelf Speaker Black/gen 2 User Guide 



SYMFONISK
Design and Quality
IKEA of Sweden





Quick guide

Plug in your SYMFONISK speaker. Go to the Apple App Store (iOS devices) or Google Play Store (Android devices) and search for Sonos.



Install and open the Sonos app. Follow the instructions to set up your SYMFONISK speaker.

If you already have a Sonos system:

Open the Sonos app and plug in your SYMFONISK speaker. In the app, select Settings (gear icon) > System > Add Product. Follow the instructions to set up your SYMFONISK speaker.

Contents

- 1 [Speaker functions](#)
- 2 [IMPORTANT & WARNING!](#)
- 3 [Documents / Resources](#)
 - 3.1 [References](#)
- 4 [Related Posts](#)

Speaker functions



Play/Pause. Press once to start or stop the music; twice to skip to the next track; three times to jump back one song. Press and hold to add the music playing in another room.
Status Light. Indicates the current status of the speaker.



Volume Up



Volume down

Additional information:

More instructions, for example on how to get started, can be found at www.ikea.com

- Select country.
- Go to Customer service > Product support.

You can also visit www.sonos.com > Support for instructions and support.

Care instructions

To clean the speaker, wipe with a soft moistened cloth Use another soft, dry cloth to wipe dry.

Model name:	SYMFONISK
Type number:	E1922
Operating temperatures:	0°C to 40°C
Input:	100-240VAC, 50/60Hz, 1.0A

Deactivating or activating the wireless port:

In the Sonos app, go to: Settings > System > select room > select product name > Select Disable/Enable Wi-Fi.

Network Mode	Network Standby* Power Consumption
Wired	<3 W
Wireless**	<3 W
*) Power consumption in “standby” is when audio playback is inactive. SYMFONISK is a device with Hina function. **) Wireless connectivity is automatically selected to optimize your Sonos / IKEA system. Whether in SonosNet (mesh mode), the power consumption is the same.	

For indoor use only

Manufacturer: IKEA of Sweden AB

Address: Box 702, SE-343 81 Almhult, SWEDEN

Save these instructions for future use.

IMPORTANT & WARNING!

- Too high a volume can damage your hearing.
- The speaker is for indoor use only and can be used in temperatures ranging from 0°C to 40 °C.
- Do not subject the speaker to wet, moist, or excessively dusty environments, as this may cause damage.
- Never use abrasive cleaners or chemical solvents as this can damage the product.
- Different building materials and the placement of the units can affect the wireless connectivity range.
- Never install the product in a confined space. Always leave a space around the product for ventilation.
- The product shall not be exposed to excessive heat such as sunshine, heat sources, and fire or similar.
- No open flame sources, such as candle lights should be placed on the apparatus
- Do not attempt to repair this product yourself, as opening or removing screwed covers may expose you to the risk of electric shock.

RF exposure information

According to RF exposure regulations, under normal operations, the end-user shall refrain from being closer than 20 cm from the device.




The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment.

For more information, please contact your IKEA store.



Complies with IMDA Standards
DA106634
Type Approved Safety Regular Production Surveillance
www.tuv.com
ID 0000057313
© Inter IKEA Systems B.V. 2021
AA-2324013-2

Documents / Resources

<p>SYMFONISK</p> 	<p>IKEA E1922 SYMFONISK WiFi Bookshelf Speaker Black/gen 2 [pdf] User Guide E1922 SYMFONISK, WiFi Bookshelf Speaker Black gen 2, E1922 SYMFONISK WiFi Bookshelf Speaker Black gen 2, WiFi Bookshelf, Speaker Black gen 2, SYMFONISK</p>
--	---

References

-  [Hej! Welcome to IKEA Global](#)
-  [Sonos | Wireless Speakers and Home Sound Systems](#)