



IKEA ENHET Shelf Insert Instruction Manual


[Home](#) » [Ikea](#) » **IKEA ENHET Shelf Insert Instruction Manual** 

Contents

- [1 IKEA ENHET Shelf Insert](#)
- [2 ENHET Product Information](#)
- [3 ENHET Product Usage Instructions](#)
- [4 ASSEMBLY INSTRUCTIONS](#)
- [5 TOOLS](#)
- [6 Documents / Resources](#)

IKEA

IKEA ENHET Shelf Insert



ENHET Product Information

The ENHET is a furniture piece that requires permanent fixing to the wall or floor to prevent tipping over, which can cause serious or fatal injuries. The product does not include fixing devices for the wall or floor, as different wall materials require different types of fixing devices. Suitable fixing devices for the walls and floors in your home can be obtained from your local specialized dealer.

The product comes with safety recommendations, which include placing the heaviest items in the lowest drawers and preventing children from climbing or hanging on the drawers, doors, or shelves.

ENHET Product Usage Instructions

1. Choose a suitable location for your ENHET furniture piece, ensuring that it is close to a wall or floor that it can be permanently fixed to.
2. Obtain suitable fixing devices for the walls and floors in your home from your local specialized dealer. For advice on suitable fixing systems, contact your local specialized dealer.
3. Assemble your ENHET furniture piece according to the instructions provided in the product manual.
4. Place the heaviest items in the lowest drawers of the furniture piece.
5. Prevent children from climbing or hanging on the drawers, doors, or shelves of the furniture piece.
6. Fix the ENHET furniture piece permanently to the wall or floor using suitable fixing devices.

Important information

Read carefully. Keep this information for further reference.





Serious or fatal crushing injuries can occur from furniture tip-over. To prevent this furniture from tipping over it must be permanently fixed to the wall/floor.


Fixing devices for the wall/floor are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls/floors in your home. For advice on suitable fixing systems, contact your local specialized dealer.

Safety recommendation:

- Place heaviest items in the lowest drawers.
- Prevent children from climbing or hanging on the drawers, doors or shelves.

ASSEMBLY INSTRUCTIONS







8x




4x




4x



2x




1x



1x




4x




4x

TOOLS


1




2





3







4







7










8







9





10




i







12




13




14




15







16




17










© Inter IKEA Systems
B.V. 2019 2022-12-01 AA-2191754-6

Documents / Resources

ENHET



ENHET

[IKEA ENHET Shelf Insert](#) [pdf] Instruction Manual
ENHET, ENHET Shelf Insert, Shelf Insert