

Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs



Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs Instruction Manual

[Home](#) » [Outsunny](#) » Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs Instruction Manual 

Contents

- [1 Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQs](#)
- [5 INTRODUCTION](#)
- [6 IMPORTANT SAFETY INSTRUCTION](#)
- [7 Precautions before assembly](#)
- [8 Maintenance](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs



Product Information

- **Specifications:**
 - **Model:** IN230900421V01_GL
 - **Product Code:** 863-055
 - **Colour:** Black
 - **Material:** Plastic
 - **Dimensions:** 10 x 5 x 3 inches
 - **Weight:** 1.5 lbs

Product Usage Instructions

- **Unboxing and Setup:**
 - When you receive the product, carefully unbox it and remove all packaging materials.
 - Ensure all parts are included as per the user manual. Place the product on a flat, stable surface.
- **Powering On:**
 - Connect the product to a power source using the provided cable. Press the power button located on the side of the product to turn it on. Wait for the device to boot up completely.
- **Functionality:**
 - Follow the user manual to understand the different functions of the product. Familiarize yourself with the buttons and controls for optimal usage.
- **Maintenance:**
 - Regularly clean the product with a soft, dry cloth to remove dust and debris. Avoid using harsh chemicals or solvents that may damage the surface of the product.
- **Storage:**
 - When not in use, store the product in a cool, dry place away from direct sunlight and moisture. Use the original packaging or a protective case to prevent damage during storage.

FAQs

- **Q: How do I reset the product to factory settings?**

- **A:** To reset the product, locate the reset button at the back of the device. Press and hold the reset button for 10 seconds until you see the reset confirmation on the screen.
- **Q: Can I use third-party accessories with this product?**
 - **A:** It is recommended to use only manufacturer-approved accessories to ensure compatibility and safety. The use of third-party accessories may void the warranty.

INTRODUCTION

- IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

Dear customer,

- Thank you for purchasing this product. So that your appliance serves you well, please read all the instructions in this user's manual.
- If you have any questions, please contact our customer care centre.

Our contact details are below:

Country	Phone	Email
UK	0044- 800-240-4004	enquiries@mhstar.co.uk
DE	0049-0(40)-88307530	service@aosom.de
FR	0033-1-84166106	aosom@mhfrance.fr
ES	0034-931294512	atencioncliente@aosom.es
PT	0034-931294512	info@aosom.pt
IT	0039-02494 71447	clienti@aosom.it
us	001- 877-644-9366	customerservice@aosom.com
CA	416-792-6088	customerservice@aosom.ca

IMPORTANT SAFETY INSTRUCTION

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

Only for camping use Use tips:

- Put the chair stably on a flat floor.
- Mount the garden chairs in the shelter of the weather.
- Stay away from open flames.
- Don't hang anything in the structure.
- Avoid the overload at the anchors/structure.
- It is advised that don't stay on the chairs when there is a storm.
- Do not use in adverse weather conditions and cover furniture when not in use.

Precautions before assembly

- Prepare a clean and dry mounting area.
- Verify that the product is not damaged.
- Check that none of the pieces are missing.

Maintenance

- Clean with a soft fabric.
- Regularly remove leaves and/or water collected on the canvas.
- Check the chair regularly.

Storage conditions:

- The fabric should be stored completely dry, and in a clean and dry place to avoid the risks of mould.

Maintenance:

- Don't use this product if the seat cloths, cloth cushions or tarpaulins are aging, and contact our customer service.
- Caution with the risks of pinching or cuts during assembly.
- The manufacturer declines all responsibility in case of damages due to a bad installation or due to weather.

IMPORTER:

- Imported by Aosom LLC
- 271 5 0 SW Kinsman Rd Wilsonville, O R 97070 USA
- MADE IN CHINA

IMPORTER:

- MH STAR UK LT D
- Unit 27, Perivale Park, Horsenden Lane South
- Perivale, UB6 3RH
- MADE IN CHINA

IMPORTADOR:

- SPANISH AOSOM, S.L.
- C/ ROC GROS, N° 15. 08550, ELS HOSTALET DE
- BALENYÀ, SPAIN.
- B66295775
- WWW.AOSOM.ES.
- ATENCIONCLIENTE@AOSOM.ES.

- **TEL:** 931294512
- HECHO EN CHINA
- SPANISH AOSOM, S.L
- C.ROC GROS N.15, 08550. ELS HOSTALET DE BALENYÀ
- **TEL:** 931294512 (SEG-SEX DAS 7:30H ÀS 16:30H)
- INFO@AOSOM.PT.
- WWW.AOSOM.PT.

Documents / Resources



[Outsunny 863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs](#) [pdf] Instruction Manual

863-055 3 Pieces Patio Bistro Set Folding Round Table and Chairs, 863-055, 3 Pieces Patio Bistro Set Folding Round Table and Chairs, Patio Bistro Set Folding Round Table and Chairs, Bistro Set Folding Round Table and Chairs, Set Folding Round Table and Chairs, Folding Round Table and Chairs, Round Table and Chairs, Table and Chairs, Chairs

References

- [User Manual](#)

[Manuals](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.