

IKEA SYMFONISK Floor Lamp with WiFi Speaker Instruction Manual


[Home](#) » [Ikea](#) » IKEA SYMFONISK Floor Lamp with WiFi Speaker Instruction Manual 

Contents

- [1 IKEA SYMFONISK Floor Lamp with WiFi Speaker](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 BOX CONTENT](#)
- [6 ASSEMBLING INSTRUCTION](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



IKEA SYMFONISK Floor Lamp with WiFi Speaker



Product Information

Specifications

- **Model:** SYMFONISK
- **Manufacturer:** IKEA
- **Product Code:** 10097844
- **Power Source:** Electric
- **Warranty:** Contact IKEA for details

Product Usage Instructions

- **Safety Precautions:**

Always ensure that the external flexible cable is not damaged. In case of damage, contact the manufacturer or a qualified service agent for replacement to avoid hazards.

- **Installation:**

Follow the provided installation guide to set up the product securely.

- **Operation:**

Connect the product to a power source as instructed in the manual. Use the designated controls to operate the product effectively.

- **Maintenance:**

Regularly check the product for any signs of wear or damage. Clean the product using a soft, dry cloth.

FAQ

- **What should I do if the external cable is damaged?**

If the external cable is damaged, it should be replaced by the manufacturer, a qualified service agent, or a

similar professional to avoid any risks. Contact IKEA for assistance.

- **How do I clean the product?**

Use a soft, dry cloth to clean the product. Avoid using harsh chemicals or abrasive materials that may damage the surface.


- **Can I use this product outdoors?**

This product is designed for indoor use only and should not be exposed to outdoor elements.


WARNING

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard. If you are uncertain, please contact IKEA.


BOX CONTENT




ASSEMBLING INSTRUCTION




2




3






4




5









9




10





13



i



Get it on Google Play





SONOS



Get it on the App Store




SONOS

i





<p>SYMFONISK</p> 	<p>IKEA SYMFONISK Floor Lamp with WiFi Speaker [pdf] Instruction Manual SYMFONISK Floor Lamp with WiFi Speaker, SYMFONISK, Floor Lamp with WiFi Speaker, WiFi Speaker</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.