




IKEA SYMFONISK Speaker lamp with WiFi Instruction Manual

[Home](#) » [Ikea](#) » **IKEA SYMFONISK Speaker lamp with WiFi Instruction Manual** 



Design and Quality
IKEA of Sweden

SYMFONISK



Contents

[1 IMPORTANT SAFETY INSTRUCTIONS](#)

[2 Documents / Resources](#)

[3 Related Posts](#)



IMPORTANT SAFETY INSTRUCTIONS


This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat the safety purpose of the polarized attachment plug. Do not alter the plug.

CAUTION:


TO PREVENT ELECTRICAL SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

WARNING


Deviation from the assembly instructions may result in a risk of fire or electric shock.



- 10042056
- 147796






- 10043260
- 10043238




- 10043241
- 10043239
- 10043257
- 10043258







- 194947
- 194948
- 197950
- 194937
- 194938
- 194940



4





5



© Inter IKEA Systems B.V. 2018
2020-02-04
AA-2135664-3

SYMFONISK



[IKEA SYMFONISK Speaker lamp with WiFi](#) [pdf] Instruction Manual
SYMFONISK, Speaker lamp with WiFi