

IKEA TRETAKT Smart Plug With Remote Control User Manual

Home » Ikea » IKEA TRETAKT Smart Plug With Remote Control User Manual

IKEA TRETAKT Smart Plug With Remote Control



Contents

- 1 Introduction
- 2 Pairing A Steering Device To Your Smart

Plug

- 3 Getting Started With DIRIGERA Hub
- 4 Good To Know
- **5 Get To Know Your Tretakt Product**
- **6 Product Servicing**
- 7 Changing The Battery
- **8 Factory Reset**
- 9 Technical Data TRETAKT
- **10 Care Instructions**
- 11 Technical Data RODRET
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

Introduction

RODRET steering device can be used to control your TRETAKT smart plug. If you own the DIRIGERA hub, you can control the TRETAKT smart plug via the IKEA Home smart app.

Pairing A Steering Device To Your Smart Plug

When the smart plug is sold together with a remote (in the same package), they are already paired. To add more smart plugs, just repeat the steps below:

- 1. Make sure that your smart plug is plugged in and the main power is turned on.
- 2. Hold the steering device close to the smart plug you want to add (no more than 5 cm away).
- 3. Press and hold the pairing button for at least 10 seconds. A red LED will steadily shine on the steering device. On your smart plug a white light will begin to dim and flash one time to indicate that it has been successfully paired.

Getting Started With DIRIGERA Hub

Download the IKEA Home smart app and follow the instructions on screen to add the smart plug to your IKEA Home smart system.

IKEA Home smart app

For Apple devices, download the app using the App Store. For Android devices, download the app using Google Play store.



Good To Know

Without DIRIGERA, you can connect a maximum of 10 smart products to one dimmer/switch. Remember to add one product at a time. If your products are close together, disconnect the ones you have already connected while adding the next product.

Get To Know Your Tretakt Product

- Press the On/Off button on the smart plug once to turn it on. Press it once again to turn it off.
- When using a remote: Press the On button () to turn the smart plug on. Press the Off button (O) to turn the smart plug off.

Factory reset your smart plug:

Push the reset button on top of the smart plug with a pointy object for at least 5 seconds until the LED starts pulsating.

IMPORTANT!

- The Smart plug is for indoor use only and can be used in temperatures from 0°C to 35°C.
- Do not leave the Smart plug in direct sunlight or near any heat source, as it may overheat.
- Do not subject the Smart plug to wet, moist or excessively dusty environments as this may cause damage.
- The range between the steering device and the receiver are measured in open air. Different building materials and placement of the units can affect the wireless connectivity range.

WARNING

- Do not connect after each other in sequence.
- Do not cover when in use.
- To disconnect the power, pull the plug.
- Use only indoors in dry areas.
- Do not overload the product.
- Discard the product if damaged.
- For adult use only. This is not a toy and is not intended for use by children.

Product Servicing

Do not attempt to repair this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks.

Get to know your RODRET product



Pairing button

- Press to turn on, or long-press to increase brightness.
- O Press to turn off, or long-press to decrease brightness.

Changing The Battery

A red LED light will blink when you press any button the dimmer/power switch to show that a new battery is needed. Open the battery lid and replace with a new AAA/ HR03 battery. We recommend using a LADDA rechargeable battery. Please note it is sold separately.

Factory Reset

To reset and remove all connected products, quick-press the pairing button 4 times (within 5 seconds). Follow steps 1-3 to reconnect your smart products.

IMPORTANT!

- The steering device is for indoor use only and can be used in temperatures ranging from 0° C to 40 °C.
- Do not leave the steering device in direct sunlight or near any heat source, as it may overheat.
- Different building materials and placement of the units can affect the wireless connectivity range.

WARNING!

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Technical Data TRETAKT

Model: TRETAKT plug smart

Type: E2240

Input: 220-240 V, 50/60 Hz Max output power: 3120 W Range: 10 m in open air. For indoor use only

Operating frequency: 2405-2480 MHz

Output power: 10 dBm

Care Instructions

To clean the product, wipe it with a soft cloth moistened with a little mild detergent. Use another soft, dry cloth to wipe dry. Never use abrasive cleaners or chemical solvents as this can damage the product.

Technical Data RODRET

Model: RODRET wireless dimmer

Type: E2201

Input: 1.2 V, 1x AAA/HR03 LADDA battery

Range: 10 m in open air. For indoor use only

Operating frequency: 2405-2480 MHz

Output power: 3 dBm (EIRP)

IP-class: IP44

Save these instructions for future use. Manufacturer: IKEA of Sweden AB

Address: Box 702, SE-343 81 Älmhult, SWEDEN

The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal. By separating a marked item from household waste, you will help reduce the volume of waste sent to incinerators or land-fill and minimize any potential negative impact on human health and the environment. For more information, please contact your IKEA store.



Documents / Resources

TRETAKT

IKEA TRETAKT Smart Plug With Remote Control [pdf] User Manual



TRETAKT Smart Plug With Remote Control, TRETAKT, Smart Plug With Remote Control, Plug With Remote Control, Remote Control, Smart Plug, Plug

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.