





IKEA UTRUSTA Wall Attachment Device User Manual

Home » Ikea » IKEA UTRUSTA Wall Attachment Device User Manual

Contents

- 1 IKEA UTRUSTA Wall Attachment
- **Device**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Usage
- 5 FAQ
- **6 Tools Required**
- 7 Parts
- **8 Installation Instructions**
- 9 Documents / Resources
 - 9.1 References
- **10 Related Posts**



IKEA UTRUSTA Wall Attachment Device



Product Information

Specifications

- Product Name: UTRUSTA
- Languages: English, Deutsch, Nederlands, Dansk, Norsk, Suomi, Svenska, Cesky, Italiano, Magyar, Polski, Eesti, Latviesu, Lietuvi, SPJIMAS, Portugues, ADVERTISEMENT, Slovensky, Hrvatski
- Warning: Serious or fatal crushing injuries can occur from furniture tip-over. Must be used with the wall attachment device(s) provided.

Product Usage Instructions

- Ensure the furniture is placed where you want it to be finally positioned.
- Attach the wall attachment device(s) provided securely to the furniture.
- Locate a suitable position on the wall to attach the furniture.
- Use appropriate screws and plugs suitable for your walls to fix the furniture securely in place.
- Double-check the stability of the furniture after installation.

Usage

- Once the UTRUSTA furniture is securely attached to the wall following the installation instructions, you can safely use it for its intended purpose.
- · Avoid placing heavy items on unstable surfaces.

FAQ

- Q: Are screws and plugs included for wall attachment?
- A: No, screws and plugs for the wall are not included. It is recommended to use screws and plugs suitable for


your walls. If unsure, seek professional advice.

WARNING!


Serious or fatal crushing injuries can occur from furniture tip-over. To prevent tip over this furniture must be used with the wall attachment device(s) provided.

Screw(s) and plug(s) for the wall are not included. Use screw(s) and plug(s) suitable for your walls. If you are uncertain, seek professional advice. Read and follow each step of the instructions carefully.


Tools Required




Info





Parts








Installation Instructions









































































© Inter IKEA Systems B.V. 2024 2024-06-19 AA-2511924-2

Documents / Resources



References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.