



IMachine A2 Smart Desktop Terminal User Manual

[Home](#) » [IMachine](#) » IMachine A2 Smart Desktop Terminal User Manual 

IMachine A2 Smart Desktop Terminal User Manual



Contents

- 1 Safety Warning**
- 2 Package Content**
- 3 Product Introduction**
- 4 Installation**
- 5 Statement**
- 6 Warranty**
- 7 Documents / Resources**
 - 7.1 References**
- 8 Related Posts**


Safety Warning

1. Please read the instructions carefully before using the product to ensure proper and safe use
2. Please use the accessories approved by the manufacturer and matched with this model of device, the use of power supply not approved by the manufacturer may cause fire, explosion or other hazards.
3. Please use the device under the specified operating temperatures, when the ambient temperature is too high or too low, it may cause equipment failure.
4. Please do not disassemble the product or its accessories by yourself, if the device or any of its parts do not work properly, you should promptly consult our after-sales service, or send it to the after-sales service network for testing and repair
5. Please unplug the power adapter and stop using it immediately if it is found abnormalities such as odor, overheating, discoloration, deformation, etc during use or storage.
6. Please do not install or use during lightning, otherwise there will be the risk of lightning strike.
7. Using the machine with potential explosive gas is strictly prohibited.

Package Content

- Device*1
- Power Adapter*1
- User Manual*1

Product Introduction

**Power on**

Under shut down state, short press then it would start up.

Shutdown

Windows system device in the boot state click the WIN icon, then click the power button to shutdown.

Reboot

Windows system device in the boot state click the WIN icon, then click the power button to reboot.

Screen off

Under the the normal working state, tap the power button then screen will be turned off.

Hibernate

Under the the normal working state, setting the system to hibernate.


Wake up

Under the the hibernation state, light press on the power button then the device will wake up.


Forced shutdown

Forced shutdown: Under the power-on state, long press the power button for 8 seconds+, the device forced to shut down.

Note: The interface of different platform configurations vary slightly, the above picture is for reference only, subject to the physical



Installation



Power cable, peripherals and communication cable connection

1. Insert the interface of the standard power adapter into the power port, the other end into the AC power socket.
2. Connect the peripheral, network, USB, serial, etc. to the corresponding interface according to the actual demand.

Statement

1. The operating system only supports official upgrades, and users are responsible for any security risks and losses caused by brushing into unofficial systems on their own.
2. The users are responsible for any loss caused by the use and maintenance beyond of this guide or using accessories purchased through unofficial channels.
3. The contents of this manual are subject to amend without prior notice, and the specific configuration shall prevail in kind.

Warranty

Welcome to use the smart terminal series products. Under normal use of the products you have purchased, the company is responsible for free maintenance within one year from the date of purchase for any quality problems caused by raw materials or the production process. Where the damage is caused by the user's own installation, disassembly or incorrect use without following the requirements of this operation guide, the company can provide maintenance, but charge for the corresponding service and parts.

1. Under normal circumstances, the host warranty period is 12 months (three months for spare parts), (the specific circumstances of the sales contract shall prevail).
2. During the warranty period, under normal use (as determined by the company's technical staff), the warranty parts of the damage or failure free of charge.
3. During the warranty period, the equipment that breaks down can be sent to our maintenance point for repair, and the shipping cost will be borne by the sender.
4. During the warranty period, the product has been repaired, disassembled or changed by maintenance personnel outside our company, or the failure caused by improper installation, improper use, broken serial number, accidental events or natural disasters is not covered by the warranty.
5. Please show the equipment SN and proof of purchase when repairing, our company reserves the right to explain the above.

6. FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a

particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help


Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator&your body

Documents / Resources

	<p>IMachine A2 Smart Desktop Terminal [pdf] User Manual A2 Smart Desktop Terminal, A2, Smart Desktop Terminal, Desktop Terminal, Terminal</p>
---	---

References

- [User Manual](#)