

**IMAX**

**08930L Led  
Table Lamp  
Kingfisher**



## Immax 08930L Led Table Lamp Kingfisher Instruction Manual

[Home](#) » [immax](#) » Immax 08930L Led Table Lamp Kingfisher Instruction Manual 

### Contents

- [1 Immax 08930L Led Table Lamp Kingfisher](#)
- [2 Technical specifications](#)
- [3 User manual](#)
- [4 Calendar and alarm settings](#)
- [5 Maintenance:](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

**IMAX**


**Immax 08930L Led Table Lamp Kingfisher**



## Technical specifications

- Color temperature: 3000K#300K 5500K#500K 4200K#400K
- CRI: > 80Ra
- Input voltage: DC12V/1A
- Material: ABS+ RUBBER
- Luminous flux: >450LM
- Power: 9W

## Battery replacement




## Lighting brightness adjustment




## User manual


- Insert the power connector into the power connector on the base of the lamp.



- USB connector: DC5V / 1A – this connector is intended only for mobile devices or accessories with a consumption lower than 5V / 1A.




- In this direction you can tilt the lamp within 90°
  - hold the base of the lamp




- You can adjust the position of the lamp head by 180 °

- Exceeding this range may damage the lamp arm



- You can control the lamp with these buttons



## Calendar and alarm settings



## Time and date settings

1. in normal mode, press the “set” button to access the setting mode, by pressing the “set” button again you can select from the following setting options: hours – minutes – year – month – day
2. press “up” or “down” to set the desired time, etc.
3. in setting mode, press the “mode” button or cancel the setting for a minute. The required setting is saved
4. in normal mode, press the “up” button to toggle between 12H and 24H time format

## Snooze settings

1. in normal mode, press the “mode” button to activate the alarm function
2. in alarm mode, press the “set” button to activate the alarm settings: hours – minutes – Snooze – music – exit
3. Press the “up” or “down” button to set the required information
4. in alarm mode, press the “up” or “down” button to turn the alarm and Snooze function on or off, press the button again to toggle between: alarm on – snooze on – alarm off – snooze off
5. The alarm will ring for one minute at the set time, then the snooze function will activate and the alarm will ring again. To turn off the alarm, press any key.

## Thermometer settings

in normal mode, press the “down” button to toggle between degrees Fahrenheit (F) or degrees Celsius (C).

## Notice:

- Do not disassemble the lamp, as this may cause injury electric current
- Use only the original AC adapter
- Do not use the lamp in high temperatures or humidity
- Do not look directly into the light source, as this may damage your eyesight
- do not use the lamp if:
  - the source cable is damaged
  - if the lamp is mechanically damaged or wet
  - if the lamp sparkles or smokes
  - the lamp flashes

## Environmental protection tips:

The symbol on the product or in the accompanying documentation means that used electrical and electronic products must not be disposed of with your other household waste. In order to dispose of the product properly, please return it to the designated collection points, where it will be accepted free of charge. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Penalties may be applicable for incorrect disposal of this waste in accordance with national regulations.

## Maintenance:

- Protect the device from contamination and contamination. Wipe the device with a soft cloth, do not use rough or coarse-grained material.
- DO NOT use solvents or other aggressive cleaners or chemicals.

A Declaration of Conformity has been issued for this product. More information can be found at [www.immax.cz](http://www.immax.cz)

## Manufacturer and importer

IMMAX, Pohorí 703, 742 85 Vresina, EU

[www.immax.cz](http://www.immax.cz)

Vyrobeno v P.R.C. / Hergestellt in P.R.C.

## Documents / Resources

	<p><a href="#">Immax 08930L Led Table Lamp Kingfisher</a> [pdf] Instruction Manual 08930L, 08934L, 08930L Led Table Lamp Kingfisher, 08930L, Led Table Lamp Kingfisher, Table Lamp Kingfisher, Lamp Kingfisher, Kingfisher</p>
---	--

## References

- [User Manual](#)

## **Manuals+. Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.