

immax NEO LITE Smart Indoor Socket With Pin User Manual

Home » immax » immax NEO LITE Smart Indoor Socket With Pin User Manual





Immax NEO LITE Smart indoor socket with pin

Contents

1 TECHNICAL

SPECIFICATIONS:

- **2 GETTING STARTED**
- **3 RESET THE SMART SOCKET**
- **4 SAFETY INFORMATION**
- **5 MAINTENANCE**
- 6 Documents / Resources
 - 6.1 References

TECHNICAL SPECIFICATIONS:

Color: white

Rated voltage: AC 230V ± 10%, 50/60 Hz

Maximum load: 3840W, 16A

Overcharge protection function: YES

2x USB + 1x USB C output: 5.0V 2.1A, Max10.5W

Overvoltage protection: 265V Mains standby power (Pnet): 1W

Zigbee repeater: YES Protocol: Zigbee

Frequency: 2400MHz~2483.5MHz

Maximum RF output power: Zigbee:10dBm - max 19dBm

Wireless distance: 30m (in open space)

Working temperature: 0°C ~ 40°C (32°F ~ 104°F)

Working humidity: 20% ~ 85%

Function in the app: ON / OFF, Timer, Countdown, Consumption measurement

Size: 7.6 cm x 5 cm x 7.6 cm

Weight: 116g

Package contents: Internal socket, user manual

The Immax NEO PRO smart gateway serves as a hub for communication between your mobile device and other smart devices communicating on the Zigbee 3.0 protocol.

Any other use is considered inappropriate. All claims arising from improper use or unauthorized modification of the product will be considered unauthorized. Any such use is at your own risk.



https://smartapp.tuya.com/immaxneosmart

PAIRING IMMAX NEO LED LIGHT SOURCES WITH THE IMMAX NEO APPLICATION ON MOBILE DEVICES **Note:**

You may encounter minor discrepancies in the Android and iOS versions of the application, such as slightly different commands or icons, but the principle of operation is the same. Firmware updates may result in changes to the functionality of the application.

- Connect the socket to the electrical network.
- 2. If the LED indicator on the socket is not flashing, press the On/Off button for at least 5 seconds.
- 3. Make sure that the LED indicator on the socket is flashing quickly.
- 4. Everything is ready for pairing.
- 5. Open the Immax NEO PRO application.
- 6. Click on the "Room" icon.
- 7. Click on the "+" icon to add a new device.
- 8. Select the Immax NEO category in the left column.
- 9. Select Smart Socket (zigbee) from the products offered
- 10. Select the smart gateway with which you want to pair this device (note: this is necessary if you have more than one Immax NEO PRO smart gateway).
- 11. Click on the "Next step" icon.
- 12. Confirm that the LED indicator is flashing quickly
- 13. Click on the "Next step" icon.
- 14. Wait until the device is properly paired with the Immax NEO PRO smart gateway.
- 15. Enter the device name.
- 16. Select the room where you want the device to be located.
- 17. Click "Done".

UNPAIRING A DEVICE FROM THE IMMAX NEO PRO SMART GATEWAY

- 1. Open the Immax NEO PRO app
- 2. Click the "Room" icon
- 3. Select the device you want to unpair
- 4. Click the "Settings" icon in the upper right corner
- 5. Click "Remove device"
- 6. Select one of the options
 - a) Disconnect removes the device from the Immax NEO PRO app, but the device information will remain stored in the Immax NEO cloud
 - b) Disconnect and clear data removes the device from the Immax NEO PRO app and from the Immax NEO cloud
- 7. Confirm device removal

RESET THE SMART SOCKET

- 1. Press the On/Off button for at least 5 seconds.
- 2. The LED indicator on the socket should flash quickly.

SAFETY INFORMATION

CAUTION: Keep out of reach of children. This product contains small parts that may cause choking or injury if swallowed.

WARNING: Each battery has the potential to release harmful chemicals that may damage skin, clothing, or the area where the battery is stored.

To avoid the risk of injury, do not allow any substance from the battery to come into contact with eyes or skin. Each

battery may rupture or even explode if exposed to fire or other forms of excessive heat. Use caution when handling batteries. To reduce the risk of injury or damage from battery mishandling, take the following precautions:

- Do not use different brands and types of batteries in the same device
- Always replace all batteries in the device when replacing batteries
- Do not use rechargeable or reusable batteries.
- Do not allow children to install batteries without supervision.
- Follow the battery manufacturer's instructions for proper battery handling and disposal.

WARNING: The product and batteries should be disposed of at a recycling center. Do not dispose of with normal household waste.

WARNING: To ensure safe use of the product, it is necessary to bring wires to the installation site in accordance with applicable regulations.

Installation must only be carried out by a person with the appropriate electrical certification. During installation or when a defect is detected, the power cable must always be disconnected from the socket (in the case of direct connection, the relevant circuit breaker must be switched off). Incorrect installation may result in damage to the product and injury.

WARNING: Do not disassemble the product, there is a risk of electric shock.

WARNING: Use only the original power adapter supplied with the product. Do not put the device into operation if the power cable shows signs of damage.

WARNING: Follow the instructions in the enclosed manual.

MAINTENANCE

Protect the device from contamination and dirt. Wipe the device with a soft cloth, do not use rough or coarse material.

DO NOT use solvents or other aggressive cleaners or chemicals.

A Declaration of Conformity has been issued for this product, more information can be found at www.immax.cz
ABRIDGED VERSION OF THE DECLARATION OF CONFORMITY

Hereby, the manufacturer IMMAX declares that the radio equipment type 07799L is in compliance with Directive 2014/53/EU.

The full text of the EU Declaration of Conformity is available on the following websites www.immax.cz, www.immax.eu

You can download the safety information for this product from www.immax.cz

If you have any questions or need advice, please contact us at podpora@immaxneo.cz.

NOTES

The symbol indicates that the product must not be disposed of with municipal waste. For proper disposal of the product, hand it in at designated collection points.

When disposing of the device, remove the batteries and bulbs – if possible.

Please dispose of your old appliance at designated collection points; it does not belong in municipal waste.

Waste electrical and electronic equipment from private households can be disposed of free of charge at public collection points

As the end user, you are responsible for erasing personal data from your old appliance

ASEKOL: AK-016010, WEEE-Reg.-№ DE 88927148



Smart home devices

Manufacturer and importer:

IMMAX, Teslova 1179/2, 702 00 Ostrava, EU

www.immaxneo.cz

Made in P.R.C.

Λ Λ













Documents / Resources



immax NEO LITE Smart Indoor Socket With Pin [pdf] User Manual

NEO LITE Smart Indoor Socket With Pin, NEO LITE, Smart Indoor Socket With Pin, Indoor Socket With Pin, Socket With Pin, With Pin

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.