

# imou Bullet WiFi Camera User Guide

Home » imou » imou Bullet WiFi Camera User Guide

#### Contents [ hide

- 1 imou Bullet WiFi Camera
- 2 Package content
- 3 Camera introduction
- **4 Trouble Shooting**
- **5 Documents / Resources** 
  - 5.1 References
- **6 Related Posts**



imou Bullet WiFi Camera



#### Welcome

Thank you for choosing IMOU.


We are devoted to providing you easy smart home products.

If you have problems using the product, please contact our service team before returning your product.


Our service mail: <a href="mailto:service.global@imoulife.com">service.global@imoulife.com</a>


Frequently asked questions can be found at imoulife.com/support/help

## Package content



#### **Camera introduction**






Note: Press and hold the Reset button for 10 s to reset the camera.

The pattern of the LED indicator is included in the following table.

LED Status	Device Status
Off	Powered off/LED turned off Rebooting after reset
Red light on	Booting Device malfunction
Green light flashing	Waiting for network
Green light on	Operating properly
Red light flashing	Network connection failed
Green and red light flashing alternatel y	Firmware updating

















# (i) Tips



To ensure the best possible wireless performance, please make sure there are no obstacles and electromagnetic interference between the camera and router.



**Trouble Shooting** 

Problem	Solution
Cannot set up camera	<ul> <li>Ensure your mobile device and the camera are within range of your Wi-Fi router.</li> <li>Ensure the LED indicator on the camera isflashing green before beginning setup.</li> </ul>
The APP says "Failed to configure device network"	<ul> <li>Reset your Camera and connect it again.</li> <li>Some cameras only support 2.4GHz, while some routers have dual band, 2.4G/5G. Make sure you are connecting 2.4GHz only.</li> </ul>
The app says "Failed to bind"	The camera is already connected to Wi-Fi, but the router is:  Not connected to Internet  Poor network status  The Wi-Fi signal is not stable due to obstacles or electronic interference
No picture / signal	<ul> <li>Ensure the LED indicator on the camera is flashing steady green. See 'LED Status' section for details if otherwise.</li> <li>Ensure the camera is properly connected to power using the included USB power adapter.</li> <li>Try repositioning the camera, router, or both to improve signal strength.</li> </ul>
Picture is not clear	<ul> <li>Check the camera lens for dirt, dust, spider webs. Clean the lens with a soft, clean cloth.</li> <li>Remove the vinyl cover on the camera lens.</li> </ul>
No audio	Ensure audio function on camera is turned on.     Ensure audio is turned up on viewing device.
Phone is not reading QR code	<ul> <li>Clean the camera lens of your Smartphone</li> <li>Ensure that there is enough light on the QR code</li> <li>Don't hold the QR code too close to the camera</li> </ul>



#### **Documents / Resources**



<u>imou Bullet WiFi Camera</u> [pdf] User Guide Bullet WiFi Camera

### References

- Imou | Enjoy Smart Life
- Support
- Imou | Enjoy Smart Life

Manuals+, home privacy