


IMOU IPC-C26EP LOOC 2MP Bullet WiFi Camera User Guide

Home » imou » IMOU IPC-C26EP LOOC 2MP Bullet WiFi Camera User Guide 🖫

IMOU IPC-C26EP LOOC 2MP Bullet WiFi Camera



Contents

- 1 Welcome
- 2 Package content
- 3 Camera introduction
- 4 Troubleshooting
- 5 Documents /

Resources

- **5.1 References**
- **6 Related Posts**

Welcome

Thank you for choosing IMOU.


We are devoted to providing you easy smart home products. If you have problems using the product, please contact our service team before returning your product.

Our service mail: service.global@imoulife.com


Frequently asked questions can be found at imoulife.com/support/help



Package content



Camera introduction




Note: The top cap can be opened with the pry bar from the accessory kit.

Press the Reset Button for 10 seconds to reset the camera.


The pattern of the LED indicator is included in the following table.

LED Indicator Status	Device Status
Red light on	Booting Device malfunction
Green light flashing	Waiting for network
Green light on	Operating properly
Red light flashing	Network connection failed
Light of	Powered off/LED turned off Rebooting after reset
Green and red light flashing alternately	Firmware updating












To ensure the best possible wireless performance, please make sure there are no obstacles and electromagnetic interference between the camera and router.







Troubleshooting

Problem	Solution
Cannot set up camera	 Ensure your mobile device and the camera are within range of your Wi-Fi route r. Ensure the LED indicator on the camera isflashing green before beginning setu p.
The APP says "Failed to co nfigure device network"	 Reset your Camera and connect it again. Some cameras only support 2.4GHz, while some routers have dual band, 2.4G/5G. Make sure you are connecting 2.4GHz only.
The app says "Failed to bin d"	The camera is already connected to Wi-Fi, but the router is: Not connected to Interne Poor network status The Wi-Fi signal is not stable due to obstacles or electronic interference
No picture / signal	 Ensure the LED indicator on the camera is flashing steady green. See 'LED St atus' section for details if otherwise. Ensure the camera is properly connected to power using the included USB power adapter. Try repositioning the camera, router, or both to improve signal strength.
Picture is not clear	 Check the camera lens for dirt, dust, spider webs. Clean the lens with a soft, clean cloth. Remove the vinyl cover on the camera lens.
No audio	Ensure audio function on camera is turned on Ensure audio is turned up on viewing device.
Human detection not worki	Ensure you have enabled "Human Detection" in the Device Settings screen of t he Imou LifeApp.
Camera stuck downwards	Turn off Camera Shielding in Device Settings on the Imou Life app.

Phone is not reading QR c ode

- Clean the camera lens of your Smartphone
- Ensure that there is enough light on the QR code
- Don't hold the QR code too close to the camera

@imouglobal | E service.global@imoulife.com | W www.imoulife.com



Documents / Resources



IMOU IPC-C26EP LOOC 2MP Bullet WiFi Camera [pdf] User Guide IPC-C26EP, LOOC 2MP Bullet WiFi Camera, 2MP Bullet WiFi Camera, Bullet WiFi Camera, WiFi Camera, Camera

References

- Imou | Enjoy Smart Life
- Support
- mou | Enjoy Smart Life

Manuals+, home privacy