

impact CSR-F Folding Wall/Door Rack for C Stands Instruction Manual

Home » Impact » impact CSR-F Folding Wall/Door Rack for C Stands Instruction Manual



CSR-F Folding Wall/Door Rack for C-Stands



INSTRUCTIONS

Contents

- 1 Introduction
- 2 Precautions
- 3 Setup
- **4 Specifications**
- 5 One-Year Limited

Warranty

- 6 Documents / Resources
 - **6.1 References**

Introduction

Thank you for choosing Impact.

Impact's Folding C-Stand Wall Mount system is ideal for studios, rental houses, and grip trucks where floor space is tight. The two sturdy steel brackets boast a 150 lb. load capacity, and they are designed to hold up to six C-stands. The base and top brackets can be attached to any flat surface, like a wall or door, and they can be configured to fit any size C-stand. When the brackets are not in use, they conveniently fold up and out of the way for a clutter-free workspace.

Precautions 4



- Please read and follow these instructions, and keep this manual in a safe place.
- Do not use this product for any device other than what it is intended for. The exact specifications, size parameters, and weight limits are found both on the product box and in the instruction manual.
- Impact takes no responsibility for any product damage or personal injury resulting from mishandling, incorrect mounting, faulty assembly, or improper use of this product.
- When installing this product, be sure to refer to the mounting instructions detailed in this manual. Failure to abide by the mounting instructions may void the product warranty.
- · Clean the unit with only a soft, dry cloth.
- Do not exceed the maximum load capacity.
- · All images are for illustrative purposes only.

Setup

Before You Start

Multiple kits and C-stands can easily weigh over 100 pounds, and the rack will be under constant stress as you load and unload your C-stands. Mounting the stand to a solid surface such as wood, wood-backed sheet rock, or concrete and masonry with the correct anchors is recommended.

Mounting the base and top to sheetrock is possible, but only with specialty anchors or toggle bolts. Consult a qualified contractor for proper installation.

Attaching the Brackets

1. Loosen the wing nut, fold the base down so it's perpendicular to the wall and tighten the wing nut.



2. Set the base at the desired height, and use a torpedo level to ensure the base is horizontal so the stands will have a level surface to rest on. Use the base as a template to mark the location of the holes in the surface.



3. Attach the base to the surface with 5/16 (M8) screws, and make sure it's solidly attached, without wobbling or movement.




- 4. Place a C-stand on the base.
- 5. Place the riser into the channel of the top bracket. Raise the top bracket until the brake castings are sitting on the left side of the channel, and mark one of the holes on the surface.





- 6. Install a screw on one side, and leave it loose so the top can rotate.
- 7. Remove the C-stand.

Place a level on the top edge of the top bracket, and mark the other hole.



When properly set up, the closed C-stand will rest on the base, and the riser locking knob will rest snugly on the top bracket.





When the brackets are not in use, they can fold flat against the wall or door.

Loosen the base's wing nut, fold it up to the wall, and tighten the wing nut to keep it in place.

The top bracket folds up or down and should have sufficient resistance when folding. If it's loose, use a 17 mm (11/16") wrench to tighten the bolts.



Specifications

	Base	Тор
Compatibility	C-stands	
Load Capacity	150 lb. (68 kg)	
Color	Black powder coat	
Construction Material	Steel	
Dimensions	3.5 × 10 × 21.1 in. (8.9 × 25.4 × 53.6 cm)	2 × 8.25 × 16 in. (5.1 × 21 × 40.6 cm)
Weight	8.28 lb. (3.7 kg)	4.16 lb. (1.9 kg)

One-Year Limited Warranty

This Impact product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise

authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit <u>www.impactstudiolighting.com</u> or call Customer Service at <u>212-594-2353</u>.

Product warranty provided by the Gradus Group.

www.gradusgroup.com

Impact is a registered trademark of the Gradus Group.

© 2024 Gradus Group LLC. All Rights Reserved.



Documents / Resources



<u>impact CSR-F Folding Wall/Door Rack for C Stands</u> [pdf] Instruction Manual CSR-F Folding Wall Door Rack for C Stands, CSR-F, Folding Wall Door Rack for C Stands, Wall Door Rack for C Stands, Door Rack for C Stands, Rack for C Stands, C Stands

References

- Gradus | Gradus Group
- i Impact | Quality Studio Lighting Equipment & Accessories
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.