**Manuals+** — User Manuals Simplified.



# IMPECCA ITAC08-LSA23 Air Conditioner Wi-Fi Function User Manual

Home » IMPECCA » IMPECCA ITAC08-LSA23 Air Conditioner Wi-Fi Function User Manual

IMPECCA ITAC08-LSA23 Air Conditioner Wi-Fi Function



This description is applied to Air Conditioners with Wi-Fi function. Please read the manual carefully before using the product and keep it for future reference.

#### **Contents**

- 1 Let's get start!
- 2 Wi-Fi Module specification and basic information
- 3 Download and Install the App
- **4 Activate APP**
- **5 Registration**
- 6 Login
- 7 Add device
- 8 Air conditioner control
- 9 Account management
- 10 Notice
- 11 Trouble Shooting
- 12 Documents / Resources
  - 12.1 References
- **13 Related Posts**

## Let's get start!

**Operation guideline.** Please take below simple guideline instruction as reference.

Operation Ste	Operation Items	New Account	Re-install APP (registered before)
Step 1	Download and Install APP	YES	YES
Step 2	Activate APP	YES	YES
Step 3	Registration Account	YES	NO
Step 4	Login	YES	YES
Step 5	Select Add Device / Window AC to control	YES	Registered Device will remain.
Step 6	Press ECO button on Remo te Control 6 times, the unit will display app, and connec t	YES	Registered Device will remain.

**Note** If you registered the account and added device before, when you re-install the APP again and login, the added device will remain .

#### FCC Caution (FCC ID: 2AJCLTWAC-TYWFS/2ANDL-WBR3)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Wi-Fi Module specification and basic information

1. Minimum specifications on a Smart phone:

Android 5.0 version or higher


IOS 9.0 version or higher

Wi-Fi Module specification and basic information

2. Basic parameters for Wi-Fi module

Parameters	Details
Network frequency	2.400 – 2.500GHz
Standards of WLAN	IEEE 802.11 b/g/n(channels 1-14)
Protocol stack support	IPv4/IPv6/TCP/UDP/HTTPS/TLS/Multicast DNS
Security support	WEP/WPA/WPA2/AES128
Network type support	STA/AP/STA+AP

# **Download and Install the App**



## For Android smart phone

Method1: Please scan the QR code with a browser scanner, download and install the APP. Method2: Open the Google "Play Store" on your smartphone and search "SmartLife-Smart Home", ownload and install the APP.



## For IOS smart phone

Method1: Please scan the QR code and follow the tips to get into "AppStore", download and install the APP.

**Method2:** Open the Apple "AppStore" on your smart phone and search "SmartLife-SmartHome", download and install the APP.





#### Note:

Please enable the permissions of Storage/Location/Camera for this APP when installing. Otherwise it will have some problems when operating.

#### **Activate APP**

The first time the app is used, it will need activating.


1. Launch the APP "SmartLife-SmartHome" on your smart phone.




SmartLife-SmartHome

2. Method1: Tap button "Scan" and scan the right Activate QR code

**Method2:** Tap "or Enter Activation Code" in bottom of the screen, then enter the activate code and tap "CONFIRM".




Activate QR code and activation code




Note Without the QR code or activation code, you can't active the APP and using it, please keep them safe.

# Registration

- 1. If you don't have any account please tap button "Register".
  - 1. Read the Privacy Policy and tap "Agree".







- 2. Tap">" and choose the country.
- 3. Enter your e-mail address.
- 4. Tap the button "Obtain verification code".

Search the country or slide the screen up/down to find and choose the Country.




- 5. Enter the verification code you received from e-mail.
- 6. Set the Password with 6-20 characters including characters and numbers.
- 7. Tap "Done".





## Login

- 1. Tap "Log in with existing account".
- 2. Enter your registered account and password.
- 3. Tap "Log in" button.



Login

\*\*\*\*\*\*

\*\*\*\*\*

enter your account(e-mail) here

enter the password


Log in


Forgot password

Login means that you agree with User Agreement and Privacy Policy

## The first time the APP is used, Create family is needed:

- 4. Tap "Create family".
- 5. Make name for the family.
- 6. Set the location.
- 7. Choose default rooms or add new rooms.
- 8. Tap "Done" and "Completed".








#### Note:


The app can open the map on your phone and you can set the location where you are.


## Forgot the password

If you forgot the password or you want to reset the password, operate as below:

- 1. Tap "Forgot password".
- 2. Enter your account(e-mail address) and tap button "Obtain verification code".
- 3. Enter the verification code received by your e-mail.
- 4. Set the new password and tap button "Done".










#### Add device

There are 2 modes CF(Quick connection) and AP(Access Point) for adding device.

#### **CF** mode


- 1. Power on the indoor unit, no need to launch the air conditioner.
- 2. Click "+" in the upper right corner of the "Home" screen or tap "Add device" on the room which has no device.
- 3. Tap the "Window Type Air conditioner" logo.
- 4. Input the password of the Wi-Fi which the same as your smart phone connected, then tap "Next".
- 5. Choose "CF Mode" on the right corner, then follow the instruction on page before or screen to reset the Wi-Fi module, then tap "Next".
- 6. You can see the percent rate of connecting process, at the same time PP", "SA", "AP" shining in turn on the indoor display.
  - "PP" means "Searching the router"
  - "SA" means "connected to the router"
  - "AP" means "connected to the server"




There are 2 methods to add the device.

#### 2-AP mode

- 1. Power on the indoor unit, no need to launch the air conditioner.
- 2. Click "+" in the upper right corner of the "Home" screen or tap "Add device" on the room which has no device.
- 3. Tap the "Window Type Air Conditioner" logo.
- 4. Input the password of the Wi-Fi which the same as your smart phone connected, then tap "Next".
- 5. Choose "AP Mode" on the right corner, then follow the instruction on page before or screen to reset the Wi-Fi module, then tap "Next".
- 6. Read the instruction carefully and tap "Connect now".
- 7. In the network setting screen, select "SmartLife-\*\*\*\*", and tap" ".
- 8. You can see the percent rate of connecting process, at the same time
  - "PP","SA","AP" shining in turn on the indoor display.
  - "PP" means "Searching the router"
  - "SA" means "connected to the router"
  - "AP" means "connected to the server"






## Air conditioner control

The device control screen will pop up automatically after adding the device.


The device control screen will pop up manually by tapping the device name on the home screen.



#### Note:

There are two different control forms base on different software or Wi-Fi module firmware. Please read the manual carefully base on the real control interface.

## **Control form1**




**Control form 2** 




## Control form1

The main control interface




## **Control form1-Mode setting**

- 1. Tap Mode to pop up the Mode screen.
- 2. Select one of the mode Feel/Cool/Heat/Dry/Fan.
- 3. Tap anywhere around the setting temperature to cancel the Mode setting.




## Control form1-Select fan speed

- 1. Tap Fan to pop up the Fan screen.
- 2. Select one of the fan speed High/med/Low/Auto.
- 3. Tap anywhere around the setting temperature to cancel the selection.




## **Control form1-Function setting**

- 1. Tap Function to pop up the Function screen.
- 2. Select one of the functions Sleep/Turbo/ECO.
- 3. Select UP-DOWN/LEFT-RIGHT for auto swing with direction of UP-DOWN/LEFT-RIGHT.
- 4. Tap anywhere around the setting temperature to cancel the Function setting.




## **Control form1-Timer adding**

- 1. Tap Timer to pop up the Add Timer screen.
- 2. Tap Add Timer.





- 3. Select the time, select the repeat days and Timer on/off.
- 4. Select the Mode/Fan speed/Function and select the setting temperature for Timer on.
- 5. Tap Save to add the timer.



## **Control form1-Timer Management**


- 1. Tap the bar of timer to edit the Timer like the Timer adding process.
- 2. Click the switch to enable or disable the Timer.
- 3. Holdind the bar of Timer about 3seconds and pop up the Remove Timer screen, tap CONFIRM and remove the Timer.






#### Control form2

The main control interface



- 1. Tap the Mode button.
- 2. There are 5 modes on the Mode screen, tap one button to set the Air conditioner working mode.
- 3. Tap the X button to back the main control screen.
- 4. The mode and background will change on the screen






# Control form2-Fan speed selection

- 1. Tap the Fan speed button.
- 2. Choose your desired fan speed and tap it.
- 3. Tap the X button to back the main control screen.
- 4. The selected fan speed indicator will appear on the screen.






Mode	Fan Speed
Cool	All speeds
Fan	All speeds
Dry	
Heat	All speeds
Auto	All speeds

## Note:

Fan Speed can't be adjusted on Dry mode .

**Note**: Fan Speed screen may appear slightly different , depending on the air conditioner model. Example as below:





#### **Control form2-Air Flow control**

- 1. Tap the Precision Air Flow button or Swing Flow button.
- 2. Choose your desired air flow and tap it.
- 3. Tap the X button to back to the main control screen.
- 4. The selected air flow indicator will appear on the screen.

Note: For some models without auto Left-Right wind, If you active it, you will hear a beep, but no any actions.








**Note**: The Main control screen and Air Flow screen may appear slightly different, depending on the air conditioner model. Example as below:






#### **Control form2-ECO function**

- 1. For Eco function, just tap the button to activate the function, the button will be lighting and the indicator will appear on the screen.
  - 2. Tap again to disable the function.
  - 3. Temperature controlled for some air conditioner model:
  - In Cooling mode, the new setting temperature will  $\geq 78^{\circ}$  .
  - In heating mode, the new setting temperature will  $\geq 77^{\circ}$ .





**Note**: The Main control screen and ECO control method may appear slightly different, depending on the air conditioner model. Example as below:




Mode	ECO enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

## **Control form2-Sleep function**

- 1. Tap the Sleep button.
- 2. Choose your desired sleep mode and tap it.
- 3. Tap the X button to back to the main control screen.
- 4. The selected sleep mode indicator will appear on the screen.






Sleep is disabled on Fan/ Dry/Auto mode .

Mode	Sleep enabled
Cool	Yes
Fan	
Dry	
Heat	Yes
Auto	

#### Note:

The Main control screen may appear slightly different ,depending on the air conditioner model. Example as below:







# Control form2-Timer(on) setting


- 1. Tap the Timer button.
- 2. Tap + in the upper right corner of the Timer main screen.
- 3. Choose the Time/Repeat/Switch OFF then tap Save.
- 4. The timer(off) will appear on the Timer main screen.








Tap repeat> then tap your desired repeat days or Once, then tap Confirm your selection.



OFF





#### Control form2-Timer(off) setting

- 1. Tap the Timer button.
- 2. Tap + in the upper right corner of the Timer main screen.

- 3. Set the Time/Repeat Date/Switch(ON)/Temperature/Mode/ Fan speed/Air Flow as your desired and then tap Save.
- 4. The timer will appear on the Timer main screen.








Tap repeat> then tap your desired repeat days or Once, then tap Confirm your selection.

Cancel	Repeat	Confirm
Once		
Monday		√
Tuesday		√
Wednesd	lay	√ <u> </u>
Thursday	,	1
Friday		√
Saturday		
Sunday		
•	tch> then o choose ( firm.	
Cancel	Switch	Confirm
	ON	
	OFF	



Tap Temperature/Mode/Fan Speed/
Air Flow > oneby one then setas your desired as mentioned on the previous chapter and tap Confirm the setting.

#### **Control form2-Timer management**

## 1. Change the Timer setting:


Tap anywhere of the timer list bar except the switch bar to get into the Timer setting screen, change the setting and then tap save.


## 2. Enable or Disable the Timer:

Tap the left of the switch to disable the Timer. Tap the right of the switch to enable the Timer.

#### 3. Delete the Timer:

Slide the list bar of the Timer from right to left until Delete button appear, then tap delete.






## **Control form2-More functions**

1. Tap the More button to operate additional functions if it appears on the screen.



## Note:


Some air conditioner model don't have the more button.




**Note**: The appearance maybe different, some icons will be hidden if the air conditional do no have this function or do not enable on the current mode.

- 2. Tap the " Display " to switch on/off the indoor LED display.
- 3. Tap the "Buzzer" to switch on/off the buzzing if it is available on the screen.
- 4. Tap the "Anti-Mildew" button to activate the Anti-Mildew function, if it is available on the screen.
- 5. Tap the "Health" button to switch on/off the healthy function, if it is available on the screen.

  It activate the antibacterial ionizer function. This function only for models with the ionizer generator.
- 6. Tap the "GEN Mode" button, if it is available on the screen. In this Mode, you can choose one of the three levels of current. The air conditioner will maintain proper current to save energy.





7. Tap the "Electricity Monitoring" button if it is available on the screen.

In this function, you can monitor the air conditioner electricity consumption.







You cantap this button to pop up the calenderthen select the date.

- 8. Tap the self-Cleaning function on User Manual.
- 9. Tap the "8 Heat" button , if it is available on the screen. This function help keep the room temperature over  $8C^{\circ}$ .




Check the details of the 8 C° Heat function on User Manual.


10. Tap the "Reservation" button, if it is available on the screen.

You can set the time, repeat day, temperature, mode, fan speed, air flow as you desired and then tap Save to activate the function.

The air conditioner will automatically reach your settings at the appointment time.








11. Tap the "Self-diagnosis" button, if it is available on the screen. The air conditioner will automatically diagnosis itself and indicate the Error code and the problem instructions if possible.








- 12. Tap the " Photosensitive " button if it is available on the screen.
  - This function allow the air conditioner to turn on/off the display automatically according to the light intensity.
- 13. Tap the "soft Wind" button if it is available on the screen.

  In this function, the air conditioner will blow soft airflow through the micro holes on the deflector.


### Device details and management


Tap on control form1 or tap ... on control form2, get into the device details screen. Here you can get some useful information and sharing the device to other accounts. Check the following pictures and instructions carefully.

### Control form1



### **Control form 2**







### **Device details and management**

#### How to share the devices to other accounts?

- 1. Tap "Device Sharing" and pop up Device Sharing screen.
- 2. Tap "Add Sharing".
- 3. Select the region and enter the account which you want to sharing.
- 4. Tap "Completed", the account will appear on your sharing list.
- 5. The received sharing members should hold pressing the home screen and slide down to refresh the device list, the device will appear on the device list.











Hold the bar about 3s then you can delete the sharing account.




## **Account management**


#### **Account Profile setting**



- 1. Tap the name of home at the left upper corner of the Home Screen and select the Home Management. Or tap Me and tap Home Management.
- 2. Tap one of the families in the family list and get into Family Settings screen



3. Set the family as the following indicators.



#### **Notice**

- 1. For technical update, there is maybe deviation of the actual items from what is on the manual. We express our apologies. Please refer to your actual product and APP.
- 2. Smart air conditioner APP can be altered without notice for quality improvement and also be deleted depending on the circumstances of manufacturing firms.

- 3. In case Wi-Fi signal strength is weakened, smart App may be disconnected. So make sure the indoor unit near to wireless router.
- 4. DHCP server function should be activated for wireless router.
- 5. The internet connection may fail because of a firewall problem. In this case, contact your internet service provider.
- 6. For smart phone system security and network setting, make sure Smart air conditioner APP is trusted.

# **Trouble Shooting**

Description	Analysis of cause
Air conditioner can't be configured succes sfully	<ol> <li>Check the mobile connected WLAN router SSID and password is correct;</li> <li>Check whether there are additional settings of WLAN router as shown below.</li> <li>Firewall by router itself or by PC</li> <li>MAC address filtering</li> <li>Hidden SSID 4)DHCP server</li> <li>Reboot WLAN router, mobile device and air conditioner (WLAN module) and connect air conditioner by CF mode again. Before rebooting, check nobody has already connected to same air conditioner.</li> </ol>
Mobile can't control a ir conditioner	<ol> <li>When air conditioner (WLAN module) is rebooted and app displays Device remove, ignoring this confirmation will lead to mobile device losing control permission of the air conditioner.         You will need to connect the air conditioner by CF mode again.     </li> <li>In case of power failure, mobile device will lose control permission of air conditioner for 3 minutes after power failure. (Notification will now show up on the mobile device.)</li> <li>If you cannot control the app (air conditioner) even after power restored, you will ne ed to connect the air conditioner by CF mode again.</li> </ol>
Mobile can't find air c onditioner	<ol> <li>App display Air conditioner Device offline. Please check the following conditions.</li> <li>The air conditioner has been reconfigured.</li> <li>Air conditioner out of power.</li> <li>Router out of power.</li> <li>Air conditioner can't connect to router.</li> <li>Air conditioner can't connect to network through the router.</li> <li>Mobile device can't connect to network.</li> <li>After adding the device, it disappears in device list.</li> <li>Hold and slide down to refresh the device list. If it has no change, shut down the ap p and start again.</li> </ol>





### **Documents / Resources**



IMPECCA ITAC08-LSA23 Air Conditioner Wi-Fi Function [pdf] User Manual ITAC08-LSA23, ITAC10-LSA23, ITAC10-LSB24, ITAC12-LSA23, ITAC12-LSB24, ITAC14-LRB24, ITAC08-LSA23 Air Conditioner Wi-Fi Function, ITAC08-LSA23, Air Conditioner Wi-Fi Function, C onditioner Wi-Fi Function

#### References

- User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.